Panasonic



Operating Manual

Business Communication Server

Model No. KX-NSX1000 KX-NSX2000

PanaTEL®

Thank you for purchasing this Panasonic product.


Please read this manual carefully before using this product and save this manual for future use. In particular, be sure to read "1.1.1 For Your Safety, page 12" before using this product.

KX-NSX series: PNMPR Software File Version 001.00000 or later

Feature Highlights

This PBX supports IP communication using a variety of IP telephones, such as the KX-NT300/KX-NT500 series with Self Labelling and/or Bluetooth® wireless headsets, Panasonic IP Softphones, and SIP phones. IP Proprietary Telephone IP Softphone SIP phone

Consult your dealer



Consult your dealer

Easy Operation

If you are using a certain Panasonic telephone that is equipped with a Navigator Key and a display, it helps you to access the desired feature easily. Also, you will be informed of the arrival of an incoming call or a message waiting by the lamp if it is equipped.






Navigator Kev

Message/Ringer Lamp

1.1 Before Operating the Telephones (page 12)

Cellular Phone Features


This PBX supports the use of cellular phones with the PBX. Cellular phones can make and receive calls as if they were registered extensions.



1.15 Cellular Phone Features (page 211)

This PBX optionally supports a Portable Station (PS) system. PSs can be used in the PBX with other wired telephones.

1.13 User Device Management (page 192)



1.10 Utilising the Call Centre (page 175)

In This Manual,

- The PBX functions provided by Business Communication Server are described here just "PBX" in this manual.
- · The following abbreviations are used:

APT → Analogue Proprietary Telephone

Display PT → Proprietary Telephone with a Display

DPT → Digital Proprietary Telephone

 $IP-PT \rightarrow IP$ Proprietary Telephone

PS → Portable Station

P-SIP → Panasonic SIP Phone (KX-HDV series/KX-TGP600)

PT → Proprietary Telephone

SIP extension/SIP Extn. \rightarrow Extensions of the PBX which uses Session Initiation Protocol for communication.

 $\mathsf{SLT} \to \mathsf{Single} \ \mathsf{Line} \ \mathsf{Telephone}$

You can set incoming calls to be redirected to your mailbox to let callers leave voice messages when you are unable to answer the phone. You can access your mailbox to listen to the messages when you are away from the office as well. Hello, this is John Smith. Please leave your message.

1.8 Using the Unified Messaging Features (page 106)

- "PT" is used as a generic term to represent IP-PT, DPT, APT and Display PT.
- The suffix of each model number (e.g., KX-NSX1000NE) is omitted.
- · The following icons are used frequently.



Hints



Conditions

Notice

- This PBX supports SIP (Session Initiation Protocol) phones. However, some PBX features may not be available for SIP phones, depending on your telephone type.
- Under power failure conditions, the connected telephones may not operate. Please ensure that a separate telephone, not dependent on local power, is available for emergency use.
- Prior to connection of this product, please verify that the intended operating environment is supported. Satisfactory performance cannot be guaranteed for the following:
 - interoperability and compatibility with all devices and systems connected to this product
 - proper operation and compatibility with services provided by telecommunications companies over connected networks

NOTES

- Some optional hardware, software, and features are not available in some countries/areas, or for some PBX models. Please consult your certified Panasonic dealer for more information.
- This manual provides basic information on how you can access commonly used PBX functions with proprietary telephones (PTs), single line telephones (SLTs), portable stations (PSs), SIP phones, and DSS Consoles. For detailed information about each feature or setting, consult your dealer.
- · In this manual, several kinds of PTs appear, as follows:
 - IP Proprietary Telephone (IP-PT)
 - Digital Proprietary Telephone (DPT)
 - Analogue Proprietary Telephone (APT)
 - Proprietary Telephone with a Display (Display PT)
 - "PT" is used as a generic term to represent all of these PTs. If a PBX feature only supports specific PTs, such as IP-PTs, the available telephone types are clearly indicated.
- IP-PTs/SIP extensions may become busy and you may not be able to make or receive calls, depending on the network status.
- The contents of this manual apply to PBXs with a certain software version, as indicated on the cover of this manual. To confirm the software version of your PBX, consult your dealer.
- · Product specifications are subject to change without notice.
- The preset melodies in this product are used with permission of © 2010 Copyrights Vision Inc.
- KX-UT series SIP phones are treated as general purpose SIP phones.

Notes for SIP Phone Users


Before using a SIP phone, please read the following notes.

For All SIP phone users

A tone may not be heard during an operation depending on the type of SIP phone being used. The following operation is an example.

[Example]

To use an account code (Account Code Entry)



For SIP phone users

- **a.** The following features are available for SIP phone users:
 - Making calls
 - Answering calls
 - Holding calls
 - Transferring calls (You cannot go on-hook before the transferred party answers.)
- **b.** The available operations using feature numbers are limited. Refer to the telephone types displayed at the top left of each operation.
- **c.** The tones listed in "5.4.1 What is This Tone?" are not available for SIP phone users. Tones or the tone types may vary depending on the type of telephone being used. For example, when you put a call on hold, a specific tone for the SIP phone may be heard, or no tone may be heard.
- **d.** Any number pressed while hearing a Busy/DND/Reorder tone, such as the feature number to activate Automatic Callback Busy, will be ignored.
- **e.** The operations for SIP phones may differ from the steps in this manual, and may vary depending on the type of telephone being used.
- **f.** To execute an operation, some SIP phones may require that the OK button is pressed after pressing all the buttons of the operation.

Notes for KX-WT115 PS Users

The operation and display of the KX-WT115 may differ from KX-TCA series PSs. For example, when the KX-WT115 is not answered while using it in parallel with a wired telephone, the display of incoming call log is different from that of the display of KX-TCA series PSs.

Notes for KX-NT300 Series, and KX-NT500 Series

If the primary PBX to which your telephone is connected fails, the extension may automatically switch its connection to a secondary PBX.

• The time required to switch to the secondary PBX or back to the primary PBX is different depending on the type of your telephone.

Feature Highlights

- When the extension switches its connection to the secondary PBX, your call will be disconnected if you
 are on a call.
- Even if the primary PBX becomes available again, your telephone will not reconnect to it if you are on a
- KX-NT300 can be connected via only the expansion gateway.

Notes for KX-NT543, KX-NT546, and KX-NT560 IP-PT Users

 While using a KX-NT543, KX-NT546, or KX-NT560 IP-PT in ECO mode, IP network transmission speed is relatively slow and the secondary Ethernet port cannot be used. To disable ECO mode, consult your dealer.

Trademarks

- Microsoft and Outlook are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc., and any use of such marks by Panasonic Corporation is under licence.
- All other trademarks identified herein are the property of their respective owners.
- Microsoft product screen shot(s) reprinted with permission from Microsoft Corporation.

Open Source Software

This product uses Open Source Software. For details, click the Information button in Web Maintenance Console.



Table of Contents

1	Operation	11
1.1	Before Operating the Telephones	12
1.1.		
1.1.2		
1.1.3		
1.1.4	4 Data Security	. 16
1.1.	5 Before Operating the Telephones	17
1.2	Making Calls	
1.2.		
1.2.2	, -	
1.2.3		
1.2.4	to the state of th	
1.2.		
1.2.6		. 41
1.2.7		
1.2.8		
1.2.9	9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)	42 45
1.3	Receiving Calls	
1.3.		
1.3.2		
1.3.3		
1.3.4		
		[′] 49
1.3.5	5 Using the ANSWER/RELEASE Button	50
1.3.6	6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID])	. 51
1.4	During a Conversation	53
1.4.	J ()	
1.4.2		
1.4.3	3 \ 1 \ 3/	
1.4.4	J J	
1.4.	and the state of t	
1.4.6		
1.4.7	J	
1.4.8		
1.5	Using a PDN/SDN Button	
1.5. ²		
1.6.	Before Leaving Your Desk	
1.6.2		
1.6.3		. 93 04
1.7	Making/Answering an Announcement	. 94
1.7.	1 Paging	. 90
1.7.2	- 3	. 90
1.7.3	3 Making a Conference Group Call	
1.8	Using the Unified Messaging Features	
1.8.		
1.8.2		
1.8.3	300 0 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	
1.8.4		
1.8.		
1.8.6		

1.8.7	Quick Reference	161
1.9	Setting the Telephone According to Your Needs	165
1.9.1	Setting the Alarm (Timed Reminder)	165
1.9.2	Refusing Incoming Calls (Do Not Disturb [DND])	166
1.9.3	Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/\(^\)OHCA)	Whispe
1.9.4	Displaying Your Telephone Number on the Called Party and Caller's Telephone (Connected Line Identification Presentation [CLIP/COLP])	(Calling
1.9.5	Preventing Your Telephone Number Being Displayed on the Caller's Telephone Number Bein	
1.5.5	(Connected Line Identification Restriction [COLR])	170
1.9.6	Preventing Your Number Being Displayed on the Called Party's Telephone (Call Identification Restriction [CLIR])	ing Line
1.9.7	Preventing Other People from Joining Your Conversation (Executive Busy (Deny)	Override
1.9.8	Turning on the Background Music (BGM)	
1.9.9	Protecting Your Line against Notification Tones (Data Line Security)	
1.9.10	Checking the Time Service Status	1/2
1.9.11	Setting the Parallelled Telephone to Ring (Parallelled Telephone)	۱/۵
1.9.12	Clearing Features Set at Your Extension (Extension Feature Clear)	1/4
1.10	Utilising the Call Centre	
1.10.1	Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up)	1/5
1.10.2	Monitoring and Controlling the Call Status of an Incoming Call Distribution	
	(Incoming Call Distribution Group Monitor)	
1.10.3	Forwarding a Waiting Call (Manual Queue Redirection)	
1.11	Using User-supplied Equipment	
1.11.1	If a Doorphone/Door Opener is Connected	
1.11.2	If an External Relay is Connected	
1.11.3	If an External Sensor is Connected	
1.11.4	If a Host PBX is Connected	
1.12	Administrative Features	
1.12.1	Using the Telephones in a Hotel-type Environment (Hospitality Features)	
1.12.2	Recording Information Using Preprogrammed Messages (Printing Message)	191
1.13	User Device Management	192
1.13.1	Introduction to the User Container Feature	192
1.13.2	Service-in/Service-out (Smart Desk)	193
1.13.3	Switching between CTI Control Devices	
1.14	Using a Telephone with a Display	
1.14.1	Using the Call Log	
1.14.2	Using the Directories	
1.14.3	Accessing System Features (System Feature Access)	
1.14.4	Self Labelling (KX-NT366/KX-NT553/KX-NT556/KX-NT560 only)	209
1.15	Cellular Phone Features	211
1.15.1	Cellular Phone Features	
_		
2 Ma	nager Operation	
2.1.1	Extension Control	
2.1.1	Time Service Mode Control	
2.1.2	Restriction Level Control (Dial Tone Transfer)	∠10 247
2.1.3		
	Turning on the External Background Music (BGM)	
2.1.5	Recording Outgoing Messages (OGM)	
2.1.6	Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)	
2.2	Configuring Unified Messaging Features	
2.2.1	System Manager Features	
2.2.2	Message Manager Features	234

3 Cı	ustomising Your Phone & System	251
3.1 3.1.1	Customising Your Phone (Personal Programming) Customising Your Phone (Personal Programming)	252
3.1.2 3.1.3	Settings on the Programming Mode Customising the Buttons	
3.2 3.2.1	System Programming Using Web Maintenance Console User Programming	
4 Cı	ustomising Extensions and the System–for Managers	277
4.1	Manager Programming	
4.1.1	Programming Information	
4.1.2	Manager Programming	
4.1.3	Supervisory Monitor (ACD) Control	280
5 A ₁	ppendix	289
5.1	List of Operations by Telephone Type	290
5.1.1	List of Operations by Telephone Type	
5.2	Troubleshooting	
5.2.1	Troubleshooting	
5.3	Feature Number Table	
5.3.1	Feature Number Table	300
5.4	What is This Tone?	310
5.4.1	What is This Tone?	310

Section 1 Operation

This section shows you step by step how to use each feature. Read this chapter to become familiar with the many useful features of this NSX server.



1.1 Before Operating the Telephones

1.1.1 For Your Safety

To prevent personal injury and/or damage to property, be sure to observe the following safety precautions.

The following symbols classify and describe the level of hazard and injury caused when this unit is operated or handled improperly.

MARNING

This notice means that misuse could result in death or serious injury.

CAUTION

This notice means that misuse could result in injury or damage to property.

The following types of symbols are used to classify and describe the type of instructions to be observed.



This symbol is used to alert users to a specific operating procedure that must not be performed.



This symbol is used to alert users to a specific operating procedure that must be followed in order to operate the unit safely.



WARNING

For All Telephone Equipment



- Do not allow rain to fall on the product or expose the product to moisture. Do not let water, oils, or other liquids to splash onto the product. Such conditions can lead to fire or electric shock, and may impair the performance of the product.
- Do not place the product on an unstable or uneven surface. If the product were to fall over, it may cause injury or damage to the product.
- Do not allow anything to rest on the power cord. Do not locate the product where the power cord may be stepped on or tripped on.
- Do not supply power to a combination of devices that exceeds the total rated capacity of the wall outlets or extension cables used. If outlets, power strips, extension cords, etc. are used in a manner that exceeds their rated capacity, they emit large amounts of heat, which could cause a fire.



- The product must only be installed and serviced by qualified service personnel. The product should be used as-is from the time of purchase; it should not be disassembled or modified. Disassembly or modification can cause a fire, electric shock, or damage to the product.
- Follow all warnings and instructions marked on the product.
- Products that require a power source should only be connected to the type of electrical power supply specified on the product label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- For safety purposes some products are equipped with an earthed plug. If you do not have an earthed outlet, please have one installed. Do not bypass this safety feature by tampering with the plug.
- Regularly clean dust off of all equipment. Excessive amounts of dust can lead to fire or electric shock, and may impair the performance of the product.
- Unplug the product from the wall outlet and contact your dealer in the following cases:
 - **a.** When the power supply cord or plug is damaged or frayed.
 - **b.** If liquid has been spilled into the product.
 - **c.** If the product has been exposed to rain or water.
 - **d.** If the product does not operate according to the operating instructions. Adjust only the controls that are explained in the operating instructions. Improper adjustment of other controls may result in damage and may require service by a qualified technician to restore the product to normal operation.
 - e. If the product has been dropped or the cabinet has been damaged.
 - **f.** If product performance deteriorates.

For the NSX server



- Do not insert foreign objects of any kind into this product, as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock.
- Do not pull, bend, rest objects on, or chafe the power cord and plug. Damage to the power cord or plug can cause fire or electric shock.
- Do not attempt to repair the power cord or plug. If the power cord or plug is damaged or frayed, contact an authorised Panasonic Factory Service Centre for a replacement.



- When mounting the NSX server on a 19-inch rack, only use the 19-inch rack mounting equipment (attachment bracket, screws) included with the NSX server.
- If damage to the unit exposes any internal parts, disconnect the power supply cord immediately and return the unit to your dealer.
- Unplug this unit from the AC outlet if it emits smoke, an abnormal smell or makes unusual noise. These
 conditions can cause fire or electric shock. Confirm that smoke has stopped and contact an authorised
 Panasonic Factory Service Centre.
- This unit is equipped with an earthed plug. For safety reasons this plug must only be connected to an earthed outlet that has been installed according to applicable regulations.

• Plug the power cord firmly into an AC outlet. Otherwise, it can cause fire or electric shock.



CAUTION

For All Telephone Equipment



- The product should be kept free of dust, moisture, high temperature (more than 40), and vibration, and should not be exposed to direct sunlight.
- Unplug the product from the wall outlet before cleaning. Wipe the product with a soft cloth. Do not clean
 with abrasive powders or with chemical agents such as benzine or thinner. Do not use liquid cleaners or
 aerosol cleaners.

For the NSX server



- When relocating the equipment, first disconnect the telecom connection before disconnecting the power connection. When the unit is installed in the new location, reconnect the power first, and then reconnect the telecom connection.
- The power supply cord is used as the main disconnect device. Ensure that the AC outlet is located near the equipment and is easily accessible.
- Slots and openings in the front, back and bottom of the cabinet are provided for ventilation; to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface while in use. The product should never be placed near or over a radiator or other heat source. This product should not be placed in a sealed environment unless proper ventilation is provided.
- When this product is no longer in use, make sure to detach it from the rack or wall.
- · To protect this unit from static electricity, do not touch any external connectors of the unit.

Notice

For All Telephone Equipment

- · Read and understand all instructions.
- When using a Panasonic proprietary telephone (PT), use only the correct Panasonic handset.

For the NSX server

- Keep the unit away from heating appliances and devices that generate electrical noise such as fluorescent lamps, motors and televisions. These noise sources can interfere with the performance of the NSX server.
- If you are having problems making calls to outside destinations, follow this procedure to test the outside lines:
 - 1. Disconnect the NSX server from all outside lines.
 - 2. Connect known working single line telephones (SLTs) to those outside lines.
 - **3.** Make a call to an external destination using those SLTs.

If a call cannot be carried out correctly, there may be a problem with the outside line that the SLT is connected to. Contact your telephone company.

If all SLTs operate properly, there may be a problem with your NSX server. Do not reconnect the NSX server to the outside lines until it has been serviced by an authorised Panasonic Factory Service Centre.

Note

For All Telephone Equipment

· Never attempt to insert wires, pins, etc. into the vents or holes of the product.

1.1.2 Important Safety Instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

- Do not use the product near water, for example, near a bathtub, wash bowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool.
- Avoid using wired telephones during an electrical storm. There is a remote risk of electric shock from lightning.
- Do not use a telephone in the vicinity of a gas leak to report the leak.
- Rack Mount Instructions—The following or similar rack-mount instructions are included with the installation instructions:
- a. Elevated Operating Ambient—If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.
- **b.** Reliable Earthing—Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (e.g., use of power strips).

SAVE THESE INSTRUCTIONS

1.1.3 Precautions

For users in the European Union only

Disposal of Old Equipment and Batteries
Only for European Union and countries with recycling systems



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries must not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and batteries, please take them to applicable collection points in accordance with your national legislation.

By disposing of them correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment.

For more information about collection and recycling, please contact your local municipality.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.



Note for the battery symbol (bottom symbol)

This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.

For users in New Zealand only

- This equipment shall not be set to make automatic calls to the Telecom '111' Emergency Service.
- The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted
 that the item complies with minimum conditions for connection to its network. It indicates no endorsement
 of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance
 that any item will work correctly in all respects with another item of Telepermitted equipment of a different
 make or model, nor does it imply that any product is compatible with all of Telecom's network services.
- APPLICABLE ONLY TO TELECOM CUSTOMERS WHO HAVE AUTOMATIC ACCESS TO OTHER CARRIERS FOR TOLL CALLS
 When calling back a number from the Caller ID list, all numbers prefixed with "0 + AREA CODE" will be automatically forwarded to your toll carrier. This includes numbers in your local calling area. The zero + area code should either be removed when calling back local numbers, or check with your toll carrier that a charge will not be levied.
- All persons using this device for recording telephone conversations shall comply with New Zealand law.
 This requires that at least one party to the conversation is to be aware that it is being recorded. In addition, the principles enumerated in the Privacy Act 1993 shall be complied with in respect to the nature of the personal information collected, the purpose for its collection, how it is used, and what is disclosed to any other party.
- The SLT ports are not specifically designed for 3-wire-connected equipment. 3-wire-connected equipment might not respond to incoming ringing when attached to these ports.

1.1.4 Data Security

In order to use the NSX server safely and correctly, the Security Requirements below must be observed. Failure to do so may result in:

- · Loss, leakage, falsification or theft of user information.
- · Illegal use of the NSX server by a third party.
- Interference or suspension of service caused by a third party.

What is User Information?

User Information is defined as:

- 1. Information stored on the Storage Memory Card: System data, error data and activation key files.
- Information sent from the NSX server to a PC or a USB memory device: System data, sound files for MOH (Music on Hold) and OGM (Outgoing Messages), and activation key files.

Requirements

- 1. The Storage Memory Card contains software for all the processes of the NSX server and all the customer data. Therefore, do not allow unauthorised access to prevent data leakage.
- 2. Always make backups of data stored on the Storage Memory Card and/or perform regular system data backups to a USB memory device or a NAS. For details, consult your dealer.
- 3. To prevent illegal access from the Internet, activate a Firewall.

- **4.** To avoid unauthorised access and possible abuse of the NSX server, we strongly recommend:
 - a. Keeping the password secret.
 - **b.** Selecting a complex, random password that cannot be easily guessed.
 - **c.** Changing your password regularly.
- **5.** Perform the following when sending the NSX server for repair or handing it over to a third party.
 - **a.** Make a backup of data stored on the Storage Memory Card.
 - **b.** Using a formatter, format the Storage Memory Card so that information cannot be retrieved from it.
- **6.** To prevent data leakage, render the Storage Memory Card physically unusable before disposal.
- 7. When user information is sent from the NSX server to a PC or a USB memory device, the confidentiality of that information becomes the responsibility of the customer. Before disposing of the PC or the USB memory device, ensure that data cannot be retrieved from it by formatting the hard disk and/or rendering it physically unusable.

1.1.5 Before Operating the Telephones

What Kind of Telephone Can Be Used?

You can use the following types of telephone with this PBX:

- Panasonic IP Proprietary Telephone (IP-PT) (e.g., KX-NT300 series, KX-NT500 series)
- Panasonic Digital Proprietary Telephone (DPT) (e.g., KX-DT300 series, KX-DT500 series)
- Panasonic Analogue Proprietary Telephone (APT) (e.g., KX-T7700 series)
- Panasonic Portable Station (PS) (e.g., KX-TCA364, KX-WT125 [Canada only])
- SIP phone (e.g., Third party SIP phones, P-SIP)
- Single Line Telephone (SLT) (e.g., rotary pulse telephone)

Which features are available depend on the type of telephone being used. If you are using a Panasonic telephone with a special feature button such as or a display or both, you can follow the operations using the buttons or displayed messages for easy programming. If you use a large display telephone (e.g., KX-NT346), you can follow the displayed messages to use the features. If your telephone does not have feature buttons and/or a display, you may operate the PBX by entering a feature number instead. Follow the operation for your type of telephone.







 If you use a Panasonic proprietary telephone which does not have feature buttons, you may change one of the unused flexible buttons to a feature button. Refer to "3.1.3 Customising the Buttons".

Registration for your Portable Station (PS)/SIP Phone

Your PS, SIP phone must be registered with the PBX and assigned an extension number before initial use, through system programming. To confirm the extension number of your PS, refer to "Your extension information" in "3.1.2 Settings on the Programming Mode". For SIP phone users, follow the instructions for your phone.

Section Feature Numbers

To use certain features, you need to enter specified feature numbers (and an additional parameter, if required).

There are two types of feature numbers as follows:

- · Flexible feature number
- · Fixed feature number

Fixed feature numbers cannot be changed. However, you can change the flexible numbers to other numbers for easier use. In this manual, the default numbers (factory installed) are used for operations. A flexible number is shown as (half-shaded key). Use the new programmed number if you have changed the feature number. Write the new number in "5.3.1 Feature Number Table" (Appendix).

Notice

The default value of a flexible feature number may vary depending on country/area.



If you use a single line telephone which does not have the "*" or "#" keys; it is not possible to access features that have "*" or "#" in their feature numbers.

♦♦ Tone

You will hear various tones, during or after an operation, for confirmation. Refer to "5.4.1 What is This Tone?" (Appendix).

Display

In this manual, "the display ..." refers to the display of a Panasonic telephone. If your telephone is not a Panasonic display telephone, the message will not be displayed. If you use a Panasonic display telephone, the display helps you confirm the settings. Some telephones also give you easy access to features. Messages are displayed according to the feature used. By pressing the corresponding button on the side or at the bottom of the display, or by pressing the Navigator Key, you can access various features. Furthermore, depending on the display telephone used, you can operate features or make calls using the displayed message. Refer to "1.14 Using a Telephone with a Display".

Notice

In this manual, the display messages are described in English.

Your Extension Number


If you use a Panasonic display proprietary telephone, you can check your own extension number on the display. Press the TRANSFER button or Soft (S1) button while on-hook.


ECO mode

If you use a KX-NT543, KX-NT546, or KX-NT560 IP-PT in ECO mode, the "ECO" icon is shown on the display during programming mode (refer to "3.1.3 Customising the Buttons"). For more information, consult your dealer.

Using a Navigator Key/Volume Key

The Navigator Key can be used for the display contrast and the volume control or you can search for desired items on the display. Press the Navigator Key/Volume Key in the desired direction. The contrast or the volume level and the items will change as follows:





Examples

The displays and the illustrations shown as examples are from a telephone connected to the KX-NS1000.

Restrictions

Some features may be restricted at your extension depending on system programming and the type of telephone being used.

| lcon Descriptions

The following icons show you the feature availability, notes and action to use the features.

979	This feature cannot be used with a single line telephone.	(CO)	Seize an outside line (One of the following).
		0/9	Press the CO button.
B	See "Programming" for Related Programming if necessary.	8 outside line group no.	Dial automatic line access number 0/9.
		<u>G cap ass</u>	Dial outside line group access number and outside line group number.

	Off-hook (One of the following). Lift the handset. Press the SP-PHONE button. Press the MONITOR button. (To start talking, lift the handset.) Press TALK button.		Press the Call button on the Doorphone.
	On-hook (One of the following). • Hang up. • Press the SP-PHONE button. • Press the MONITOR button. • Press CANCEL button.	८ ∰√	Press the hookswitch lightly.
	Press the corresponding feature button on the proprietary telephone or SIP phone.	G (1/2	Talk or make an announcement.
desired no.	Enter the required number. <example> account code Enter the account code.</example>		You will hear a busy, confirmation, dial, ring or ringback tone. B. Tone: Busy Tone C. Tone: Confirmation Tone D. Tone: Dial Tone R. Tone: Ring Tone R. B. Tone: Ringback Tone
(extension no.)	Dial an extension number.	outside phone no.	Dial outside phone number.
phone no.	Dial the telephone number.	dial key	Press any dial key (0−9, ★, #).
HOLD	Press the HOLD button on your SIP phone.	REDIAL	Press the REDIAL button on your SIP phone.

When You Use a Panasonic Proprietary Telephone

Panasonic proprietary telephones have useful feature buttons that simplify some operations. For details, refer to the "Location of Controls" or equivalent section in the documentation for your phone.

Customised Buttons

If the term is in parentheses like (Account) in this manual, it means a flexible button has been made into an "Account" button. For more information, refer to "3.1.3 Customising the Buttons" when using a PT or PS, or " Editing Settings in My Portal" when using Web Maintenance Console.


Button	Feature
Loop-CO (L-CO)	Used to access an idle outside line for making outside calls. Incoming outside calls from any outside line arrive at this button.
Group-CO (G-CO)	Used to access an idle outside line in a specified outside line group for making outside calls. Incoming calls from outside lines in the assigned outside line group arrive at this button.

Button	Feature
Single-CO (S-CO)	Used to access a specified outside line for making or receiving outside calls.
Direct Station Selection (DSS)	Used to access an extension with one touch. It is also possible to be changed to the other feature button.
One-touch Dialling	Used to access a desired party or system feature with one touch.
Incoming Call Distribution Group (ICD Group)	Used to access a specified incoming call distribution group for making or receiving calls.
Message	Used to leave a message waiting indication or call back the party who left the message waiting indication.
Message for Another Extension	Used to have a Message button for another extension.
Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls	Used to forward all calls to a specified destination or refuse.
FWD/DND—Outside calls	Used to forward outside calls to a specified destination or refuse.
FWD/DND—Intercom calls	Used to forward intercom calls to a specified destination or refuse.
Group FWD—Both calls	Used to forward all the calls to your group to a specified destination.
Group FWD—Outside calls	Used to forward the outside calls to your group to a specified destination.
Group FWD—Intercom calls	Used to forward the intercom calls to your group to a specified destination.
Account	Used to enter an account code.
Conference	Used to establish a multiple party conversation.
Terminate	Used to disconnect the current call and make another call without hanging up.
External Feature Access (EFA)	Used to access special features offered by a host PBX or a telephone company.
Call Charge Reference	Used to check the total call charge for your own extension.
Call Park	Used to park or retrieve a call in a preset parking zone.
Call Park (Automatic Park Zone)	Used to park a call in an idle parking zone automatically. Set both the Call Park (Automatic Park Zone) button and the Call Park (preset parking zone) button.
Call Log	Used to show the incoming call information.
Call Log for ICD Group	Used to have a Call Log button for incoming call distribution group.
Log-in/Log-out	Used to switch between the log-in and log-out mode.
Log-in/Log-out of a specified group	Used to have a Log-in/Log-out button for another incoming call distribution group.
Log-in/Log-out for all groups	Used to have a Log-in/Log-out button for all groups.
Hurry-up	Used to transfer the longest waiting call in the queue of an incoming call distribution group to the overflow destination.
Wrap-up	Used to switch the wrap-up status, Ready and Not Ready mode.

Button	Feature
System Alarm	Used to confirm a NSX server error. Also, pressing the System Alarm button displays the current Multi-Connection networking status.
Time Service (Day/Night/ Lunch/Break)	Used to switch the time service mode.
Answer	Used to answer an incoming call.
Release	Used to disconnect the line during or after a conversation or to complete a Call Transfer.
Toll Restriction/Call Barring	Used to change the toll restriction/call barring level of other extension users temporarily.
ISDN Service	Used to access an ISDN service.
Calling Line Identification Restriction (CLIR)	Used to switch between the CLIP and CLIR services.
Connected Line Identification Restriction (COLR)	Used to switch between the COLP and COLR services.
ISDN-Hold	Used to transfer a call using telephone company.
Headset	Used to talk using the headset.
Time Service Switching Mode (Automatic/Manual)	Used to switch the time service mode, Automatic or Manual.
Two-way Record	Used to record a conversation into your own mailbox.
Two-way Transfer	Used to record a conversation into the mailbox of a specific extension.
One-touch Two-way Transfer	Used to record a conversation into the mailbox of a specific extension with one touch.
Live Call Screening (LCS)	Used to monitor your own voice mailbox while an incoming caller is leaving a message and, if desired, intercept the call.
Voice Mail Transfer	Used to transfer a call to the mailbox of a specified extension. Also used to access the Unified Messaging system with one touch.
CTI	Used to access CTI features.
Check-in	Used to switch the room status of extensions from Check-out to Check-in.
Check-out	Used to switch the room status of extensions from Check-in to Check-out.
Cleaned-up	Used to switch the room status of extensions between Ready and Not Ready.
Primary Directory Number (PDN)	Used to make and receive both outside and intercom calls.
Secondary Directory Number (SDN)	Used to show the current status of another extension, call the extension, and pick up or transfer calls to it.
Directory Number (DN)	Used to make intercom or outside calls.

♦♦ How to Follow the Steps

An example of system operation is shown below.




Telephone types in procedures

The following abbreviations are displayed at the top left of each procedure and indicate which types of telephones support the operation. However, in some cases a specific model number is given instead.

Abbreviation		Telephone Type
PT		Proprietary Telephone (e.g., KX-NT300 series, KX-NT500 series, KX-T7700 series)
	DPT	Digital Proprietary Telephone (e.g., KX-DT300 series, KX-DT500 series)
	Display PT	Proprietary Telephone with a Display (e.g. KX-NT346, KX-NT546, KX-DT346, KX-DT546)
PS	·	Portable Station (e.g., KX-TCA364, KX-WT125 [Canada only])
SIP Ext	n.	SIP phone (e.g., Third party SIP phones, P-SIP)
SLT		Single Line Telephone (e.g., KX-T7710)

Connection Example

This diagram shows you a connection example.



- 1TSP: Internet Telephony Service Provider
- DCE: Data Circuit Terminating Equipment


1.2 Making Calls

1.2.1 Basic Calling

- Calling Another Extension
- Calling an Outside Party
- Making a Call to a Private Network (TIE Line Access)
- Using an Account Code (Account Code Entry)

Calling Another Extension

To call an extension (Intercom Call)





The DSS button light shows the current status as follows:

Off: The extension is idle.

Red on: Your or another extension is using the line.

 * You have to press the SDN button once or twice depending on the mode of the SDN button. For details, refer to "1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension".



- To call using a directory, refer to "1.14.2 Using the Directories".
- For guick operation
- If you are an operator or dial some extensions frequently, DSS buttons are useful.
- Hands-free Operation
 You can make an intercom call and have a conversation in hands-free mode using the SP-PHONE button.




Customising Your Phone

- 3.1.2 Settings on the Programming Mode—Preferred Line Assignment—Outgoing Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons
 Create or edit a Direct Station Selection (DSS) button.

To call an operator (Operator Call)

You can call an extension or a group assigned as the operator.






• The operator call number (default) varies depending on country/area.

Calling an Outside Party

You have to seize an outside line before dialling an outside phone number because external calls are made via your PBX.

Select one of the following methods:


To select an idle outside line automatically (Automatic Line Access)






• The automatic line access number (default) varies depending on country/area.

To select an idle outside line in the specified outside line group automatically (Outside Line Group Access)



To select the specified outside line





Each of the S-CO button or G-CO button light shows the current status as follows:
 Off: The line is idle.

Red on: The line is in use.

 You may be restricted from making a call to the specified outside party. To make a call, refer to "1.2.7 Calling without Restrictions".



- To confirm number before dialling, you can enter a phone number and confirm it on the display and then go off-hook. (Predialling)
- Call Charge Reference
 You can confirm your total call charges by pressing the Call Charge Reference button.
- To make a call to another party without going on-hook, press the FLASH/RECALL button. It will re-access the outside line and provide external dial tone. Pressing the Terminate button will provide intercom dial tone. You can dial the new phone number without going on/off-hook.
- Hands-free Operation

You can make an outside call and have a conversation in hands-free mode using the SP-PHONE button.




Customising Your Phone

- 3.1.2 Settings on the Programming Mode—Preferred Line Assignment—Outgoing Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons
 Create or edit a Loop-CO (L-CO) button, a Group-CO (G-CO) button, a Single-CO (S-CO)
 button, a Terminate button or a Call Charge Reference button.

♦♦ Making a Call to a Private Network (TIE Line Access)

You can access extensions connected to other PBXs in a private network.

To call






* Which type of telephone number must be entered depends on the settings of your PBX.

Using an Account Code (Account Code Entry)

You may give a specified account code to extension users and check their telephone usage. You can specify an account code for each client and check the call duration.





- A Panasonic proprietary telephone extension user can enter an account code during a conversation and when hearing reorder tone after the other party hangs up.
- · Account codes may use the digits "0" through "9".
- Depending on the settings of your PBX, you may be required to enter an account code to make an outside call.
- If you enter the wrong code, press the "X" key and re-enter the account code.



• For your convenience, you can store the code with the phone number in the memory (e.g., Speed Dialling).



Customising Your Phone

 3.1.3 Customising the Buttons Create or edit an Account button.

1.2.2 Easy Dialling

This is convenient for frequently dialled phone numbers.


- With a One-touch Button (One-touch Dialling)
- Using Numbers Stored at Your Extension (Personal Speed Dialling)

- − ♦ Using Numbers Stored in the PBX (System Speed Dialling)
- To a Preset Number by Going Off-hook (Hot Line)
- \ Using a Preprogrammed Number (Quick Dialling)

With a One-touch Button (One-touch Dialling)

You can store a phone number into the flexible button for one-touch operation.








Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a One-touch Dialling button, store the desired phone number or feature number.


♦♦ Using Numbers Stored at Your Extension (Personal Speed Dialling)

You can store up to 100 numbers at your extension for your personal use. This feature is also known as Station Speed Dialling.

To store a phone number



To dial






- To call using a directory, refer to "1.14.2 Using the Directories".
- For SIP phone users: Telephones display only personal speed dialling numbers.

♦♦ Using Numbers Stored in the PBX (System Speed Dialling)

You can make calls using speed dialling numbers stored in the PBX.






- To call using a directory, refer to "1.14.2 Using the Directories".
- For SIP phone users: Telephones display only system speed dialling numbers.


♦ To a Preset Number by Going Off-hook (Hot Line)

You can make an outside call simply by going off-hook if you have preprogrammed your phone. This feature is also known as Pickup Dialling.


To store a phone number



To set/cancel



To dial





- To call another party, dial the desired party's phone number before the preprogrammed number is dialled.
- You should assign the intercom line as the seized line when going off-hook. (Preferred Line Assignment—Outgoing)
- It is possible to increase the delay before Hot Line is activated through system programming. This can be useful if you require more time after going off-hook to dial another telephone number or extension number.




Customising Your Phone

• 3.1.2 Settings on the Programming Mode—Preferred Line Assignment—Outgoing Select the seized line when going off-hook.

♦ Using a Preprogrammed Number (Quick Dialling)

You can make a call simply by pressing the preprogrammed number for quick dialling.






This is a useful feature for hotels.
 For example, to dial Room Service, dial the digit "3", not the full extension number.


1.2.3 Redial

This is convenient when calling the same outside party again.

Redialling the Last Number You Dialled (Last Number Redial)

Redialling the Last Number You Dialled (Last Number Redial)







- Up to 32 digits can be stored and redialled.
- · After pressing REDIAL, if you hear a busy tone again, press REDIAL to retry.
- If you want to log outgoing intercom calls to the outgoing call log, consult your System Installer.
- If you have seized a trunk, pressing the REDIAL button will be ignored if the last number you dialled was an extension.



Automatic Redial

To redial automatically, press the SP-PHONE button and then the REDIAL button, or press the REDIAL button directly. It will keep trying the busy number until the called party answers or until a specified timeout.

You can perform other tasks during dialling. To cancel, press the FLASH/RECALL button. Some outside lines may not support this feature.

This feature is not available for the PS.

1.2.4 When the Dialled Line is Busy or There is No Answer

- Reserving a Busy Line (Automatic Callback Busy)
- Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])
- Sending a Call Waiting Notification (Call Waiting)
- Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)


- Joining an Existing Call (Executive Busy Override)
- Monitoring Another Extension (Call Monitor)
- To an Extension Refusing the Call (DND Override)

Reserving a Busy Line (Automatic Callback Busy)


You can set the telephone to receive callback ringing:

- · when a dialled extension becomes idle.
- when your desired outside line that is in use by another extension becomes idle. You cannot set Automatic Callback Busy for a busy party outside of the PBX. When you answer the callback ringing:
- · For an outside call: The line is seized.
- · For an intercom call: The called extension starts ringing automatically.


To set (for both extension and outside line)



To answer the callback ringing from an idle extension




To answer the callback ringing from an idle outside line





• If you do not answer the callback ringing within 10 seconds, this feature will be cancelled.


To cancel callback ringing (Automatic Callback Busy Cancel)



◆◆ Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])

You can set the telephone to receive callback ringing when a busy called party on an ISDN line becomes free.


When you answer the callback ringing, the called party's telephone number is automatically dialled.



To answer while hearing a callback ringing



To cancel (CCBS Cancel)






- If you do not answer within a specified time period, this feature will be cancelled.
- · Availability of this feature depends on the ISDN service of your telephone company.

Sending a Call Waiting Notification (Call Waiting)

You can inform the called party that your call is waiting. This feature is also known as Busy Station Signalling (BSS).






- Depending on the type of the other party's telephone, you may be able to talk to the other party using the speaker and the microphone (Off-hook Call Announcement [OHCA]), or you can send a call announcement through the handset (Whisper OHCA), if they are having another conversation using the handset.

 Refer to "1.9.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/ Whisper OHCA)".
- Depending on system programming and the called extension's setting, a call waiting tone may be sent automatically without performing the operation above.


◆◆ Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)

- ◆ For an extension leaving a message waiting indication
 When the called extension is busy or does not answer your call, you can leave a notification so that the called party may call you back.
- ◆ For an extension receiving a message waiting indication
 As a message receiver, the Message button light or Message/Ringer
 Lamp lets you know that a call has been received. If you receive
 notification, you can call the caller back by a simple operation.




◆ For an extension leaving a message waiting indication

To leave a message waiting indication




To leave/cancel a message waiting indication





♦ For an extension receiving a message waiting indication

To check the left message and call back



To call back








 Performing this operation after receiving multiple waiting indications will call back the extension that left the most recent message waiting indication.

To clear message waiting indications left on your extension





- The Message button light or Message/Ringer Lamp shows the current status as follows:
 Off: No message
 - Red on: You have a message.
- · The display shows the messages starting with the most recent call.
- At a called extension, the MESSAGE button allows you to clear message waiting indications
 if you do not want to call the callers back. To clear, press the MESSAGE button and then
 press the soft button.
- On your PT, you can establish one or more Message for Another Extension buttons. These
 buttons can accept the message waiting notification of other extensions or various incoming
 call distribution groups.
 - In other words, you can monitor the message waiting notifications of other telephones.
- A single line telephone extension user will receive a special dial tone as message waiting notification when going off-hook.
- The message waiting lamp of a single line telephone can also let you know that you have a message in the same way as the Message button.




Customising Your Phone

• 3.1.3 Customising the Buttons
Create or edit a Message button or Message for Another Extension button.


♦ Joining an Existing Call (Executive Busy Override)

The preprogrammed extension can call someone who is busy on the telephone and establish a three-party conversation. After pressing a DSS button, you can check the caller information of the call to another extension on the display before establishing a three-party conversation.

To join an intercom call



To join an outside call






- SIP phone users cannot use this feature, but other extensions can call them using Executive Busy Override.
- To join another conversation, you must have Executive Busy Override enabled at your extension through COS programming.
- It is possible for an originating extension to leave a three-party conversation with an outside party and let the two other parties talk by simply going on-hook.

◆ For the originating extension

To talk to each party alternately






 You can also deny others the possibility of joining your conversation (Default: Allow). Refer to "1.9.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)".

Monitoring Another Extension (Call Monitor)

The preprogrammed extension can monitor another extension. After pressing a DSS button, you can check the caller information of the call to another extension on the display. Then, you can choose to monitor the call, if necessary.

To monitor






SIP phone users cannot use this feature, but they can be monitored by other extensions.

♦ To an Extension Refusing the Call (DND Override)

The preprogrammed extension can call someone who has set the DND feature.






 SIP phone users cannot use DND Override to call someone who has set the DND feature, but can let other extensions call them using DND Override when the DND feature is set.

1.2.5 Accessing the ISDN Service (ISDN Service Access)

You can access services provided by the ISDN.



To access





Availability of features depends on the ISDN service of your telephone company.



Customising Your Phone

• 3.1.3 Customising the Buttons Create or edit an ISDN Service button.


1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice)

The caller can alternate the alerting method, either ring or voice, when making an intercom call.


On the other hand, any extension can set the alerting method, either ring or voice, when receiving an intercom call

Ringing (Default): You can call the other party with a ring tone.

Voice-calling: You can talk to the other party immediately after confirmation tone.



To change the method





- Voice-calling from a SIP extension is not available.
- If the called party uses a SIP extension, single line telephone (SLT) or portable station (PS), Voice-calling is not available.
- This feature is not available when the called party's telephone is in the Voice Call Deny mode.



Customising Your Phone

• 3.1.2 Settings on the Programming Mode—Alternate Receiving—Ring/Voice Select the alerting method, either ring or the other party's voice.


1.2.7 Calling without Restrictions

Using Your Calling Privileges at Another Extension (Remote COS Access)


Using Your Calling Privileges at Another Extension (Remote COS Access)

You can use your calling privileges (Class of Service) at another extension. You may override restrictions which have been set. To use this feature, an original extension number and an extension PIN (Personal Identification Number) are required. You can make a call by entering a verification code and verification code PIN.

To call (Walking COS)



To call with a verification code (Verification Code Entry)




1.2.8 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])

Calling through DISA


Calling through DISA

When outside callers access extensions in the PBX, a prerecorded message greets the caller and gives information about how to access an extension. You do not need the operator's assistance.


You may be able to access system features or call an outside party with your password depending on the security mode.



To call an extension




To call an outside party





- * Callers from preprogrammed outside numbers can access the PBX through DISA without a password (extension PIN/verification code PIN) (DISA Automatic Walking COS).
- When making an outside call using Walking COS through DISA, the CLIP number for that call will be that of the extension seized by Walking COS.

To retry





CAUTION

There is a risk that fraudulent telephone calls will be made using the Outside-to-Outside Call feature of DISA.

The cost of such calls will be billed to the owner/renter of the PBX.

To protect the PBX from this kind of fraudulent use, we strongly recommend:

- a. Enabling DISA security (Trunk Security or All Security).
- **b.** Keeping your passwords (verification code PIN/extension PIN) secret.
- **c.** Selecting complex, random PINs that cannot be easily guessed.
- d. Changing PINs regularly.
- Time limit

Both parties will hear an alarm tone fifteen seconds before the specified time limit. To extend, press any dial button except \star .


• If Built-in Automated Attendant service is set, you can access the desired extension simply by pressing a single digit (0–9) from the options given the prerecorded message.

1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)


You can set the following features on your telephone from another extension or through DISA.

- Call Forwarding (FWD)/Do Not Disturb (DND)
- · Changing the Log-in/Log-out Status of Extensions
- · Absent Message
- Extension Dial Lock
- Time Service—Changing the Time Mode (Day/Night/Lunch/Break)

From another extension




Through DISA



1.3 Receiving Calls

1.3.1 Answering Calls





Hands-free Operation

You can receive a call and have a conversation in hands-free mode using the SP-PHONE button.



Customising Your Phone

• 3.1.2 Settings on the Programming Mode—Preferred Line Assignment—Incoming Select the seized line when going off-hook.

Alternate Receiving—Ring/Voice

Select the alerting method, either ring or the other party's voice.


3.1.3 Customising the Buttons
 Create or edit an Incoming Call Distribution Group (ICD Group), Primary Directory Number
 (PDN), or Secondary Directory Number (SDN) button.

1.3.2 Answering Hands-free (Hands-free Answerback)

You can answer an incoming call without going off-hook as soon as the line is connected. When an intercom call arrives, you will hear the caller talking without the phone ringing. When an outside call arrives, you will hear the caller talking after a preprogrammed number of rings. Hands-free Answerback for outside calls requires system programming.



To set/cancel





PT users: The AUTO ANS button light shows the current status as follows:

Off: Not set Red on: Set

• PS users: Refer to the documentation for your phone.

1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)


- Answering a Call from Another Telephone (Call Pickup)
- Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)

Answering a Call from Another Telephone (Call Pickup)

You can answer an incoming call that is ringing at another extension or group from your phone without leaving your desk.


The following types of pickup are available:

Group Call Pickup: Picks up a call within your group. **Directed Call Pickup:** Picks up a specified extension's call.



Caller Information Display before Call Pickup using DSS button

Depending on system programming, you can confirm the caller information of a call to another extension using the DSS button before picking up the call. Pressing the corresponding DSS button will call the extension receiving the call rather than picking up the call. While hearing the busy tone, you can check the caller information on the display. You can pick up the call by pressing the same DSS button again.






• If you receive a call waiting tone, you can ask a third party to pick up your second call with Directed Call Pickup.

Answering a Call from Another Telephone (Call Pickup Group Monitor)

Depending on system programming, PT users such as colleagues can view the caller information of a call to another extension which belongs to the same call pickup group. The user can view the caller's information on the LCD while their PT is idle. You can pick up the call by pressing the ANSWER soft button.

To pickup a call






- · Available telephones are as follows:
 - IP-PTs*1
 - DPTs^{*1}
- While the caller information is displayed on the LCD, going off-hook will not answer the call.
- ^{*1} Except models with a single line display.

◆◆ Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)


You can deny or allow other people to pick up your calls.



1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])

You can be notified of incoming outside calls through an external speaker. These calls can be answered from any extension.

Through an external speaker






• You can also receive a paging announcement via a speaker with this operation.

1.3.5 Using the ANSWER/RELEASE Button


The ANSWER and RELEASE buttons are convenient for operators using headsets. With the ANSWER button, you can answer all incoming calls. With the RELEASE button, you can disconnect the line during or after a conversation, or complete transferring a call.



To answer




To transfer a call




To talk to a waiting caller



To transfer an outside call to an extension with a one-touch operation



To end a conversation





Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit an Answer button or a Release button.

1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID])

You can ask your telephone company to trace a malicious calling party during a conversation or after the calling party hangs up.

You will receive the information on the malicious call later on.

To request MCID

During a conversation or when hearing a reorder tone after the calling party hangs up. TRANSFER or Recall/hookswitch. Enter * 7*3. Talk or on-hook.



• Availability of this feature depends on the ISDN service of your telephone company.

1.4 During a Conversation

1.4.1 Transferring a Call (Call Transfer)

- Transferring to an Extension in the PBX
- Transferring to an Outside Party Using the PBX Service
- Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)
- Transferring to an Outside Party Using the SIP Service



 You can transfer a held call without talking, and go on-hook even if the transferred party does not answer the call.

If a transferred call is not answered within a specified time, it will ring at a preprogrammed extension, if set, or at your extension again. If you are off-hook at that time, you will hear an alarm tone. If an outside call is not answered within a specified time, it is automatically disconnected.

For users of SIP phones:


- Even if your telephone has a TRANSFER button, you cannot use it to transfer calls.
 Please make sure to use the HOLD button.
- The transfer operation for SIP extension users may differ from the steps in this section, and may vary depending on the type of telephone being used.


- Blind Transfer


Blind Transfer may be available on your phone. For details about using Blind Transfer, refer to the documentation for your SIP phone. (This feature is not available when transferring to an outside party using the SIP service.)

♦ Transferring to an Extension in the PBX

To transfer










- * For SIP phone users, instead of going on-hook, if you press the HOLD button once or twice (depending on the telephone being used), you can return to the held call. The call with the transferred party will be disconnected.
- For all types of telephone users, if the call is not transferred within a specified time, you will hear an alarm (Transfer Recall).



 For the transfer operation using an SDN button, refer to "1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension".

To transfer with one touch (One-touch Transfer)








• System programming is required to use the One-touch Transfer feature during a conversation with an extension.

♦♦ Transferring to an Outside Party Using the PBX Service

Some extensions may be restricted from performing this feature.










- * For SIP phone users, instead of going on-hook, if you press the HOLD button once or twice (depending on the telephone being used), you can return to the held call. The call with the transferred party will be disconnected.
- Time limit
 Both the caller and the transferred party will hear an alarm tone fifteen seconds before a specified time period, and the call will be disconnected.
- To return to the held call before the destination answers, press the TRANSFER button, the corresponding CO, ICD Group, INTERCOM, or DN button, or the hookswitch.





Customising Your Phone

• 3.1.3 Customising the Buttons Create or edit a Direct Station Selection (DSS) button.

♦ Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)









- To retrieve the held call, press the TRANSFER button, Recall/hookswitch.
- Even if you go on-hook while transferring a call, it is transferred.
- After the call is transferred, the line becomes idle.





Customising Your Phone


• 3.1.3 Customising the Buttons Create or edit an ISDN-Hold button.

♦ Transferring to an Outside Party Using the SIP Service


To transfer a call with announcement (Attended Transfer)








To transfer a call without announcement (Blind Transfer)







- The availability of this feature depends on your SIP service provider.
- You cannot return to the held call after dialling the destination's number.



Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a One-touch Dialling button, store the Blind Transfer feature number.

1.4.2 Holding a Call

- Holding
- Holding in a System Parking Zone (Call Park)




• For users of SIP phones:


The holding operation for SIP extension users may differ from the steps in this section, and may vary depending on the type of telephone being used.


++ Holding

There are two types of hold. The difference between them is that other people can retrieve your held call (Regular Hold) or not (Exclusive Call Hold). As they can be alternated, ask your manager what the current mode is.

To hold (Call Hold)








To retrieve a call (Call Hold Retrieve)


PT/SLT/PS

• At the holding extension (Call Hold Retrieve)



Off-hook. Press flashing CO or INTERCOM, or enter * 50.

● To retrieve an outside call from another extension—only Regular Hold (Call Hold Retrieve—Specified with a held line number)




Off-hook.

Press CO, or enter *53 and then held line number (3 digits).

Talk.

● To retrieve an intercom call or outside call from another extension—only Regular Hold (Call Hold Retrieve—Specified with a holding extension number)




SIP Extn.

• At the holding extension (Call Hold Retrieve)




● To retrieve an outside call from another extension—only Regular Hold (Call Hold Retrieve—Specified with a held line number)



Off-hook. Enter ***53**. Dial **held line number** (3 digits). Talk.

● To retrieve an intercom call or outside call from another extension—only Regular Hold (Call Hold Retrieve—Specified with a holding extension number)





- For PT users: The CO or INTERCOM button light shows the current status as follows:
 - Regular Hold mode

Flashing green slowly: Your held call Flashing red: Another extension's held call

- Exclusive Call Hold mode

Flashing green moderately: Your held call Red on: Another extension's held call

• If a call is not retrieved within a specified time, you will hear an alarm as a reminder (Hold Recall).

If an outside call is not answered within a specified time, it is automatically disconnected.

Hold Mode Change (PT only)

After pressing the HOLD button, if you press the HOLD button again, the status switches from the Regular Hold mode to the Exclusive Call Hold mode or from the Exclusive Call Hold mode to the Regular Hold mode.



- If Automatic Call Hold has been preprogrammed, you can put the current call on hold automatically by pressing another CO, ICD Group, INTERCOM, or DN button to make or answer another call.
- For the Call Hold Retrieve operation using a PDN/SDN button, refer to "1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension".

♦♦ Holding in a System Parking Zone (Call Park)


You can put a call on hold in a common parking zone of the PBX so that any extension can retrieve the parked call. You can use this feature as a transferring feature.


A call can be put into either a specified parking zone (Specified) or any idle parking zone (Auto). If a Call Park button and Call Park (Automatic Park Zone) button have been established, you can select either way to park by simply pressing the corresponding button.

When a call is parked automatically, or more than one call has been parked at the same time, you need to specify the parking zone number to retrieve the required call.


To set








To retrieve (Call Park Retrieve)







- If a call is parked automatically, confirm the parking zone number on the display.
- If a call is not retrieved within a specified time, you will hear an alarm as a reminder (Call Park Recall).

If an outside call is not answered within a specified time, it is automatically disconnected.

The Call Park button light shows the current status as follows:
 Flashing red (for PT): You or another extension has a call parked.



- If you hear a reorder tone when retrieving a parked call, there is no held call. Confirm the stored parking zone number.
- After you park a call, you can perform other operations.



Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a Call Park button or Call Park (Automatic Park Zone) button.


1.4.3 Talking to Two Parties Alternately (Call Splitting)


When talking to one party while the other party is on hold, you can swap the calls back and forth (alternately).




• SIP phone users: You cannot leave the conversation and let the two remaining parties talk.


To alternate between the parties leaving one party on hold temporarily





To leave the conversation and then let the two parties talk





1.4.4 Answering Call Waiting


- Answering Call Waiting in the PBX
- Answering Call Waiting from the Telephone Company

Answering Call Waiting in the PBX


During a conversation, a call waiting tone or voice announcement through the speaker or the handset occurs when an outside call has been received or another extension is letting you know a call is waiting. You must activate this feature to use it. (Default: Disable—No call [Intercom calls]/No tone [Outside calls])


You can answer the second call by disconnecting (1) or holding (2) the current call.

1. To disconnect the current call and then talk to the new party




2. To hold the current call and then talk to the new party






After talking to the new party (second call), you can disconnect (2.1) or hold (2.2) it and then retrieve the first call.


2.1 To disconnect the second call and then talk to the original party






2.2 To hold the second call and then talk to the original party

After holding it, you can talk to the original party. Then, you can disconnect it and then talk to the new party again.







• Depending on the type of your telephone, you may be able to talk to the other party using the speaker and the microphone (Off-hook Call Announcement [OHCA]), or you can receive an announcement through the handset (Whisper OHCA) if you are having a conversation using the handset.


Refer to "1.9.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/ Whisper OHCA)".

• The caller's name or number is displayed for five seconds in fifteen second intervals while waiting to be answered.




Customising Your Phone

• 3.1.2 Settings on the Programming Mode—Call Waiting Tone Type Selection
If you select "Tone 1", you will hear the same tone for Call Waiting from an outside party and an extension. If you select "Tone 2", you will hear different tones for Call Waiting from an outside party and an extension.



Answering Call Waiting from the Telephone Company

This is an optional telephone company service. You can receive a call waiting tone and the caller's information. For details, consult your telephone company.





- To return to the original party, repeat the operation.
- In this case, the FLASH/RECALL button on a proprietary telephone must be set to External Feature Access (EFA) mode through system programming.



Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit an External Feature Access (EFA) button.


1.4.5 Multiple Party Conversation

- Adding Other Parties during a Conversation (Conference)
- Leaving a Conference (Unattended Conference)
- Leaving a Conference (Leaving Three-party Conference)
- Letting a Third Party Join Your Call (Privacy Release)
- Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)


Adding Other Parties during a Conversation (Conference)

You can add one or more parties to your conversation.


To establish a conference call




During a conversation | C.Tone | C.Ton




To establish a conference call when receiving a call from an outside party during a two-party conversation




To add four or more parties to a conference




To add another party on hold to a conference




To talk to two parties alternately in a three-party conversation





To disconnect one party and then talk to the other in a three-party conversation





- * In this case, the FLASH/RECALL button on a proprietary telephone must be set to Flash/ Recall mode through system programming.
- During a three-party conversation, pressing the TRANSFER button or Recall/hookswitch alternates between the other parties in the conversation.
- You can have a conference with a maximum of eight parties (comprising intercom or outside lines) simultaneously.
- During a conversation involving four or more parties, you cannot disconnect one party and maintain the conversation with the other parties.
- SIP phone users cannot originate a conference call, but can be added as a member.



Customising Your Phone

• 3.1.3 Customising the Buttons Create or edit a Conference button.

Leaving a Conference (Unattended Conference)


The person who originated a conference can leave the conference, and allow the other parties to continue the conversation.



To leave a conference



To return while others are talking



To complete a conversation





Time limit

Both parties will hear an alarm tone before a specified timeout. The originating extension user will hear an alarm tone before timeout. The call is disconnected when the timer runs out unless the originating extension returns to the conference.




Customising Your Phone

• 3.1.3 Customising the Buttons Create or edit a Conference button.


Leaving a Conference (Leaving Three-party Conference)


The person who originated a conference with two other parties can leave the conference, and allow the other parties to continue the conversation.

To leave a conference involving at least one other extension



To leave a conference involving two outside parties








 To leave a conference call involving two outside parties and have the conversation continue, your extension must be enabled to transfer calls to outside lines through COS programming.

♦ Letting a Third Party Join Your Call (Privacy Release)

You can let a third party join your current outside call and establish a three-party conversation. You can also leave the conversation and then let the two other parties talk.




To let a third party join your conversation and establish a three-party conversation







- Only an S-CO button can be used for this operation.
- You can leave a three-party conversation and let the two other parties talk by simply going on-hook.


◆◆ Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)







To complete a conversation





Customising Your Phone


• 3.1.3 Customising the Buttons Create or edit an ISDN-Hold button.

1.4.6 Mute

You can disable the microphone or the handset to consult privately with others in the room while listening to the other party on the phone through the speaker or the handset.



To set/cancel





 The AUTO ANS/MUTE or VOICE CALL/MUTE button light for PTs shows the current status as follows:

Off: Normal

Flashing red: Mute


- · If mute is used during OHCA, it will become Handset Mute.
- PS users: Refer to the documentation for your phone.

1.4.7 Letting Other People Listen to the Conversation (Off-hook Monitor)

You can let other people in the room listen to the conversation through the speaker while continuing the conversation using the handset.



To set/cancel





- The SP-PHONE button light shows the current status as follows:
 - **Off**: The voice is heard through the handset.
 - On: The voice is heard through the speaker and the handset.
- · This feature requires system programming.



Hands-free operation

You can have a conversation in hands-free mode using the SP-PHONE button. You can perform other tasks simultaneously.

- Helpful hints for hands-free operation:
 - If it is difficult to hear the other party's voice,
 Increase the volume using the Navigator Key or Volume Key.
 - If the other party has difficulty hearing you,
 Decrease the volume.
 - If the other party reports that your voice echoes,
 Use the telephone in a room that has curtains, carpeting or both.
 - If parts of the conversation cannot be heard,
 If you and the other party speak at the same time, parts of your conversation may be lost.
 To avoid this, try to speak alternately.

1.4.8 Using the Headset (Headset Operation)


You can have a conversation using a headset. In this case, you must select "Headset on" in programming mode or set the Headset button on (red) in advance.




To talk using the headset



To use the handset during a conversation using the headset



To talk in hands-free mode during a conversation using the headset





• The Headset button light shows the current status as follows:

Off: Headset mode off Red on: Headset mode on



For KX-NT300 series (except KX-NT321)/KX-NT560/KX-DT343/KX-DT346 telephone users:

 With KX-NT300 series (except KX-NT321)/KX-NT560/KX-DT343/KX-DT346 telephones, you can use a Bluetooth wireless headset registered on your extension as a headset.

Operating Distance

Please keep the telephones with connected Bluetooth Modules, 3 m or more apart from each other. Also, if a Bluetooth headset is in use near a telephone with a connected Bluetooth Module, other than the one it is registered to, noise may be heard. Move away from the telephone and closer to the one it is registered to, to improve the signal.

Noise

Signals are transmitted between this module and the Bluetooth headset using radio waves. For maximum distance and noise free operation, it is recommended that the module is situated away from electrical appliances such as faxes, radios, PCs, or microwaves.

Systems using the 2.4 GHz ISM (Industrial, Scientific and Medical) band may interfere
with this product. Examples of such systems are cordless telephones, wireless LAN,
Home RF, microwave ovens and other ISM devices. These systems may cause minor
noise.

• For KX-NT560 users:

 You may not be able to use all of the functionality available on a Bluetooth headset. For example, redialling will not work with a REDIAL button on a Bluetooth headset, and, during hands-free mode, you cannot switch the call to the Bluetooth headset through headset operation.

• For KX-NT500 series (except KX-NT551), KX-DT543, and KX-DT546 telephone users:

 You can use Electric Hook Switch (EHS) headsets. For the latest information about headsets that have been tested with this unit, consult your dealer.



Customising Your Phone

- 3.1.2 Settings on the Programming Mode—**Headset Operation** Select the equipment to use.
- 3.1.3 Customising the Buttons Create or edit a Headset button.

1.5 Using a PDN/SDN Button

1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension

Primary Directory Number (PDN) buttons and Secondary Directory Number (SDN) buttons are useful when extension users will handle calls for other extensions. For example, a secretary or multiple secretaries can handle calls and check the call status of a boss or multiple bosses. The functions of PDN and SDN buttons are as follows:



PDN button: This button can be used to make and receive all calls (including both outside and intercom calls). Having multiple PDN buttons allows multiple calls to be queued at the extension. Extensions that have a PDN button are called PDN extensions.

SDN button: The light of an SDN button displays the current call status of the registered extension, similar to a DSS button. In addition, this button can be used to perform the following operations:

- call the PDN extension (SDN Direct Dial)
- · answer calls ringing at the PDN extension
- hold calls and retrieve calls held by the PDN extension (Call Hold and Call Hold Retrieve)
- transfer calls to the PDN extension (Call Transfer Using SDN Button) Extensions that have an SDN button are called SDN extensions.



- The extension that is registered as the destination of an SDN button must have at least one PDN button.
- · One extension can have up to 8 PDN buttons.
- An extension can have only one SDN button for each PDN extension.
- The button light of each PDN/SDN button shows the current status as follows:


Light Pattern	PDN Button Status	SDN Button Status
Off	The PDN extension is idle.	
Green on	The extension is on a call using the PDN button.	The extension is on a call using an SDN button.
Flashing green slowly	A call is on hold at the PDN extension (Regular Hold).	A call answered with the SDN button is on hold (Regular Hold).
Flashing green moderately	A call is on hold temporarily or on Exclusive Call Hold.	A call answered with the SDN button is on hold temporarily or on Exclusive Call Hold.
Flashing green rapidly	The PDN extension is receiving an incoming call.	An SDN extension is receiving a Hold Recall or callback ringing from a call answered with the SDN button.
Red on	A corresponding SDN extension is using the line.	The corresponding PDN extension or another corresponding SDN extension is using the line.

Light Pattern	PDN Button Status	SDN Button Status
Flashing red slowly	A corresponding SDN extension is holding a call.	Another corresponding SDN extension, or the PDN extension itself, is holding a call.
Flashing red rapidly	The PDN extension is receiving an incoming call to an incoming call distribution (ICD) group.	The corresponding PDN extension is receiving an incoming call.


SDN Direct Dial

Using an SDN button, you can easily call the corresponding PDN extension. SDN buttons are in one of two modes depending on system programming, and the operation procedure differs as follows:

Enhanced DSS Key Mode



Standard SDN Key Mode





- When performing SDN Direct Dial to call the corresponding PDN extension, the SDN button light shows the current status of the destination extension as follows:
 Green on: You are using the line.
 - **Red on**: The line is being used. (The PDN extension, or another SDN extension when multiple extensions have SDN buttons to a same PDN extension, is using the line.)
- Even if a PDN extension has set Do Not Disturb (DND), you can call the extension as normal by pressing the SDN button.




When an SDN button is in Standard SDN Key Mode, you can dial a telephone number while
hearing a dial tone, instead of pressing the SDN button again. Depending on system
programming, your call will be made using either your normal calling privileges (Class of
Service) or those of the corresponding PDN extension (SDN Walking COS).

◆ Call Hold and Call Hold Retrieve

You can put calls answered with a PDN or SDN button on hold normally (\rightarrow **1.4.2 Holding a Call**).

You can also retrieve a call held at your extension/another extension with a simple operation, regardless of the call type.

Call Hold Retrieve





• If a call is not retrieved within a specified time, you will hear an alarm as a reminder (Hold Recall).

If an outside call is not answered within a specified time, it is automatically disconnected.




• If **Automatic Call Hold** has been preprogrammed, you can put the current call on hold automatically by pressing another PDN button to make or answer another call.

♦♦ Call Transfer Using SDN Button

You can transfer a call to a PDN extension with a simple operation using a corresponding SDN button.

To transfer a call to a PDN extension





- System programming is required to use this feature during a conversation with an extension.
- * When an SDN button is in Standard SDN Key Mode, you have to press the SDN button twice to transfer the call, unless you used that SDN button to answer an incoming call.



Customising Your Phone

- 3.1.2 Settings on the Programming Mode—Preferred Line Assignment—Incoming Select the seized line when going off-hook.
- 3.1.2 Settings on the Programming Mode—Preferred Line Assignment—Outgoing Select the seized line when going off-hook.
- 3.1.3 Customising the Buttons
 Create or edit a Primary Directory Number (PDN) or Secondary Directory Number (SDN) button.

1.6 Before Leaving Your Desk

1.6.1 Forwarding Calls

- Forwarding Your Calls (Call Forwarding [FWD])
- → FWD/DND Settings Using Fixed FWD/DND Button
- Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)

\| Forwarding Your Calls (Call Forwarding [FWD])

You can have your incoming calls forwarded to a specified destination.

All Calls:

All calls are forwarded. Preset extensions may also forward from their own receiving group.

Busy:

All calls are forwarded when your extension is busy.

No Answer:


All calls are forwarded when you do not answer the call within a specified time period.

Busy/No Answer (BSY/NA):

All calls are forwarded when you do not answer within a specified time period or when your extension is busy.

Follow Me (From):

If you fail to set the above-mentioned "All Calls" to forward before you leave your desk, you can set the same feature from the destination extension.





Incoming calls can be forwarded up to four times.




- You can set the UM group's floating extension number as a forward destination.
- You can set your cellular phone as the forward destination.


Boss & Secretary feature

The extension which has been set as the destination can call the forwarding extension.


<Example>



To set/cancel



To set Follow Me from another extension






 When using a proprietary telephone, you can set or cancel Call Forwarding by pressing the FWD/DND button (fixed button) instead of "**710".




Nonstop servis TELEFONNÍ ÚSTŘEDNY

volejte dispečink tel. 606 193 950
PanaTEL® je specialistou na telefonní ústředny, komunikační systémy Panasonic
www.PanaTEL.cz

To set the timer for "No Answer" and "Busy/No Answer"



To set/cancel (Call Forwarding [FWD] for your Incoming Call Distribution Group)





• The FWD/DND button light shows the current status as follows:

Off: Both features are not set.

Red on: FWD mode

Flashing red slowly: DND mode

The Group FWD button light shows the current status as follows:

Off: No set

Red on: FWD mode

 The system has two modes: (1) FWD/DND Cycle Switch Mode and (2) FWD/DND Setting Mode. Ask your manager what mode your system is in if you are not sure.

(1) When in FWD/DND Cycle Switch Mode:

Pressing the FWD/DND button (fixed button) while in idle status will cycle the setting as shown below:



(2) When in FWD/DND Setting Mode:

Pressing the FWD/DND button (fixed button) while in idle status allows you to switch the FWD/DND status and set the FWD destination (refer to " FWD/DND Settings Using Fixed FWD/DND Button").

Note

A FWD/DND button (customised button) is always in FWD/DND Cycle Switch Mode: the mode cannot be changed.

- Transferred outside calls are also forwarded to the destination assigned for outside calls.
- When intercom calls are set to be handled differently from outside calls (forwarding type, forward destination), we recommend establishing buttons for both FWD/DND—Outside calls and FWD/DND—Intercom calls, and/or Group FWD—Outside calls and Group FWD—Intercom calls, because:
 - a. the light patterns of the FWD/DND—Both calls button (including FWD/DND button [fixed button]) and the Group FWD—Both calls button will indicate the setting for either outside calls or intercom calls, but not both.

Note

The FWD icon on PS display reflects the setting for outside calls only.

b. pressing the FWD/DND—Both calls button (including FWD/DND button [fixed button]) or the Group FWD—Both calls button will not change the FWD or DND mode for intercom calls and outside calls separately.



Customising Your Phone


3.1.3 Customising the Buttons
 Create or edit FWD/DND (Both calls, Outside calls, Intercom calls) buttons, or Group FWD
 (Both calls, Outside calls, Intercom calls) buttons.

Remote FWD Settings Using Group FWD Button

Using a proprietary telephone (PT), you can easily switch the FWD status of another phone. First, the extension that will allow remote forwarding operation must specify an extension to perform remote forwarding. Then, the extension to perform remote forwarding can assign a Group FWD button for this purpose. The forwarding status of the target extension can be checked via the LED of the button. This feature allows users to forward calls to themselves from another extension.



To set/cancel (Remote FWD setting)





Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit Group FWD (Both calls, Outside calls, Intercom calls) buttons.


♦ FWD/DND Settings Using Fixed FWD/DND Button

Using a proprietary telephone (PT), you can easily switch the FWD/DND status, and set the forward destination for outside/intercom calls with the FWD/DND button (fixed button). For PT users, it is also possible to set outside telephone numbers (e.g., your cellular phone) as forward destinations for up to 4 public devices.




- · Switching the FWD/DND status and setting FWD destination for outside/intercom calls
- Timer for "No Answer" and "Busy/No Answer"

To switch FWD/DND status for outside calls




To switch FWD/DND status for intercom calls





 When you switch the FWD/DND status, any FWD destination that was set previously is not cleared.


To set and clear FWD/DND for outside/intercom calls





* This step can be omitted.

To set the timer for "No Answer" and "Busy/No Answer"






• * You can enter the time as a 1–3 digit number. For example, 15 seconds can be entered as "15" or "015".

♦ Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)


All calls are forwarded to an outside party using ISDN. The following types of call forwarding are provided by the ISDN service.

- Unconditional (Call Forwarding Unconditional [CFU])
- When your extension is busy (Call Forwarding Busy [CFB])
- When you do not answer (Call Forwarding No Reply [CFNR])


To set



To cancel



To confirm the condition




1.6.2 Showing a Message on the Caller's Telephone Display (Absent Message)


You can show the reason you do not answer, if the caller uses a Panasonic display proprietary telephone. There are eight preprogrammed messages and one for your personal message (16 characters). The selected message is shown on the display of your telephone.

Message no.	Message (Example)
1	Will Return Soon
2	Gone Home
3	At Ext %%%% (Extension number)
4	Back at %%:%% (Hour:Minute)
5	Out until %%/%% (Month/Day)
6	In a Meeting
7	
8	
9	A message assigned for each extension. (Personal Absent Message)

To set



To cancel






- Enter the desired value in the "%" positions. You must enter the correct number of characters as represented by the "%" using 0 to 9 or *x.
- The preprogrammed messages can be changed through system programming.
- To create your personal message (Message no. 9), refer to "3.1.2 Settings on the Programming Mode".


1.6.3 Preventing Other People from Using Your Telephone (Extension Dial Lock)

You can lock your extension so that other users cannot make unauthorised outside calls. This feature is also known as Electronic Station Lockout.

To lock




To unlock





- If you forget the extension PIN or cannot unlock your extension, consult your manager. He can clear your extension PIN. Then, you can set the new PIN and unlock your extension by entering it.
- If your extension is locked by this feature, it cannot perform features as follows:
 - Making outside calls
 - Changing the call forwarding destination
- If you do not set extension PIN, you cannot lock and unlock your extension.

To make an outside call while your extension is locked





· After you make an outside call, Extension Dial Lock is automatically activated again.

1.7 Making/Answering an Announcement


1.7.1 Paging

- Group Paging
- Paging and then Transferring a Call

\$\rightarrow\$ Group Paging

You can make a voice announcement to proprietary telephones or external speakers or both in the preset group simultaneously.


To page






• If the group which you paged is already being used for paging, you hear a busy tone.

♦ Paging and then Transferring a Call









• After you go on-hook, the caller can talk to the person who answers the page.

1.7.2 Answering/Denying a Paging Announcement

To answer



To allow/deny a paging announcement (Paging Deny)





- The following are extensions that cannot receive a paging announcement:
 - Portable station
 - Single line telephone
 - Proprietary telephone that is ringing or busy
 - Proprietary telephone in Paging Deny mode
 - Proprietary telephone in DND mode
 - SIP phone
- System programming may be required for some IP-PT users to receive paging announcements.
- Even if the announcement is not paging your extension, you can answer it, if it is paging your group.

1.7.3 Making a Conference Group Call

You can call multiple parties, assigned as members of a group (conference group), and establish a multiple party conversation with the called parties. You can make a conference group call to both extensions and outside lines (including analogue lines). The following two modes are available:

- Conference Mode: the called parties can join the conversation automatically. (Conference Mode)
- **Broadcast Mode:** the called parties can hear the caller's voice announcement, and then be allowed to join the conversation by the caller. (Broadcast Mode)



- If you dial a conference group number that is in use for another conversation, you will hear a busy tone and cannot establish a multiple party conversation.
- If you fail to seize idle outside lines necessary for all members assigned in the conference group, you will hear a reorder tone and cannot make a conference group call.
- When making a conference group call to an outside party, the CLIP number for that call will be the one you select for making calls to an outside line. Refer to "1.9.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP])".

Conference Mode

If this mode is selected through system programming, the called parties can join the conversation simply by going off-hook. The caller can end the conversation with a specific party manually.

PT/SLT/PS/SIP Extn. Caller conference entry code group no. Off-hook. Enter * 32. Dial conference Enter entry code group number (2 digits). (max. 8 digits). Wait for an # answer. C.Tone Enter #. A multiple party **Any Telephone** conversation is now established. Called Party The telephone rinas. Off-hook. Talk.

To make/answer a conference group call



- * If you do not enter an entry code when making the conference group call, extensions/ outside telephones can join the conversation without needing to enter an entry code.
- Entry codes can consist of the digits "0" through "9". When "*" is used as an entry code, no one can join a conversation that is already in progress. "*" must be used by itself (i.e., you may not combine it with numeric digits). For details, refer to " Join After Time Out".
- A conversation can be established with a maximum of 8 parties (including the caller).
- If the Hands-free Answerback feature is enabled, the called extension can answer the conference group call without going off-hook.
- With PTs and KX-WT125 (Canada only)/KX-TCA175/KX-TCA275/KX-TCA185/KX-TCA285/KX-TCA385 PSs, a conference group call can be automatically answered without going off-hook. This mode is selected through system programming.
- If using an SLT or SIP phone, the caller can only originate a conference group call and cannot control the called parties' call status manually.

◆For a caller

To end a conversation with a specific party

PT/PS

During a conversation

• To end a conversation with a specific party



Press DSS.

 To end a conversation with the party who joined the conversation last



Press TRANSFER.

To disconnect the party who joined the conversation last from the conference group call



Press FLASH/RECALL.




 In this case, the FLASH/RECALL button must be set to Flash/Recall mode through system programming.

Broadcast Mode

If this mode is selected through system programming, the caller can call multiple parties in a conference group, make a voice announcement, and then establish a multiple party conversation with the called parties. This conversation will be heard by all called parties. Called parties can listen to the announcement simply by going off-hook. They can send a notification tone if they want to join the conversation.

To make/answer a conference group call





- * If you do not enter an entry code when making the conference group call, extensions/ outside telephones can join the conversation without needing to enter an entry code.
- Entry codes can consist of the digits "0" through "9". When "*" is used as an entry code, no one can join a conversation that is already in progress. "*" must be used by itself (i.e., you may not combine it with numeric digits). For details, refer to " Join After Time Out".
- With PTs and KX-WT125 (Canada only)/KX-TCA175/KX-TCA275/KX-TCA185/KX-TCA285/KX-TCA385 PSs, a conference group call can be automatically answered without going off-hook. This mode is selected through system programming.
- If the Hands-free Answerback feature is enabled, the called extension can answer the conference group call without going off-hook.
- If using an SLT, or SIP phone, the caller can only originate a conference group call and cannot control the called parties' call status manually.

◆For a caller


To make a conversation with a specific party



To make a conversation with a party in the group's preassigned order



To end a conversation with a specific party






- In this case, the FLASH/RECALL button must be set to Flash/Recall mode through system programming.
- If the maximum number of parties who can actively participate in the conversation is set to 32 through system programming, the keys on the conference originator's telephone (DSS, CONFERENCE, TRANSFER, FLASH, etc.) will not function.

◆For a called extension

To send a notification tone to the caller and join a conversation





• A maximum of 32 parties (including the caller) can join the conference. Also, depending on system settings, a maximum of 32 parties (including the caller) can join the conversation.



Push-to-Talk for PT/PS/SLT users

If the Broadcast Mode and this mode are selected through system programming, the called PT/PS/SLT users can join the conversation by pressing any dial key $(0-9, \times, \#)$ during the voice announcement.

By assigning PSs with the Hands-free Answerback feature enabled to a conference group, the caller can create a wireless paging system. All of the called PS users, with the Hands-free Answerback feature enabled, will hear the voice announcement. Then, any PS user can respond by pressing any dial key, and their reply will be heard by all of the called parties.


Solution Join After Time Out

Extensions or outside telephones can join the multiple party conversation that has been already started using this feature. For example, if the conference group members fail to answer when a conference group call is made, they can join the multiple party conversation later using this feature. They can join the conversation from outside telephones (through DISA or TIE Line) or extensions. This feature is available for both modes: Conference Mode and Broadcast Mode.

For security reasons, you can set a specific entry code for the conference group call. To join the conversation, extensions/outside telephones have to enter the same entry code. Therefore, you have to inform the parties to be added to the conversation of the entry code in advance.


♦ For an extension originating the conversation

To make a conference group call with an entry code



♦ For an extension joining the conversation

To join a conversation with an entry code





- * If you do not enter an entry code when making the conference group call, extensions/ outside telephones can join the conversation without needing to enter an entry code.
- Entry codes can consist of the digits "0" through "9". When "*" is used as an entry code, no one can join a conversation that is already in progress. "*" must be used by itself (i.e., you may not combine it with numeric digits).
- When you are using an outside telephone (through DISA or TIE Line), it is possible to join the conversation after accessing your extension using Walking COS.
- Extensions/outside telephones can join the conversation using this feature only when the
 conference group call has already been established between the extension originating a
 conversation and at least one member.
- To join a conversation that is already in progress, extensions/outside telephones must be using an idle extension with no held calls.
- If a conversation has reached the maximum number of participants, this feature cannot be used to join the conversation.



Starting a Conference Group Call using Hands-free Answerback

If the Hands-free Answerback feature is enabled with at least one conference group member, the call can be automatically answered and the conversation begins with only one participant (the caller). Then, up to 6 participants can use the Join After Time Out feature to join the conversation.

1.8 Using the Unified Messaging Features

1.8.1 What is the Unified Messaging system?

Introduction to the Unified Messaging system

Your PBX can provide you with Unified Messaging system service. You or an outside party can access the Unified Messaging system from a telephone. As the owner of a mailbox, you can:

- Send a message to one or more people inside or outside your office.
- · Receive and print fax messages.
- · Transfer messages to other subscribers and add your own comments.
- · Access your mailbox and listen to your messages, even when out of the office.
- · Have the Unified Messaging system call or e-mail you when someone leaves you a message.
- Be notified by the message waiting lamp on your extension when new messages have been recorded in your mailbox.
- · Screen your calls.
- Create a set of options and functions exclusive to your mailbox (Personal Custom Service) that can be selected by your callers.
- Voice, fax, and e-mail messages can be managed via an e-mail client that supports IMAP4.
- · Many other useful messaging features.



 PBX users who are assigned a mailbox in the Unified Messaging system are called subscribers.

Hospitality Mode:

If your service mode is set to "Hospitality Mode", available features such as listening to messages, personal greetings, etc. may be limited according to the COS settings for your mailbox.

Before You Begin

In order to use the Unified Messaging system as a subscriber, you need to know the following information. The System Manager can help you if you do not know this information.

- The extension number that you should dial in order to access the Unified Messaging system.
- Your mailbox number and extension number (In many cases these are the same number, but it is possible they are not).
- · Your mailbox password (if set).
- The System Manager's telephone number. The System Manager is the person you should refer to when you have any problems with the Unified Messaging system.

Prompts

Prompts are recorded voice guidance messages that help you set and use Unified Messaging system features. Prompts also help callers when the system is handing their calls. Depending on how your Unified Messaging system is programmed, subscribers and callers can select the language they prefer for system prompts.

<Prompt example>

"To leave a message, press 1."

"Please leave a message at the tone."

"To end recording, hang up or press 1 for more features."



- Not all prompts are described in each operation.
- The prompts in each operation are not exactly the same as the actual prompts you will hear from the Unified Messaging system.

1.8.2 Logging in to and Configuring Your Mailbox

- Logging in to Your Mailbox
- Subscriber Tutorial (Easy Mailbox Configuration)
- A Changing or Deleting Your Personal Greeting Messages
- Personal Greetings for Caller ID
- Changing Your Password
- Changing or Deleting Your Subscriber (Owner) Name
- Common Service Commands and Navigation Commands

Logging in to Your Mailbox for the First Time

The first time you log in to your mailbox, there are certain mailbox settings you should perform before using any other Subscriber Services. These settings identify you as the owner of your mailbox, and are described in " Logging in to Your Mailbox".

- Password
- Subscriber's Name
- Personal Greeting Messages

Your Unified Messaging system may be programmed to initiate a "Subscriber Tutorial" the first time you log in to your mailbox. If the Subscriber Tutorial is enabled, Unified Messaging system prompts will guide you through the mailbox configuration process.

♦ Logging in to Your Mailbox

In order to access Subscriber Services (to play messages, change mailbox settings, etc.), you must first log in to your mailbox. There are 2 ways to log in to your mailbox:

Manual Log-in:

Manual Log-in is necessary when logging in to your mailbox using someone else's extension, or when Automatic Log-in is not enabled for your mailbox.

Automatic Log-in:

When logging in to your mailbox from your own extension, you do not need to enter any special commands or your mailbox number.



• The UM group's default floating extension number depends on system programming. For more information, consult your System Administrator or System Manager.




Mailbox Capacity Warning


When your mailbox is almost full, you will receive a Mailbox Capacity Warning shortly after logging in to your mailbox. When you hear a Mailbox Capacity Warning, you should delete unnecessary messages to make more recording time in your mailbox available. The amount of recording time that remains when you hear the Mailbox Capacity Warning depends on how your mailbox is configured. This feature may be disabled by the System Administrator or System Manager for your mailbox.

For more information, consult your System Administrator or System Manager.

Manual log-in



Automatic log-in





CAUTION

- It is strongly recommended that a password of 16 numbers be used for maximum protection against unauthorised access.
- To avoid unauthorised access to the PBX, keep the password secret. If it becomes known to others, the PBX may be misused.
- · Change the password periodically.

Notice

• When disabling the password requirement, ensure that an unauthorised third-party is not allowed access to your extension.



- When following audible prompts only: if Autoplay New Messages is enabled for your mailbox, new messages will be played back automatically each time you log in to your mailbox. Whether or not new messages will be played back one after the other automatically depends on system programming. For more information, consult your System Administrator.
- If Message Waiting Lamp is enabled for your mailbox, the message lamp on your telephone
 will light when you receive a new message. You can log in to your mailbox and play back a
 new message automatically simply by going off-hook and pressing the Message button on
 your telephone. The Unified Messaging system will play back the first new message only. To
 play back other messages, press the appropriate button.
- After logging in, the system will announce the number of total messages, the number of new messages, or the length of new messages. These announcements depend on the mailbox settings and Class of Service (COS) settings of your mailbox.



Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a Voice Mail Transfer button or a Message button.

♦♦ Subscriber Tutorial (Easy Mailbox Configuration)

Your Unified Messaging system may be programmed to present a "Subscriber Tutorial" to you the first time you log in to your mailbox. If the Subscriber Tutorial is enabled, Unified Messaging system prompts will guide you through the mailbox configuration process. Simply by following the prompts, you can configure the following items. You can configure these items later manually if necessary, as explained later in this section. This feature may be disabled by the System Administrator or System Manager for your mailbox.



- You may be asked to enter your password after logging in to your mailbox. If you do not know this password, ask your System Administrator.
- The subscriber tutorial may be simplified or not available depending on your COS settings.

Password:

If your mailbox has a password, you must enter it using the dial keys (0–9) whenever you log in to your mailbox. Your password can contain up to 16 digits.

Subscriber's Name:

This is a recording of your name. Other subscribers will hear your name when they listen to messages you left for them. It may also be heard by callers when they use the Dialling by Name feature.

Personal Greetings:


The following Personal Greeting Messages can be recorded in the subscriber tutorial. After the greeting is played, a tone will sound, and the caller can leave a message.

- **No Answer Greeting:** Heard by callers when you do not answer their calls. A common example might be, "This is (name). I can't take your call right now...".
- Busy Signal Greeting: Heard by callers when you are on another call. A common example might be, "This is (name). I'm on another call right now...".
- After Hours Greeting: Heard by callers when the Unified Messaging system is in night mode. A common example might be, "This is (name). I've gone home for the day...".



• If you do not record a greeting message, a prerecorded greeting message will be used.

To start the Subscriber Tutorial





CAUTION

- It is strongly recommended that a password of 16 numbers be used for maximum protection against unauthorised access.
- To avoid unauthorised access to the PBX, keep the password secret. If it becomes known to others, the PBX may be misused.
- · Change the password periodically.

Changing or Deleting Your Personal Greeting Messages

After callers reach your mailbox, they will hear your personal greeting message. You can record 6 kinds of Personal Greetings; the appropriate greeting will be played for callers. If you delete or do not record a greeting message, a prerecorded greeting message will be used.

No Answer Greeting:

Heard by callers when you do not answer their calls. A common example might be, "This is (name). I can't take your call right now...".

Busy Signal Greeting:

Heard by callers when you are on another call. A common example might be, "This is (name). I'm on another call right now...".

After Hours Greeting:

Heard by callers when the Unified Messaging system is in night mode. A common example might be, "This is (name). I've gone home for the day...".

Personal Greeting for Caller ID:

Heard by callers from preprogrammed telephone numbers. For details, refer to " Personal Greetings for Caller ID".


· Temporary Greeting:

A special greeting that, if recorded, is heard by callers instead of the other greetings. A common example might be, "This is (name). I'm out of the office this week...".

Absent Message:

Heard by callers when a personal greeting is set to a PBX's absent message, and that absent message is currently set.

To record or delete your Personal Greeting Messages





 The contents of the Absent Message Greeting prompt and the absent message displayed on telephones (refer to "1.6.2 Showing a Message on the Caller's Telephone Display (Absent Message)") should be programmed to match through system programming.



- * We recommend stating your name in your greeting messages, so that callers will know they have reached the correct mailbox.
- A Temporary Personal Greeting is played instead of all your other greetings until it is deleted. Each time you log in to your mailbox, the Unified Messaging system will ask you if you want to turn off (delete) your Temporary Personal Greeting.

Direct Service Access

If Direct Service Access is set in Mailbox Settings, you can access Record No Answer Greeting, Record Busy Greeting, Record After Hours Greeting and Record Temporary Greeting features directly by dialling a specific Unified Messaging extension number from your extension. Automatic login must be enabled to use Direct Service Access (refer to "Automatic log-in"). For details about these Unified Messaging extension numbers, consult your System Administrator.


Personal Greetings for Caller ID

You can record personalised greetings for specific callers. If you have assigned their telephone numbers (Caller ID numbers) to a personalised greeting, they will hear the appropriate greeting when they call you, instead of your other greeting messages normally played for callers.


You can record 4 personalised greetings and assign 8 callers to each greeting. Record your personalised greetings before assigning Caller ID numbers.

This feature may be disabled by the System Administrator or System Manager for your mailbox.


To record a personalised greeting for the first time



To change a personalised greeting




To assign Caller ID numbers for the first time





• * While entering a Caller ID number, you can press \times to enter a "wild card". This allows several telephone numbers to match the Caller ID number that you assigned. For example, if you store the Caller ID number as "012 \times ... \times " (enter the number of \times s as required for telephone numbers in your area), any telephone number that begins with "012" (for example, all callers from the "012" area code) will hear your personalised greeting.


To add/delete/review Caller ID numbers later



♦ Changing Your Password

You can protect your mailbox by setting a password to prevent unauthorised access to your mailbox. If your mailbox has a password, you must enter it using the dial keys (0–9) whenever you log in to your mailbox. Your password can contain up to 16 digits. You can change your password at any time. When choosing a password, avoid using obvious number combinations. If you forget your password, have your System Administrator or System Manager clear your password. You may then set a new one.

To change your password






CAUTION

- It is strongly recommended that a password of 16 numbers be used for maximum protection against unauthorised access.
- To avoid unauthorised access to the PBX, keep the password secret. If it becomes known to others, the PBX may be misused.
- · Change the password periodically.

Changing or Deleting Your Subscriber (Owner) Name

You can record your name in the Unified Messaging system. The system can then announce your name for callers to let them know that they have reached the correct mailbox.

To change/delete your subscriber name



Common Service Commands and Navigation Commands

Commands for Changing the Current Unified Messaging System Service

After going off-hook and pressing the MESSAGE button, Voice Mail Transfer button, or enter the UM group's floating extension number, you can enter a service command to access certain Unified Messaging system features quickly. While guidance is being provided, you can also use service commands to, for example, switch to a different Unified Messaging system service mode.

# 1 Dialling by Name	
----------------------	--

# 2	Custom Service You will be guided to enter a Custom Service number (1–200).	
# 5	Log in [™]	
# 6	Voice Mail Service You can record a message for another subscriber by entering his or her mailbox number when guided. You can also log in to your mailbox by entering this command followed by ** and your mailbox number.	
# 7	Restart (Return to Main Menu) ⁻²	
# 8	Automated Attendant Service	
# 9	Exit	
*	Return to Previous Menu	
0	Help	
# #	Switch Service mode If you are authorised to access a System Manager and/or Message Manager mailbox by the System Administrator, you can switch between those services as follows: Subscriber service Message Manager service System Manager service	

- 1 If pressed while in Subscriber Service, you will be prompted to enter the desired mailbox number.
- ² If pressed while in Subscriber Service, you will return to the Subscriber Service Main Menu.



- Commands #5 and #7 are available only after you have accessed Subscriber Service.
- Some commands may not be available depending on the COS settings of your mailbox.

When Using Voice Prompts

The following commands can be used to help you navigate through Unified Messaging system menus.

*	Takes you back to the previous menu.
0	Repeats the current menu.
# 7	Takes you back to the Main Menu.

1.8.3 Message Playback and Related Features

- Playing Messages
- Printing Fax Messages
- Bookmarks (Voice Messages only)
- Recovering Deleted Messages
- Replying to Messages
- Transferring Messages

Remote Access

Playing Messages

Callers and other subscribers can leave voice messages for you, and you can play them back later after you have logged in to your mailbox. Also, when you receive a fax message, you can play back any attached voice messages or message envelopes, and print the fax.

Messages in your mailbox are divided into 3 types:

New Messages:

Messages in your mailbox which you have not played back yet.

· Old Messages:


Messages in your mailbox which you have played back but have not yet deleted.

· Deleted Messages:

Messages in your mailbox which you have deleted. You can "recover" your deleted messages, after which they will be treated as old messages (refer to " Recovering Deleted Messages"). If you do not recover deleted messages, they will be permanently deleted at the end of the day.

When playing back a message, the Unified Messaging system can also announce the message's "envelope"—the date and time of the message, and the message sender's information.

To play messages





- * This step is omitted depending on settings and COS settings of your mailbox.
- Fax features may not be available depending on the COS settings of your mailbox.

Additional features are available during/after the playback of voice messages and fax message envelopes. Refer to the table below and press the appropriate dialling key. The message types that can be used with each key a marked with a \checkmark . Note that certain features are not available depending on the message type (new, old, deleted).

Key	Feature	Message Type		
		New	Old	Deleted
1	Repeat this message	✓	✓	✓
1 1	Replay the previous message	✓	✓	✓
2	Play the next message	✓	✓	✓

Was a		Message Type		
Key	Feature	New	Old	Deleted
(+ 1 '1)	Delete this message If a confirmation message is played, press 1 to delete the message.	√	✓	
3	Recover this message			✓
4	Reply to this message	✓	√	
5	Transfer this message	✓	√	
6 *1	Play the message envelope	✓	✓	✓
7	<during only="" playback=""> Rewind the voice message</during>	✓	✓	✓
	<after a="" envelope="" fax="" listening="" message="" only="" to=""> Print the fax message</after>	✓	✓	
8	<during only="" playback=""> Pause/restart message playback</during>	✓	√	✓
8 4	<during only="" playback=""> Increase playback volume</during>	✓	✓	✓
8 5	<during message="" only="" playback="" voice=""> Set a Bookmark for the voice message</during>	✓	√	
	To restart message playback, press 8.			
8 6	<for messages="" only="" voice=""> Start playback at the Bookmark for the voice message</for>	✓	√	
9	<during only="" playback=""> Fast-forward</during>	✓	✓	✓
#	Save this message as new • After saving the message, the next message will be played.	✓		

These keys only available when the appropriate COS settings are assigned to your mailbox. For more information, consult your System Administrator.




- For voice messages, Unified Messaging system programming determines if the message envelope is played before each message, after each message, or only when you press 6.
 For more information, consult your System Administrator.
- The Unified Messaging system will automatically delete both new and old messages after a specified number of days have passed. Your System Administrator or System Manager controls how many days messages are retained for. Each time you play a new or old message, the message retention counter resets.
- During playback, you can increase the playback volume by pressing **84**. If volume is at the highest setting, pressing **84** will select the lowest setting, as shown below.

```
Level 1 \rightarrow Level 2 \rightarrow Level 3 \rightarrow Level 4 \rightarrow Level 5 – (default)
```


Printing Fax Messages

You can print faxes received in your mailbox when you play back a fax message envelope. Also, you can set Automatic Delivery to immediately print any faxes received in your mailbox to a specified fax machine.

To print a fax message



To set Automatic Delivery





• * If you are using an ISDN or SIP line in en bloc dialling mode, to insert a pause or special command in the middle of the telephone number, pause momentarily while entering the telephone number. You will hear a list of available options, for example, "To add more digits, press 4. To insert a pause, press 5.".


♦ Bookmarks (Voice Messages only)

While listening to a message in your mailbox, you can set a bookmark. A bookmark lets you easily resume playback from a specific point in a specific message later. You can set one bookmark for each message in your mailbox; if you set a new bookmark, the old one is deleted.



You cannot set or use bookmarks for deleted messages.

To set the Bookmark



To start playback at the Bookmark

PT/SLT/PS/SIP Extn. During or after message playback 8 6 Enter 86.

Necovering Deleted Messages

You can delete voice/fax messages in your mailbox. Once a message has been deleted, it is retained until the end of the day, then it will be permanently deleted. Deleted messages can be "recovered", after which they will be treated as old messages.

To recover a Deleted Message

PT/SLT/PS/SIP Extn. During or after voice message/fax message envelope playback 3 Enter 3.

Replying to Messages

You can reply to messages left in your mailbox by either calling back the caller or by leaving a message in the caller's mailbox.

Calling back is possible when the person who left you the message is another subscriber. Calling back outside callers is possible if their Caller ID information is received by the system, however, this feature may be disabled by the System Administrator or System Manager for your mailbox.

Replying by leaving a message in the caller's mailbox is possible only if the caller is another subscriber (i.e., the person must have his or her own mailbox). When replying by leaving a message in the caller's mailbox, you can set any of the following:

Urgent Status:

The message will be heard before other messages by the recipient.

Private Status:

The recipient will not be able to forward the message, ensuring privacy.

Auto Receipt:

You will receive notification (receipt message) once the recipient has played back the message.

Finally, you can send your reply immediately or set a message delivery time. However, please note that you cannot reply to receipt messages.




 Only new and old messages can be replied to. To reply to a deleted message, recover the message first (refer to "
 Recovering Deleted Messages").

To call back the message sender

PT/SLT/PS/SIP Extn. During or after voice message/fax message envelope playback 4 1 Enter 4. Enter 1 to call the sender.

To leave a message for the sender





- *1 Example: To enter 5:00, press 5#. To enter 5:15, press 515#.
- *2 This option may not be available if the Unified Messaging system is programmed to use 24-hour time.
- *3 Example: If today is February 16 and you enter **17#**, the message will be delivered tomorrow. If today is February 16 and you enter **5#**, the message will be delivered on March 5.
- Auto Receipt is not enabled by default. For more information, consult your System Administrator.
- New urgent messages are played before any other messages. However, old urgent messages are treated like regular messages: messages are played starting with the oldest.

Transferring Messages


You can transfer (forward) messages in your mailbox to other subscribers. However, please note that you cannot transfer receipt messages, or messages that were specified by the sender as "private". When transferring a message, you can:

- · Specify the recipient by entering another subscriber's mailbox number.
- Specify several recipients by entering a Personal Group Distribution List number (refer to " Personal Group Distribution Lists") or a Mailbox Group number.
- Record your own comments and send them along with the transferred message.




- No acknowledgement will be given to indicate the message has been transferred.
- Only new and old messages can be transferred. To transfer a deleted message, recover the message first (refer to " Recovering Deleted Messages").

To specify the recipients by number



To specify the recipients by name (dialling by name)



Remote Access

You can call the Unified Messaging system while outside and log in to your mailbox in order to listen to your messages. There are 2 ways to log in to your mailbox remotely:

Automatic Log-in:

When logging in to your mailbox remotely from a preprogrammed outside telephone number (assigned as a Caller ID number), you do not need to enter any special commands or your mailbox number. The Unified Messaging system can recognise the telephone number you are calling from and therefore determine you are the caller (refer to " Assigning Your Telephone Numbers for Remote Automatic Log-in and Toll Saver"). This feature may be disabled by the System Administrator for your mailbox.


· Manual Log-in:

Manual Log-in is necessary if logging in to your mailbox, when your mailbox is not programmed for Automatic Log-in, or when you are calling from a telephone number not programmed for Automatic Log-in.



 Ask your System Administrator what telephone number you should dial in order to access the Unified Messaging system remotely.


Remote automatic log-in





 The number of rings you hear before the Unified Messaging system answers your call can indicate whether or not you have new messages (Toll Saver feature). For more information, consult your System Administrator.

Remote manual log-in





CAUTION

- It is strongly recommended that a password of 16 numbers be used for maximum protection against unauthorised access.
- To avoid unauthorised access to the PBX, keep the password secret. If it becomes known to others, the PBX may be misused.
- · Change the password periodically.

Notice

 When disabling the password requirement, ensure that an unauthorised third-party is not allowed access to your extension.

1.8.4 Sending Messages

- Message Delivery
- Personal Group Distribution Lists
- External Message Delivery
- External Message Delivery Lists
- Receiving External Delivery Messages

You can record messages and send them to other subscribers, to extension users who do not have mailboxes, and even to outside parties. Messages can be sent using one of the following features:

Message Delivery:

Sending a message to other subscribers (refer to " Message Delivery").

External Message Delivery:

Sending a message to parties that do not have Unified Messaging system mailboxes (extension users and outside parties) (refer to " External Message Delivery").

There are several ways to determine the recipients of your messages. You can specify recipients by:

- Mailbox number or subscriber name (specifies an individual recipient for Message Delivery).
- Personal Group Distribution List number or Mailbox Group number (specifies a group of recipients for Message Delivery).
- Extension number or telephone number (specifies an individual recipient for External Message Delivery).
- External Message Delivery List number (specifies a group of recipients for External Message Delivery).

Message Delivery

You can send messages to other subscribers. You can specify message recipients either by number or by subscriber name.

To specify the recipients by number:

- · Enter the subscriber's mailbox number.
- Enter a Personal Group Distribution List number (refer to " Personal Group Distribution Lists").
- Enter a Mailbox Group number (these must be created by the System Administrator. For more information, consult your System Administrator).

To specify the recipients by name:

• Enter the first few letters of the subscriber's name (Dialling by Name feature).

Once you have specified the recipients, you can record a message. Before sending your message, you can set any of the following:

Urgent Status:

The message will be heard before other messages by the recipient.

Private Status:


The recipient will not be able to forward the message, ensuring privacy.


Auto Receipt:

You will receive notification once the recipient has played back the message.

Finally, you can send your message immediately or set a message delivery time.

To send a message








- *1 Example: To enter 5:00, press 5#. To enter 5:15, press 515#.
- *2 This option may not be available if the system is programmed to use 24-hour time.
- *3 Example: If today is February 16 and you enter **17#**, the message will be delivered tomorrow. If today is February 16 and you enter **5#**, the message will be delivered on March 5.
- Auto Receipt is not enabled by default. For more information, consult your System Administrator.
- New urgent messages are played before any other messages. However, old urgent messages are played with other messages, in the original order.


Personal Group Distribution Lists

Personal Group Distribution Lists allow you to send messages to several subscribers at once (refer to " Message Delivery"). You can create and edit 4 Personal Group Distribution Lists, and these lists can only be used by you. You can assign 40 group members (subscribers) to each list and record a name for each group (for example, "Sales Team", "Department Heads", etc.).


To create and edit personal group distribution lists



To delete members from personal group distribution lists



To change personal group distribution list names





• The System Administrator can create "Mailbox Groups", which are similar to personal group distribution lists except they can be used by other subscribers. For more information, consult your System Administrator.

****** External Message Delivery

You can send messages to outside parties and to extension users who do not have their own mailboxes. After you record your message, the system will dial the appropriate telephone numbers and/or extension numbers, and once the party on the other end answers the call, your recorded message will be played back. You can specify message recipients by:

- · Extension number
- Outside telephone number
- External Message Delivery List number (refer to " External Message Delivery Lists")


Unlike recipients who have their own mailboxes, you have no way of knowing who may answer the call when the Unified Messaging system sends an External Delivery Message. To protect the privacy of your messages, you may assign a password that must be entered by the other party before your message is played back.

You can set Auto Receipt so that you will receive notification once the recipient has played back your message. You can also send your message immediately or set a message delivery time. Finally, recipients of an External Delivery Message can reply to your message, and can even set urgent and private message status.




 This feature must be enabled for your mailbox by the System Administrator or System Manager.

To send an external delivery message





 * If you are using an ISDN or SIP line in en bloc dialling mode, to insert a pause or special command in the middle of the telephone number, pause momentarily while entering the telephone number. You will hear a list of available options, for example, "To add more digits, press 4. To insert a pause, press 5.".





- *1 Example: To enter 5:00, press 5#. To enter 5:15, press 515#.
- *2 This option may not be available if the system is programmed to use 24-hour time.
- *3 Example: If today is February 16 and you enter **17#**, the message will be delivered tomorrow. If today is February 16 and you enter **5#**, the message will be delivered on March 5.
- If you set a password required for listening to the message, make sure you notify each recipient what the password is.
- If you are using a PRI line, you may need to enter # at the end of outside telephone numbers. For more information, consult your System Administrator.
- Auto Receipt is not enabled by default. For more information, consult your System Administrator.


External Message Delivery Lists

Your external message delivery lists allow you to send messages to several outside parties and extension users who do not have their own mailboxes at once (refer to " External Message Delivery"). You can create and edit 2 External Message Delivery Lists, and these lists can only be used by you. You can assign up to 8 members to each list and record a name for each member.



• This feature must be enabled for your mailbox by the System Administrator.








• * If you are using an ISDN or SIP line in en bloc dialling mode, to insert a pause or special command in the middle of the telephone number, pause momentarily while entering the telephone number. You will hear a list of available options, for example, "To add more digits, press 4. To insert a pause, press 5.".


To delete members from an external message delivery list



Receiving External Delivery Messages

When you send an external delivery message, the Unified Messaging system will call each of the specified recipients. When a recipient answers the call, the system will guide him or her through the following procedure. After a recipient has listened to an external delivery message, he or she can send you a reply to your message, and even set urgent or private message status.

To receive a message and reply





- If the recipient enters an incorrect password 3 times, the system will announce the following information if it has been programmed. This information can help the recipient track down the message or message sender (you).
 - Company name
 - Callback telephone number
 - Your subscriber name
- The Unified Messaging system may be able to guide recipients using a different language. For more information, consult your System Administrator.

1.8.5 Transferring Calls

- Call Transfer
- Incomplete Call Handling
- Assigning Your Covering Extension
- Remote Call Forwarding
- Assigning and Cancelling Telephone Numbers for Call Transfer to Outside Line

Voice Mail Transfer

Call Transfer

When a call reaches your extension via the Automated Attendant service, normally your extension will ring and you can answer the call. If you use the Call Transfer feature, however, the Unified Messaging system can handle the call in a number of ways. The status you set for Call Transfer determines what happens to the call. You can set one of the following:

Call Blocking:

The call will be handled by the Incomplete Call Handling feature (refer to " Incomplete Call Handling"), which allows you to have your calls ring at another extension, transferred to your mailbox, transferred to the operator, etc. The call will not ring at your extension. The call will be handled according to the settings you have made for Incomplete Call Handling for No Answer.

Call Screening:

The system will prompt the caller to record his or her name. If you are available to answer calls, the system will ring your extension and play back the name of the caller. You can then answer the call if you choose. If you do not or cannot answer the call, the call will be handled according to the settings you have made for Incomplete Call Handling for No Answer.

Intercom Paging:

The Unified Messaging system will page you using the Intercom Paging feature. The call will not ring at your extension. Your name will be announced to alert you to the call. If you do not or cannot answer the call, the call will be handled according to the settings you have made for Incomplete Call Handling for No Answer.

Transfer to Mailbox:

The system will transfer the caller to your mailbox where he or she can leave a message for you. The call will not ring at your extension.


Transfer to Custom Service:

The system will transfer the caller to the custom service you specify here. The call will not ring at your extension.

Disable Call Transfer:

Turns the Call Transfer feature off. The call will ring at your extension.

To set call transfer status





If Call Screening or Disable is selected, calls will be transferred to an outside telephone if a
telephone number has been programmed for call transfer to outside line (refer to "
Assigning and Cancelling Telephone Numbers for Call Transfer to Outside Line").

| Incomplete Call Handling

When a call is directed to your extension via the Automated Attendant service, Incomplete Call Handling will handle the calls if:

- You do not answer the call (These calls are considered "no answer" calls).
- You are on another call (These calls are considered "busy" calls).
- You have set Call Blocking (refer to " Call Transfer").

The status you set for Incomplete Call Handling determines what happens to these calls. You can set one or more of the following for no answer calls and for busy calls separately. If you select more than one option, the caller will be prompted to select his or her desired option.

Leaving a Message:

The system will transfer the caller to your mailbox where he or she can leave a message for you.

Transfer to Covering Extension:

The system will transfer the caller to your Covering Extension (refer to " Assigning Your Covering Extension"). If you have not assigned your Covering Extension, this option is not available.

Intercom Paging:

The system will page you using the Intercom Paging feature. Your name will be announced to alert you to the call.

Transfer to Custom Service:

The system will transfer the caller to the Custom Service you specify here.


Transfer to Operator:

The system will transfer the caller to the operator.

Return to Top Menu:

The caller is returned to the top menu of the Automated Attendant service and can then choose to call a different extension.

To set Incomplete Call Handling status





 When Call Blocking is enabled, blocked calls are treated by Incomplete Call Handling for no answer calls.

Assigning Your Covering Extension

A Covering Extension is an extension that receives your calls instead of you. Your calls can be transferred to your Covering Extension in 2 ways:


- By the Incomplete Call Handling Feature:
 - When the Incomplete Call Handling feature handles the call (i.e., if you do not answer, if you are on another call, or if you have set Call Blocking), it will be transferred to your Covering Extension if you have set Incomplete Call Handling to "Transfer to Covering Extension" (refer to " Incomplete Call Handling").
- By pressing the specified dialling key (0, 3–9):

 If the caller presses the key assigned for "Transfer to the Specified Extension" during your greeting message or while recording a message for you, the call will be transferred to your Covering Extension.



- You can change the dialling key that transfers your callers to your Covering Extension. If
 you assign the "Transfer to Operator" option in your Personal Custom Service to a dialling
 key, callers who press that dialling key will be transferred to your Covering Extension (refer
 to " Personal Custom Service").
- If you do not assign your Covering Extension, callers will be transferred to the operator instead.

To assign your Covering Extension





 Once you assign a Covering Extension, remember to tell callers in your greeting message that they can press the button you have assigned for transferring to your Covering Extension. For example, "To speak with my assistant, press 0".

Remote Call Forwarding

You can programme the Unified Messaging system to forward your calls to another extension or to an outside telephone (if authorised). You can do this even when you are away from the office. This feature may be disabled by the System Administrator or System Manager for your mailbox. There are 6 forwarding settings available:

FWD All:

Forwards all incoming calls to a specified extension number.

FWD Busy:

Forwards all incoming calls to a specified extension number when you are already on another call.

FWD No Answer:

Forwards all incoming calls to a specified extension number when you do not answer your telephone.

FWD Busy and No Answer:

Forwards all incoming calls to a specified extension number when you are on another call or do not answer your telephone.


FWD to Outside:

Forwards all incoming calls to the specified outside telephone number if you are authorised to use this feature.

FWD Cancel:

Cancels the forwarding setting.


To assign outside telephone numbers for Remote Call Forwarding





- Before you can forward your calls to an outside telephone, you should first store the
 telephone numbers you plan on using with this feature. You can store 2 telephone numbers
 for use with Remote Call Forwarding.
- If you change one of the outside telephone numbers for Remote Call Forwarding, you will need to set Remote Call Forwarding to "FWD to Outside" once again before the new outside telephone number will be used as the forward destination. If you do not do this, the old telephone number will continue to be used.

To set/cancel Remote Call Forwarding






 * This option is announced only if you are authorised to use it through system programming for PBX COS (Class of Service) settings and UM COS settings. For more information, consult your System Administrator.

♦ Assigning and Cancelling Telephone Numbers for Call Transfer to Outside Line


When you assign a telephone number for Call Transfer to Outside Line, your calls will be transferred to the assigned telephone number when:

- You have set Call Screening (refer to " Call Transfer").
- You have set Disable Call Transfer (refer to " Call Transfer").

To assign telephone numbers for call transfer to outside line



To cancel telephone numbers for call transfer to outside line





- · This feature must be enabled for your mailbox by the System Administrator.
- If you are using a PRI line, you may need to enter # at the end of outside telephone numbers. Consult your System Administrator for more information.


Voice Mail Transfer

If you cannot answer calls, you can forward them to your mailbox. You can select the type of incoming calls (Intercom Calls/Outside Calls/Both Calls) that are forwarded.


If your telephone has a Message button, the Message light turns on when a message is left in your mailbox. You will hear an indication tone* when going off-hook, regardless of whether or not your telephone has a Message button.

You can also create a Voice Mail Transfer button on your phone to transfer received outside calls to a mailbox of another extension so that calling parties can leave messages. Using the Voice Mail Transfer button, you can also perform operations with one touch (for PT and PS only).


To forward your calls to your mailbox




To forward a call to your mailbox while it is ringing



To transfer a call to a mailbox



To transfer your own call to the called extension's mailbox





*Indication tone after going off-hook





Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a Voice Mail Transfer button or a Message button.

1.8.6 Other Features

- Interview Mailbox
- Message Waiting Notification
- Personal Caller Name Announcement
- Live Call Screening (LCS)
- Recording Your Conversation
- Assigning Your Telephone Numbers for Remote Automatic Log-in and Toll Saver
- Personal Custom Service
- Setting the Alarm (Timed Reminder)
- Setting Absent Message Remotely
- Call-through Service
- Sending a Fax from your PC
- IMAP

Interview Mailbox


An interview mailbox is a mailbox designed to ask questions to callers and record their answers. If you have an interview mailbox (not all subscribers do), you can record up to 10 questions and set the answer recording time individually for each question from 1 to 60 seconds.

Your interview mailbox can be used, for example, to allow callers to place orders or request information from your company. You can ask them to record their names, address, and order or request information, and then you can note their information later while playing back their messages.




• If you would like to use this feature, you must first be assigned an Interview Mailbox. For more information, consult your System Administrator.


To record questions



To change answer lengths



To delete questions



Message Reception Mode

If you have an interview mailbox in addition to your regular mailbox, Message Reception Mode determines which mailbox is used when:

- Calls are directed to your mailbox by the "Leaving a Message" setting of the Incomplete Call Handling feature (refer to " Incomplete Call Handling").
- Your extension is a Logical Extension (i.e., your mailbox receives your calls automatically, perhaps because you do not have your own telephone for regular use).

To set a message mode





 Not all subscribers have interview mailboxes. For more information, consult your System Administrator.

♦♦ Message Waiting Notification

The Message Waiting Notification feature lets you know you have received new messages in your mailbox by:

Message Waiting Lamp:

The message lamp on your telephone (if it has one) will light when you receive a new message. If you have a 6-line display PT, you can also see the number of new messages you have on your display. If your telephone has a Message button, the Message light will also turn on when you receive a new message.

Device Notification:

Notifying you via a "device", i.e., an outside telephone, another PBX extension, your cellular phone, etc. You can assign three different devices. For each device, you have the option of receiving notification for urgent messages only, or for all messages. You can also choose to receive notification during certain hours only

(called "scheduling"), which is useful if you do not want to be disturbed at night, for example. For more information on scheduling, consult your System Administrator.


If you turn device notification on for more than one device, the lowest numbered device (1, 2, or 3) will be used first. If notification is not possible (for example, if your outside telephone is busy), the next device will be used.

Message notification by e-mail may also be available for your mailbox. When you receive new messages in your mailbox, you can receive notification by e-mail. The recorded message can also be added to the e-mail as an attachment. Consult your System Administrator for more information.




 Displaying the number of new messages is only available with a 6-line Display PT. For more information, consult your System Administrator.

To turn Message Waiting Lamp Notification On/Off




To turn Device Notification On/Off





- Device number 4, 5, or 6 is used to specify a device number that is "Device No. 1, 2, or 3" for "E-mail/Text Message Device" in Web Maintenance Console.
- To use the Device Notification feature for device number 1, 2, or 3, the telephone number for each device should first be assigned.

To change device numbers






- * If you are using an ISDN or SIP line in en bloc dialling mode, to insert a pause or special command in the middle of the telephone number, pause momentarily while entering the telephone number. You will hear a list of available options, for example, "To add more digits, press 4. To insert a pause, press 5.".
- If you are using a PRI line, you may need to enter # at the end of outside telephone numbers. Consult your System Administrator for more information.

Personal Caller Name Announcement


By storing caller telephone numbers and recording caller names, you can have the Unified Messaging system announce the caller name to you when:

- · You play back a message from one of the assigned callers.
- The system transfers a call to you from one of the assigned callers.
- The system pages you to inform you that you have a call from one of the assigned callers. This feature may be disabled by the System Administrator or System Manager for your mailbox.


To assign Caller ID numbers and recording names



To change Caller ID numbers and recorded names



To delete Caller ID numbers and recorded names





 The number of callers you can assign for this feature is controlled by the System Administrator.

♦♦ Live Call Screening (LCS)

While a caller is leaving a message in your mailbox, you can monitor the call without answering. If you so desire, you can answer the call while monitoring. There are two methods available (Default: Hands-free mode).



Hands-free mode:

You can monitor the message automatically, live through the telephone speaker.


Private mode:

You will hear an alarm tone while the caller is leaving a message.


Before operating

- · Create a Live Call Screening (LCS) button (Personal Programming).
- Select the mode, either Hands-free or Private (Personal Programming).
- · Set the extension PIN (Personal Identification Number).
- · Set the Live Call Screening feature.

To set Live Call Screening




To cancel Live Call Screening



Operation Flowchart

The operations in the shaded areas can be done hands-free.





The Live Call Screening (LCS) button light shows the feature status as follows:
 Off: LCS is off.

Flashing green rapidly: Alerting in the Private mode.

Flashing green slowly: Monitoring.

Red on: LCS is on.

- The manager extension can clear an extension PIN.
- This feature is available for a single line telephone if it is connected to a proprietary telephone in parallel. (Private mode only)

 To answer the call while monitoring, press Recall/hookswitch.
- Only the handset monitoring in the Private mode is available for PS users.



Customising Your Phone


- 3.1.2 Settings on the Programming Mode—Live Call Screening Mode Set
 Select the mode, either monitoring the message through the speaker automatically or
 receiving, while the caller leaves a message.
- 3.1.3 Customising the Buttons
 Create or edit a Live Call Screening (LCS) button.

Recording Your Conversation


You can record a conversation into a mailbox while talking on the phone. You can select the mailbox each time you record a conversation.




To record into your mailbox (Two-way Record)



To record into another mailbox (Two-way Transfer)



To record into another mailbox with one touch (One-touch Two-way Transfer)





 The Two-way Record button light, Two-way Transfer button light or One-touch Two-way Transfer button light shows the current status as follows:

Off: Not recording.

On: Recording the conversation.

Note

When you record your Two-way telephone conversations, you should inform the other party that the conversation is being recorded.



- If all Unified Messaging system ports are busy when you try to use one of these features, you will hear a warning tone, dial tone, or busy tone, depending on the feature you are trying to use.
- Recording time when using these features may be limited. For more information, consult your System Administrator.



Customising Your Phone


3.1.3 Customising the Buttons
 Create or edit a Two-way Record button, a Two-way Transfer button and a One-touch Two-way Transfer button.

♦♦ Assigning Your Telephone Numbers for Remote Automatic Log-in and Toll Saver

When logging in to your mailbox remotely (i.e., from an outside telephone) to listen to your messages, the Remote Automatic Log-in (refer to " Remote Access") and Toll Saver features identify you by recognising your telephone number (caller ID). In order to use these features, you must first store the telephone numbers that you will use to access your mailbox remotely.

Automatic Log-in and Toll Saver may be disabled by the System Administrator for your mailbox.

To assign





 The System Administrator must enable Automatic Log-in and Toll Saver for your mailbox before it can be used.

Personal Custom Service

A Personal Custom Service is a set of options you can present to your callers, allowing them to press buttons on their telephones in order to access certain features. You should explain the options available to your callers in each of your personal greeting messages, for example, "This is (name). I can't take your call right now. Press 3 to leave me a message. Press 4 to speak with my assistant. Press 5 to dial another extension...". For details on recording your greeting messages, refer to " Changing or Deleting Your Personal Greeting Messages" or " Personal Greetings for Caller ID".

You can create your own personal custom service and allow your callers to access the following features:

Transfer to Mailbox:

The system will transfer the caller to your mailbox (or another mailbox you specify here) where he or she can leave a message.

Transfer to Extension:

The system will transfer the caller to the extension you specify when creating the custom service.

Transfer to Outside:

The system will transfer the caller to the outside telephone number you specify when creating the custom service. This feature must be enabled for your mailbox by the System Administrator or System Manager.

Transfer to Custom Service:

The system will transfer the caller to the Custom Service you specify here.

Voice Mail Service:

The system will prompt the caller to enter a mailbox number and leave a message.

Automated Attendant Service:

The system will prompt the caller to dial an extension number in order to speak with someone else.

Intercom Paging:

The system will page you using the Intercom Paging feature. Your name will be announced to alert you to the call.

Repeat Greeting:

The caller can play your greeting message back from the beginning in order to listen to your Personal Custom Service options once again.

Transfer to Operator:

The system will transfer the caller to the operator, or to your Covering Extension if you have assigned one (refer to " Assigning Your Covering Extension").

You can also select what happens when a caller makes no selection (No DTMF Input Operation) while listening to your greeting, perhaps because the caller is using a rotary/pulse telephone. The caller can either be transferred to your mailbox or be disconnected.




 The following dialling keys are assigned to the following features by default, and cannot be changed.


1	End recording
2	Begin recording while listening to personal greeting message

X Exit


To create your personal custom service




To delete options from your personal custom service



To select the No DTMF Input operation



To confirm the settings for your personal custom service






- The System Administrator or the System Manager must enable Transfer to Outside for your mailbox before it can be used.
- The Transfer to Outside option can be used a maximum of 4 times in your Personal Custom Service.
- If you are using a PRI line, you may need to enter # at the end of outside telephone numbers. For more information, consult your System Administrator.

♦♦ Setting the Alarm (Timed Reminder)

You can receive an alarm at your telephone to remind you of a meeting, appointment or as a wake-up call. The alarm can occur either once or daily (every day until cancelled) at a preset time. When you go off-hook to answer, you will hear a special dial tone or prerecorded message.

To set/cancel




- *1 Example: To enter 5:00, press 5#. To enter 5:15, press 515#.
- *2 This option may not be available if the system is programmed to use 24-hour time.

Setting Absent Message Remotely

You can set your absent message by accessing the subscriber service menu. To login to your mailbox from an outside telephone, refer to " Remote Access".


To set/cancel



Call-through Service

You can make outside calls by accessing the subscriber service menu (from an outside telephone) and dialling an outside destination. To login to your mailbox from an outside telephone, refer to "�� Remote Access".

To call an outside party





This feature must be enabled for your mailbox by the System Administrator.

♦♦ Sending a Fax from your PC

You can send a document from your PC as a fax by selecting KX-NSX series FAX Driver as the printer.

To download KX-NSX series FAX Driver

- 1. Log in to My Portal.
- 2. On the My Portal screen, click the Voicemail tab.
- 3. Click Download for Fax Service Utility to access the download site for the KX-NSX series FAX Driver.



- For details about the KX-NSX series FAX Driver software, refer to the software's documentation.
- For details about Web Maintenance Console, refer to "3.2 System Programming Using Web Maintenance Console".

MAP

If your e-mail client supports IMAP4, you can access the contents of your mailbox through an e-mail client and you can do the following:

- Play back voice messages
- · View received fax messages
- · Save voice and fax message data to your PC
- · Delete voice and fax messages



• For configuring an IMAP account, consult your System Administrator.

UM IMAP Session Controller for Microsoft Outlook

If you will be accessing Unified Messaging data through an IMAP connection, you must install the IMAP Session Controller software. This software is a plug-in for Microsoft Windows®. When installed, it appears in the notification area. The software changes the selected account in the Outlook user interface from the Unified Messaging IMAP account to the default Outlook inbox after a specified time period. Doing so enables multiple users efficiently interact with the KX-NS1000 through Microsoft Outlook.

To download IMAP Session Controller

You can download the IMAP Session Controller software from Web Maintenance Console:

- 1. Log in to My Portal.
- 2. On the My Portal screen, click the Voicemail tab.
- Click Download for IMAP Plug-in for MS-Outlook to access the download site for the IMAP Session Controller software.



 For details about Web Maintenance Console, refer to "3.2 System Programming Using Web Maintenance Console".

To install IMAP Session Controller

Double-click UmicSetup.exe, and then follow the on-screen guidance to install the software.

To uninstall IMAP Session Controller

Uninstall this software using the programme uninstall feature in the Control Panel. For details, refer to the documentation for your operating system.

To configure settings and view information

While this software is running, you can configure settings and view information about the software. Rightclick the icon in the notification area, and then select an item.

Notification area icon



Item	Description
Settings	Language Select the language to use for the settings dialogue box and the notification area menu.
	No Operation Timer Enter the time period after which the selected account is changed from the Unified Messaging account to the default Outlook inbox if there has been no user activity. Timer value: 30 to 600 seconds (Recommended timer value: 30 to 60 seconds)


Item	Description	
	E-Mail Account for UM Enter your Unified Messaging e-mail account. The maximum size is 256 characters. If nothing is entered, all of the e-mail accounts using IMAP are assumed to be Unified Messaging accounts. You can copy the mail account from Mail Account in the General tab of the Internet E-mail Settings dialogue box.	
	To open the Internet E-mail Settings dialogue box:	
	 In Outlook 2007, click the Tools menu → Account Settings → Change → More Settings button. 	
	 In Outlook 2010, click the File menu → Info → Account Settings → Change → More Settings button. 	
About	Display the copyright and version of this software.	
Exit	Exit this software.	

1.8.7 Quick Reference


The flow below includes all top menu options and frequently used features. Only options 1–4 and 0 are announced in the top menu when accessed. If you press 0 (help menu), you can listen to the whole top menu (options 1–9).

The help menu may not be available from the top menu depending on the COS settings of your mailbox.





Continued from previous page



Continued on next page


Continued from previous page **Set Other Features:** 1 Listen to Deleted Message 2 Set Interview Mailbox 3 Set External Delivery Message 4 Set Remote Call Forwarding 5 Set Timed Reminder Listen to Deleted Messages: Receive Deleted Message (During or after playback): 2 1 Voice Message Repeat Message 2 Fax Message Envelope (#) 1.1 Previous Message # All Messages 2 Next Message 3 Recover Message 6 Message Envelope Rewind (During playback only) Pause/Restart (During playback only) 8.4 Volume Up (During playback only) 9 Fast Forward (During playback only) 0 Help Interview Mailbox Management: 1 Record Question 2 Set Answer Length 3 Erase Question **External Message Delivery:** 1 Record Message 2 Set a Mailing List Remote Call Forwarding Set: 1 FWD—All Calls 2 FWD—Busy 3 FWD—No Answer 4 FWD-Busy/No Answer 5 FWD to an Outside Line 6 FWD Cancel

1.9 Setting the Telephone According to Your Needs

1.9.1 Setting the Alarm (Timed Reminder)

You can receive an alarm at your telephone to remind you of a meeting, appointment or as a wake-up call. The alarm can occur either once or daily (every day until cancelled) at a preset time. When you go off-hook to answer, you will hear a special dial tone or prerecorded message.


To set






* Enter the time in the format assigned to your PBX (12-hour or 24-hour).

To cancel



To stop or answer the ringback



To confirm





- You can also confirm the Timed Reminder by using the soft button.
- The alarm keeps ringing for preprogrammed seconds.
- If you receive an incoming call during ringback, the ringing starts after the ringback stops.
- If you are having a conversation exceeding alarm ringing period, the ringback will start after your conversation.


1.9.2 Refusing Incoming Calls (Do Not Disturb [DND])

- Do Not Disturb (DND)
- Switching FWD/DND Status Using Fixed FWD/DND Button

♦ Do Not Disturb (DND)

You can set this feature to prevent incoming calls from ringing at your extension. This can be useful, for example, when you are in a meeting or busy.

To set/cancel





 When using a proprietary telephone, you can set or cancel Do Not Disturb by pressing the FWD/DND button (fixed button) instead of "*x710".
 For details, refer to the documentation for your phone.



The FWD/DND button light shows the current status as follows:
 Off: Both features are not set.

Red on: FWD mode

Flashing red slowly: DND mode

 The system has two modes: (1) FWD/DND Cycle Switch Mode and (2) FWD/DND Setting Mode. Ask your manager what mode your system is in if you are not sure.

(1) When in FWD/DND Cycle Switch Mode:

Pressing the FWD/DND button (fixed button) while in idle status will cycle the setting as shown below:



(2) When in FWD/DND Setting Mode:

Pressing the FWD/DND button (fixed button) while in idle status allows you to switch the FWD/DND status and set the FWD destination (refer to " Switching FWD/DND Status Using Fixed FWD/DND Button").

Note

A FWD/DND button (customised button) is always in FWD/DND Cycle Switch Mode: the mode cannot be changed.

- If your extension has set this feature, a calling extension will hear DND tone.
- If this feature is set, the Call Forwarding (FWD) feature does not work.
- Specified extensions can override this feature and call DND extensions (DND Override).
- When making a call using an SDN button to a PDN extension with DND set, this feature will temporarily be deactivated.
- When intercom calls are set to be handled differently from outside calls (DND set/cancel), we recommend establishing buttons for both FWD/DND—Outside calls and FWD/DND—Intercom calls, because:
 - a. the light patterns of the FWD/DND—Both calls button (including FWD/DND button [fixed button]) will indicate the setting for either outside calls or intercoms calls, but not both.

Note

The DND icon on PS display reflects the setting for outside calls only.

b. pressing the FWD/DND—Both calls button (including FWD/DND button [fixed button]) will not change the FWD or DND mode for intercom calls and outside calls separately.



Customising Your Phone


3.1.3 Customising the Buttons
 Create or edit FWD/DND (Both calls, Outside calls, Intercom calls) buttons.

♦♦ Switching FWD/DND Status Using Fixed FWD/DND Button


Using a proprietary telephone (PT) or SIP phone, you can easily switch the FWD/DND status for outside/intercom calls without clearing any FWD destination that was set previously.




To switch the FWD/DND status for outside calls



To switch the FWD/DND status for intercom calls



To set and clear FWD/DND for outside/intercom calls





• * This step can be omitted.

1.9.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)

During a conversation, you can be informed of a call waiting with a tone or voice announcement through your built-in speaker or handset. (Default: Disable—No call [Intercom calls]/No tone [Outside calls])

Call Waiting Tone:

a waiting tone through the built-in speaker of PT/handset of SLT. To change the tone from PT, refer to "3.1.2 Settings on the Programming Mode".


OHCA:

a voice announcement through the built-in speaker


Whisper OHCA:

a voice announcement through the handset

To set/cancel for intercom calls (Manual Call Waiting)



To set/cancel for outside calls (Automatic Call Waiting)





- OHCA is only available with certain digital proprietary telephones.
- Whisper OHCA is only available with certain digital proprietary telephones and IP proprietary telephones. In addition, both you and the other party must use supported telephones.
- When the incoming extension is received through IP-PT, BSS is sent instead of OHCA.

1.9.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP])

CLIP:


When making an outside call, you can present your preprogrammed telephone number to the called party.

COLP:

When receiving an outside call, you can present your preprogrammed telephone number to the calling party. You can select the telephone number sent, either the number of the line used or the number assigned to your extension.

If you select "Public", the calling/called party sees the number of the line used (subscriber's number). If you select "Your extension", they see the telephone number assigned on your extension.

To show either the number assigned to the outside line or your extension





- Availability of this feature depends on the ISDN service of your telephone company.
- When you forward a call to an outside party, the CLIP number for that call will be that of the calling party or of the forwarding extension depending on system programming.




 If you use the ICD Group button to make a call to the other party, the telephone number assigned to the ICD Group will be used.

1.9.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR])

When receiving an outside call, you can select whether the caller can see your telephone number or not.

To show/prevent





You can change the mode by pressing a preset COLR button while on-hook.
 The COLR button light shows the current status as follows:

Off: shows your telephone number.

Red on: prevents your telephone number being displayed.

· Availability of this feature depends on the ISDN service of your telephone company.




Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a Connected Line Identification Restriction (COLR) button.

1.9.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])

When making an outside call, you can select whether the called party can see your telephone number or not.

To show/prevent





- You can change the mode by pressing a preset CLIR button while on-hook.
 The CLIR button light shows the current status as follows:
 - Off: shows your telephone number.

Red on: prevents your telephone number being displayed.


· Availability of this feature depends on the ISDN service of your telephone company.



Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a Calling Line Identification Restriction (CLIR) button.

1.9.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)






Some extensions may be prohibited from performing this feature.

1.9.8 Turning on the Background Music (BGM)

You can listen to the background music through your telephone speaker while on-hook. An external music source, such as a radio, can be connected. If your extension becomes busy (off-hook, making or receiving a call etc.), the music stops temporarily. When you go back on-hook, the music starts again.



To select and set/cancel






• System programming may be required for some IP-PT users to listen to background music.

1.9.9 Protecting Your Line against Notification Tones (Data Line Security)

You can protect the line against audible notification tones, such as a call waiting tone during a conversation. Set this feature if your extension has a data communication device, such as a PC or fax machine connected to ensure secure data transmission.


To set/cancel



1.9.10 Checking the Time Service Status

You can check the current status of the Time Service on the display.







• The Time Service (Day/Night/Lunch/Break) button light shows the current status as follows:

Off: Day mode

Green on: Lunch mode **Flashing green:** Break mode

Red on: Night mode

Flashing red: Holiday mode

 Any extension user except the managers can check the current status by pressing the Time Service (Day/Night/Lunch/Break) button.



Customising Your Phone


3.1.3 Customising the Buttons
 Create or edit a Time Service (Day/Night/Lunch/Break) button.

1.9.11 Setting the Parallelled Telephone to Ring (Parallelled Telephone)

In the case where a single line telephone is connected in parallel to your digital proprietary telephone, you can choose whether the parallelled single line telephone will ring to an incoming call or not.









- Even if "No ring" is selected, calls can be made and answered on the single line telephone by lifting the handset.
- If you go off-hook while your parallelled telephone is in use, the call will switch over to you.


1.9.12 Clearing Features Set at Your Extension (Extension Feature Clear)

You can reset the settings of the following features on your extension to the default settings with one operation.

This feature is also known as Station Programme Clear.

Features	Default Setting
Hot Line ⁻¹	Off
Message Waiting—(All the messages that have been left by other extension users)	Off
Call Pickup Deny	Allow
Call Forwarding (FWD)*1	Off
Absent Message	Off
Paging Deny	Allow
Timed Reminder	Cleared
Do Not Disturb (DND)*1	Off
Call Waiting for intercom calls ⁻¹ Call Waiting for outside calls ⁻¹	Disable (No call) Disable (No tone)
Executive Busy Override Deny	Allow
BGM	Off
Data Line Security	Off
Parallelled Telephone	The telephone in parallel rings.
Log-in/Log-out	Log-in

These features may not be reset depending on the system programming.





· For Users in Canada Only:

After performing Extension Feature Clear, the setting of Call Waiting becomes "Enable (Tone)". In this case, dial tone 2 will be heard when you go off-hook.



Nonstop servis TELEFONNÍ ÚSTŘEDNY


volejte dispečink tel. 606 193 950
PanaTEL® je specialistou na telefonní ústředny, komunikační systémy Panasonic

www.PanaTEL.cz

1.10 Utilising the Call Centre

1.10.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up)


You can control your status in an incoming call distribution group. When in the Log-out mode, incoming calls to the group will not ring at your extension. When you return, calls will again ring at your extension. (Default: Log-in) Even if your extension is logged-in, you can have a specified time period (wrap-up time) when you will not receive calls after completing a previous call. This time can be used for you to write a report and so on. You can also manually select "Not Ready" mode to temporarily leave a distribution group.





Conditions

 Wrap-up mode transitions to one of the devices that are associated with the user container at the end of a phone call.


To set Log-in/Log-out








To enter/leave Not Ready mode



To set/cancel Not Ready mode or to leave Wrap-up mode (To enter Ready mode)





* The status will be as follows:

Ready → Not Ready Not Ready → Ready Wrap-up → Not Ready

• The Log-in/Log-out of a specified group button light shows the current status as follows:

Off: Log-in mode
Red on: Log-out mode

 The Wrap-up button alternates the setting of Wrap-up mode, Not Ready mode or Ready mode.

The Wrap-up button light shows the current status as follows:

Off: Ready mode

Red on: Not Ready mode Flashing red: Wrap-up mode

- In Wrap-up mode/Not Ready mode, your extension does not receive calls through any group, even if it belongs to multiple groups.
- The last remaining logged-in extension may not be allowed to log out, depending on system programming.
- The Supervisor extension can control the Log-in/Log-out status of other extensions. For more information, refer to "1.10.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)".




Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a Log-in/Log-out button, a Log-in/Log-out of a specified group button or a
 Wrap-up button.

1.10.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)

- Monitoring the Status of Waiting Calls
- Monitoring and Changing the Log-in/Log-out Status of Extensions

The extension assigned as a Supervisor extension can monitor and control the status of other extensions in an incoming call distribution group. It should have a PT with 6-line display. The display and DSS buttons show as follows:



♦♦ Monitoring the Status of Waiting Calls

The Supervisor extension can monitor the status of calls waiting to be answered in the queue. If an incoming call distribution group has an overflowed call, the display shows the status automatically. The following information is displayed.


<Queuing Monitor>

- · The current date/time
- · The ICD Group extension number/name
- · The number of waiting calls
- · The longest waiting time


<Call Log History>

- · The date/time when cleared at last time
- · The total number of received calls
- The number of overflowed calls
- · The number of unanswered calls
- The average waiting time of queuing calls

To monitor



To clear Call Log History






• The accumulated data is cleared.

"****" shows if the number to be displayed exceeds the maximum displayable digits.


Monitoring and Changing the Log-in/Log-out Status of Extensions

The Supervisor extension can monitor the Log-in/Log-out status of the incoming call distribution group members by the DSS button light. It can also change their Log-in/Log-out status if needed.

To monitor



To change the Log-in/Log-out mode





The DSS button light shows the current status as follows:

Off: The extension is not in the group. **Green on**: Log-in (Ready) mode

Flashing green: Log-in (Not Ready) mode

Red on: Log-out mode


1.10.3 Forwarding a Waiting Call (Manual Queue Redirection)

When your incoming call distribution group is busy and other outside calls arrive, the arriving calls are put in a waiting queue.



Extensions can check the status of the queue with the Hurry-up button light, and forward the longest waiting call in the queue to a preset destination manually. This feature is also known as Hurry-up Transfer.

To forward the waiting call





The Hurry-up button light shows the current status as follows:

Off: No waiting call.

Red on: Some calls are waiting.

Flashing red: The number of calls exceeds the manual queue redirection level.



Customising Your Phone

 3.1.3 Customising the Buttons Create or edit a Hurry-up button.

1.11 Using User-supplied Equipment

1.11.1 If a Doorphone/Door Opener is Connected

You can talk to a person at the door through the doorphone. Preprogrammed extensions or an outside party can receive the calls from the doorphone. You can open the door.


- Doorphone Call
- Opening a Door (Door Open)




- When connecting a KX-NTV150 or KX-NTV160:
 - It can be registered to the NSX server as a Communication IP Camera or Video Door Phone. KX-NTV100 series are SIP extensions with a call button and a camera, and they can make and receive calls in the same way as other SIP extensions.
 - It is treated as a SIP extension, then the doorphone number is not assigned. The following doorphone control with doorphone number is not available.
 - To call the doorphone [*33] + [doorphone no.]
 - Opening a door (Door open) from specified extension [*55] + [doorphone no.]
 - It is necessary to register the unit to the V-SIPEXT card as a SIP phone.
 - It is not necessary to associate the unit with a user container.
 - It is necessary to configure the Optional IP Device settings.
 - Camera control by key pad (dialling) operation is possible only for KX-HDV series P-SIP phones, and third party SIP phones compatible with RFC8233.
 - P2P communication between the KX-NTV150/KX-NTV160 and the connected devices is necessary for camera control.

Doorphone Call


To call from the doorphone



To answer a call from the doorphone



To call the doorphone






• If no one answers a doorphone call within a specified time period, the call is cancelled.

♦ Opening a Door (Door Open)

Some extensions may be prohibited from using this feature.

From a specified extension



From any extension while talking to the doorphone






• The door open will be triggered for a specified time period.

1.11.2 If an External Relay is Connected

Preprogrammed extensions can switch on a relay (e.g., alarm) connected to the PBX.

To switch on the relay





· The relay will be switched off after a specified time period.

1.11.3 If an External Sensor is Connected

Preprogrammed extensions can receive an alert call from an external sensor (e.g., security alarm) connected to the PBX.

To answer a sensor call





• If you do not answer a sensor call within a specified time period, the sensor call will stop.



Dial Tone Definitions

· 5.4 What is This Tone?


1.11.4 If a Host PBX is Connected

Accessing External Services (External Feature Access [EFA])

♦♦ Accessing External Services (External Feature Access [EFA])

You can access special features (e.g., Call Waiting) offered by a host PBX or telephone company. This feature is only effective for an outside call.

<Example> To hold the current call and then talk to the new party





• In this case, the FLASH/RECALL button on a proprietary telephone must be set to External Feature Access (EFA) mode through system programming.



Customising Your Phone

• 3.1.3 Customising the Buttons Create or edit an External Feature Access (EFA) button.

1.12 Administrative Features

1.12.1 Using the Telephones in a Hotel-type Environment (Hospitality Features)

In a hotel-type environment, an extension assigned as a hotel operator can be used to view and set the check-in/check-out/cleaned-up (Ready or Not Ready) status of each guest room extension. When the hotel operator presses a flexible button assigned as "Check-in", "Check-out", or "Cleaned-up" on his/her extension, the extension will switch to Room Status Control mode, and the light of the DSS button for each room extension will show the current room status. This allows the hotel operator to manage guests and rooms with just a telephone. In addition, the hotel operator can set automatic wake-up calls for guest rooms.





Note:

Hospitality features cannot be used at the same time as the Supervisory Monitor (ACD) Control feature. (Refer to "4.1.3 Supervisory Monitor (ACD) Control".) For details, consult your system administrator.

- **Check-in**
- Check-out
- Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)
- Cleaned-up



- The hotel operator must be using a 6-line display PT to use the Check-in, Check-out, and Cleaned-up features.
- While in Room Status Control mode:
 - **1.** The hotel operator's extension can only check extensions in/out and ready/not ready. All other operations will be ignored.
 - **2.** The light of each DSS button shows the room status of the corresponding extension as follows:

Off: Checked-out and Ready

Flashing Red: Checked-out and Not Ready


Red on: Checked-in

- 3. The lights of other buttons may not show their normal display.
- **4.** The hotel operator's extension is considered to be busy. Callers to that extension will hear a busy tone.

Check-in

The hotel operator can change the room status of extensions to check-in by using the Check-in button assigned on his/her extension.

To check in





- After check-in, Remote Extension Dial Lock is deactivated, and the guest can make outside calls from the room extension. (Refer to "2.1.1 Extension Control".)
- After check-in, all billing data previously charged to the extension will be cleared automatically.
- When the room status of extensions is changed, detailed room status information is recorded automatically. This requires system programming.
 Example>

Date	Time	Ext	со	Dial Number
02/02/00	03:07PM	1234		Check in


♦ Check-out

The hotel operator can change the room status of extensions to check-out by using the Check-out button assigned on his/her extension.


Depending on the setting of the PBX, the hotel operator can do the following:

- · Record/edit charges for Minibar/Others
- Print out an invoice containing charge information

To check out a room with/without printing an invoice



To record/edit room charges and check out a room with/without printing an invoice





- After check-out, Remote Extension Dial Lock is activated, and outside calls from the room extension are restricted. (Refer to "2.1.1 Extension Control".)
- After check-out, wake-up call and Call Log information for the room extension are cleared automatically. In addition, features set on the room extension are reset to the default settings. For a list of features that are reset, refer to "1.9.12 Clearing Features Set at Your Extension (Extension Feature Clear)".
- When the room status of extensions is changed, detailed room status information is recorded automatically. This requires system programming.
 <Example>

Date	Time		Dial Number
02/03/00	MA80:80	1234	Check out

 To print out an invoice, a printer should be connected to the PBX. If the room extension is in use, an invoice cannot be printed out.
 Example>

```
Hotel
***********
Check in : 01.JAN.00 06:31PM
Check out: 03.JAN.00 07:03AM
         : 202 : Mr. Smith
01/01/00 06:52PM 202 01 Call amount:0012 01:24'30 FR00084.50 001
02/01/00 06:07PM 202 01 123456789 00:10'12 FR00010.20 1234567890
02/01/00 07:30PM 202 01 012345678901234 00:06'36 FR00006.60 12345
02/01/00 08:45PM 202 01 0011234567890123 00:03'00 FR00003.00 12345
Telephone
                          104.30 (Tax 10.000% =
                                                9.48)
                         4.00 (Tax 10.000% = 0.36)
Minibar
Others
                           0.00 \text{ (Tax } 15.000\% = 0.00)
                  FR 108.30 \text{ (Tax Total} = 9.84)
Total
Sheet: 002
====== Hotel PBX ======
Tel: +41 3 12 34 56 78 Fax: +41 3 12 34 56 78
E-Mail: 12345678@hotelpbx.ch
```

 The PBX can store a limited amount of room information. When this storage becomes almost full, the information of the extension that made the most calls is printed out automatically. In this case, the printout is similar to the example above, but without categorised charge information and the total. The PBX can then store new room information.

"Call amount:0012" in the example above indicates that the information of 12 phone calls has previously been printed out automatically.




Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a Check-in or a Check-out button.

Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)

The hotel operator can remotely set or cancel a Timed Reminder to a room extension. This allows guests to request wake-up calls without having to program the extension themselves. The hotel operator can also confirm the current Timed Reminder setting for a room extension.


To set






* Enter the time in the format assigned to your PBX (12-hour or 24-hour).

To cancel



To confirm





- Timed Reminder can also be set from the room extension. (For information about setting Timed Reminder, refer to "1.9.1 Setting the Alarm (Timed Reminder)".) The most recent setting will be valid no matter which extension made the setting.
- When a Timed Reminder starts, and when it is answered or not answered, detailed Timed Reminder information is recorded automatically. This requires system programming.
 <Example>

Date	Time	Ext	со	Dial Number
02/02/00 02/02/00				Timed Reminder/Start Timed Reminder/Answer




 Users of PTs without displays can confirm only whether a Timed Reminder has been set or not by following the steps shown above. If set, a confirmation tone will be heard.

Cleaned-up

The hotel operator can change the room status of extensions depending on whether the room has been cleaned or not by using the Cleaned-up button assigned on his/her extension. This allows the hotel operator to confirm that the room is clean and ready for the next guest.

To change the cleaning status of a room





Customising Your Phone


 3.1.3 Customising the Buttons Create or edit a Cleaned-up button.

1.12.2 Recording Information Using Preprogrammed Messages (Printing Message)

You can record a variety of information from your extension using up to 8 preprogrammed messages. Message information from all extensions is recorded with the PBX. For example, it is possible to use this feature as a time card by selecting preprogrammed "sign in" and "sign out" messages.

In a hotel-type environment, this feature can be used to record room information from a room extension. For a list of preprogrammed messages, consult your dealer.

To record





* Depending on the content of the selected message, you may be required to enter a numeric parameter, such as a price or time. Enter the correct number of characters as required for the message. For information about required parameters, consult your dealer. <Example>

If "Snack %%.%%" has been programmed as message number 1 (for recording charges for room snacks consumed), hotel employees would enter data as in the example below using the room extension:

$$\star$$
 761 $\frac{1}{\Box}$ $\frac{0300}{\Box}$ # message no. parameter (Snack charge)

• When a preprogrammed message is selected, detailed information is recorded automatically, as shown below:

Date	Time	Ext	СО	Dial	Number
02/02/00	10:45AM	1234		Snack	c 03.00

 Any charges recorded here are not related to charges that the hotel operator records when checking out a room.

1.13 User Device Management

1.13.1 Introduction to the User Container Feature

The User Container feature links the user to each PBX device, and is configured to provide services and perform maintenance on a per-user basis.

The user owns either a wired connection, softphone or PS as their main device, and owns a sub device, wireless device, public device and the built-in UM mailbox.

The user can use the PBX service features on all devices by using the extension number of the main device as a representative number. The settings for the user's devices and UM mailbox can be configured through My Portal.



- Each user can set the grade, usable devices, and extended features vary depending on the grade.
- In order to set a grade, the activation key of the respective grade needs to be installed.
- By calling the user's main extension, it is possible to send an incoming call signal to the main device, sub device, wireless device and public device at the same time.
- It is possible to send an incoming call signal to a sub device, wireless device and/or public device at a predetermined time delay from the time of an incoming call to the main device.
- When one of the devices registered to 1 user answers to an incoming call, the incoming signal on the other devices will be stopped and only the responsive device will be able to speak with the outside party.
- When DND/FWD is set using any of the user-owned devices, the setting is applied to incoming calls for that user.
- When one of the user's devices is busy, none of the user's devices can be used to make a call.
- The paging signal will be delivered to all extensions, including the main extension, subextension and PS. However, the paging signal cannot be delivered when the terminal type is SIP terminal or SLT.
- · Voice calls can only be used on main extensions that use PT.
- Recalls for the terminal handling such as, pending recalls and callbacks only arrive on the operation device. Transferred recalls arrive at the transfer recall destination extension as configured in the main extension.
- It is possible to forward incoming calls to another device (operation terminal), when any of the main/sub-/wireless devices are on a call while the handsets of other devices (except general purpose SIP terminals) are off hook or [SP-Phone][Monitor] is pressed on the other devices. (Call interception)
- Calls can not be intercepted with another device if the calling device is in any of the following states.
 During extension DT, while dialing an extension, during external line DT, while dialing an
 - external line, during temporary hold, during a conference call (except during 2Way recordings)
- Sounds heard during a call, such as call waiting tones and hold alarms, are only sent to the party that is on the call.
- It is possible to use DISA from a public device number without having to input the extension + password. An Advanced user license or Mobile user license is required in order to use this feature.
- If a device has delayed ringing configured, a pre-ring will sound when the delayed ring times out.

1.13.2 Service-in/Service-out (Smart Desk)

When a telephone terminal does not have a fixed extension number, a user can use that telephone terminal to Service-in using their extension number.


The user can use their extension as the telephone terminal.

- Service-in
- Service-out


Service-in

When a user logs in using a main device, sub device, or wireless device that is assigned to their User Container, the device can be used as a terminal assigned with that user's extension number.


Main Device Service-in Operation



Sub Device Service-in Operation



Wireless Device Service-in Operation






- Service-in can only be operated from devices in a Service-out state.
- Service-in on a sub device or wireless device is only possible from an operational device which can be registered as a sub device or wireless device.
- Service-in on a sub device or wireless device is not possible when the main device is not serviced in.
- Service-in operation for users who are serviced in on other devices.
 When serviced in, if the device of the specified device type (main/sub/wireless) of the specified user is already registered, it is possible to newly Service-in on a device that is performing the Service-in operation by servicing out the registered devices. Any subdevices or wireless devices registered at that time will continue to be serviced in.
- If a PT with an LCD is used, service-in is possible by pressing the **START** button (soft button) while "**Service-OUT**" is displayed on the LCD.

Service-out

When the user performs the Service-out feature on a serviced in terminal, the link between the terminal and the user will be released, causing the terminal to disconnect from the user. A serviced out terminal cannot perform any other services than the Service-in operation or emergency calls.

Service-out Operation






- SIP terminals are unable to perform the Service-out operation.
- Service-out is not possible when on a call, when on hold, or when receiving a call.
- When servicing out a device linked as the main device, the sub devices and wireless
 devices linked to that user will automatically be serviced out as well. However, unlike with
 the normal Service-out state, the sub devices and wireless devices will automatically
 reconnect and become operational again when the main device is serviced in again if the
 other users linked to the user are saved before servicing out on the main device.
- You can change the setting that determines whether password authenitication is required when servicing out. (Default: password authentication enabled)
- If password authentication is selected, the user linked to the device will not be able to service out if there is no User PIN is configured.
- It is possible to Service-in on an extension connected to the DSS console, however, the user will not be able to Service-out.
- To display the Service-out status of Smart Desk, **Handset Number** or **Base&H/S No.** needs to be selected for the Standby Display setting.

1.13.3 Switching between CTI Control Devices

For CTI, operation from any of the devices owned by the user (main/sub/wireless/public) will be notified by the extension number of the main device of the user.

When receiving a response with CTI client for the user call and for Makecalls originating from the CTI client, it is possible to switch between which user-owned device receives a response and which device makes a Makecall with the following methods.

Switching between CTI Control Devices





 It is not possible to configure a public device as a CTI Control Device with KX-NSX Series V1 models.

1.14 Using a Telephone with a Display

1.14.1 Using the Call Log

This is available for display proprietary telephones, and portable stations.

- Calling with the Incoming Call Log
- Calling with the Outgoing Call Log



- PS users: Refer to the documentation for your phone.
- The following PSs can use the incoming call log information in the same way as a wired PT when they receive a call from other extension (including TIE).
 KX-TCA185/KX-TCA285/KX-TCA385
- PSs other than these may not display the same incoming call log information as a PT connected to the PBX.
- · For details about referencing the incoming call log, refer to the PS's documentation.

Calling with the Incoming Call Log

When you receive a call, including external sensor calls, call information is recorded automatically in the incoming call log. A preprogrammed number of calls can be logged per extension.

When the call log is full and other call arrives, the oldest call is deleted.


You can modify the logged telephone number.

When the Call Log button light turns on, there is a call which you did not answer.


The following information is logged.

- Caller's Name
- · Date/Time call received
- Answered or Not Answered Confirmed or Not Confirmed
- · Caller's Phone Number


To confirm the log information with the Call Log button




To confirm the log information with the Navigator Key




To clear the log information



To call



To store the caller's information in personal speed dialling





- The Call Log button light shows the current status as follows:

 Off: No incoming call. Or you have already viewed the call log.

 Red on: You have missed calls to view.
- If your call is answered by another extension, the caller's information is recorded on the displays of both your extension and the answering extension.
- You can lock your call log display by using an extension PIN (Personal Identification Number), so that you can prohibit access to your logged information (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- You can also have a Call Log button for an ICD Group (Incoming Call Distribution Group).
- If a call arrives while you are using the call log, the call log display will be replaced with the caller's information.




Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a Call Log button or Call Log for ICD Group button.

Calling with the Outgoing Call Log

You can redial using the outgoing call log.


To call





- The following PSs can use outgoing call log information to other extensions (including TIE) with same information as a PT connected to the PBX.
 KX-TCA185/KX-TCA285/KX-TCA385
- PSs other than these may not display the same outgoing call log information as a PT connected to the PBX.
- For details about referencing the outgoing call log, refer to the PS's documentation.
- * When an outside call is made from the Outgoing Call Log, if a name is registered to the Personal/System Speed Dialling entry, the name is displayed on the LCD of the display PT making the call.


To call with the REDIAL button





- · This operation is available only for PTs with a display.
- *1 System programming is required for this operation.
- *2 After an outside call is made from the Outgoing Call Log, when another call is made
 using the REDIAL button, if a name is registered to the Personal/System Speed Dialling
 entry, the name is displayed on the LCD of the display PT making the call.

To store the caller's information in personal speed dialling





- You can lock your call log display by using an extension PIN (Personal Identification Number), so that you can prohibit access to your logged information (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- If a call arrives while you are using the call log, the call log display will be replaced with the caller's information.

1.14.2 Using the Directories

You can call using the directories (*Personal Speed Dialling Directory, System Speed Dialling-External (LDAP) and Extension Number Directory*).

Only personal directories can be stored, edited or deleted on your extension.

If a call arrives while you are using a directory, the display will be replaced with the caller's information.

- Calling with the Directory
- Storing Names and Numbers
- Entering Characters



PS users: Refer to the documentation for your PS.

♦ Calling with the Directory

To select and call

KX-NT300/KX-NT500/KX-DT300/KX-DT500

While on-hook







Press **Up** or **Down** until **desired name and/or number***2 appears.



Off-hook



*1 The display order is as follows:

One time: Personal Speed Dialling Directory Two times: System Speed Dialling Directory

Three times: External Directory

Four times: Extension Number Directory

 *2 If a name is registered to the directory entry, the name is displayed on a display PT's LCD when the directory is displayed. When a call is established, if the name of the person who answered the call is received over the line, it is displayed instead of the name registered in the directory.

If a name is registered to the directory entry, the name can be searched for by entering the first 1–6 alphanumeric characters of the name on the directory access screen, and then pressing ENTER or Select (soft button).

When an outside call is made using a directory, if a name is registered to the directory entry, the name is displayed on the second line of a display PT's LCD. The name is not displayed on a phone with a one line LCD.


- To cancel or exit, press the CANCEL or FLASH/RECALL button.
- You can lock your personal speed dialling directory by using an extension PIN (Personal Identification Number), so that you can prohibit access to it (Display Lock). Refer to "3.1.2 Settings on the Programming Mode".
- IP Softphones can only be operated in the classical mode.



- Directory entries generally should include name and number. If the name is not registered, an entry cannot be displayed.
- The System Speed Dialling Directory can be displayed simply by pressing the AUTO DIAL/ STORE button while on-hook.
- Names up to 20 characters that appear on the display during outgoing and incoming calls using the *System Speed Dialling-External (LDAP)* Directory can be stored in the history.
- There are some condition as below when the Name information is searched in *System Speed Dialing-External (LDAP) Directory*.
 - **a.** When the Name information is searched, the maximum number of input characters are six.
 - **b.** In order to search the name, available characters are only alphanumeric characters (Capital letter only).
 - **c.** When the Name with small alphabet is searched, it is necessary to set not to distinguish Capital/Small characters. Consult your network administrator.

Storing Names and Numbers

To store a Personal Speed Dialling Directory item





• Telephone numbers and names displayed are stored using the first spare Personal Speed Dialling memory available.



• For more details, refer to "To store the names and numbers in personal speed dialling" in "3.1.2 Settings on the Programming Mode".

♦ Entering Characters

You can enter the following characters. The tables show you the characters available for each button. Table 1 or Table 2 can be programmed.

Table 1 (Standard mode)

Times Buttons	1	2	3	4	5	6	7	8	9
1	!	?	"	1					
2	A	В	С	a	b	C	2		
3	D	Е	F	d	е	f	3		
4	G	Н	I	g	h	i	4		
5	J	K	L	j	k	1	5		
6	М	N	0	m	n	0	6		
7	Р	Q	R	S	р	q	r	s	7
8	Т	U	V	t	u	v	8		
9	W	Х	Y	Z	W	х	У	Z	9
0	(Space)	•	,	1	:	;	0		
*	/	+	_	=	<	>	×		
#	\$	00	&	@	()	€	£	#

Table 1 (Standard mode for RU model)

Times	1	2	3	4	5	6	7	8	9
1	!	?	11	1					
2	A	В	С	a	b	С	2		
3	D	E	F	d	е	f	3		
4	G	Н	I	g	h	i	4		
5	J	K	L	j	k	1	5		
6	М	N	0	m	n	0	6		
7	P	Q	R	S	р	q	r	S	7
8	Т	U	V	t	u	v	8		
9	W	X	Y	Z	W	х	У	Z	9
0	(Space)		,	1	:	;	0		
*	/	+	_	=	<	>	*		
#	\$	010	&	@	()			#

Table 2 (Option mode)

Times Buttons	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	!	?	"	ä	ö	ü	1								
2	Α	В	С	a	b	С	À	Á	Â	Ã	Ä	Å	Æ	Ç	2
3	D	E	F	d	е	f	Đ	È	É	Ê	Ë	3			
4	G	Н	I	g	h	i	Ì	Í	î	Ï	4				
5	J	K	L	j	k	1	5								
6	М	N	0	m	n	0	Ñ	Ò	Ó	ô	õ	Ö	Ø	Œ	6
7	Р	Q	R	S	р	đ	r	s	š	ß	7				
8	Т	U	V	t	u	v	Ù	Ú	Û	ΰ	8				
9	W	Х	Y	Z	W	x	У	z	Ý	ž	9				
0	(Space)		,	1	:	;	0								
*	/	+	_	=	<	>	*								
#	\$	0/0	&	@	()	€	£	#						

Table 2 (Option mode for CE model)

Times Buttons	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	!	?	11	ä	ö	ü	1								
2	A	В	C	а	b	С	Á	Â	Ă	Ä	Ą	Ć	Ç	Č	2
3	D	Е	F	d	е	f	Ď	Đ	É	Ę	Ë	ě	3		
4	G	Н	I	g	h	i	Í	î	4						
5	J	K	L	j	k	1	Ľ	Ĺ	5						
6	М	N	0	m	n	0	Ń	ň	Ó	ô	Ő	Ö	6		
7	Р	Q	R	S	р	q	r	s	Ŕ	Ř	š	Ś	Ş	ß	7
8	Т	U	V	t	u	v	Ť	Ţ	ů	Ú	Ű	Ü	8		
9	W	Х	Y	Z	W	x	У	z	ž	ź	Ż	Ý	9		
0	(Space)		,	ı	:	;	0								
*	/	+	_	=	<	>	*								
#	\$	00	&	@	()	€	£	#						

Table 2 (Option mode for GR model)

Times				_	_		_		
Buttons	1	2	3	4	5	6	7	8	9
1	!	?	"	1					
2	A	В	Γ	2					
3	Δ	E	Z	3					
4	Н	Θ	I	4					
5	K	Λ	М	5					
6	N	Ξ	0	6					
7	П	P	Σ	7					
8	Т	Y	Φ	8					
9	Х	Ψ	Ω	9					
0	(Space)	•	,	ı	:	;	0		
*	/	+	_	=	<	>	*		
#	\$	%	&	@	()	€	£	#


Table 2 (Option mode for RU model)

Times Buttons	1	2	3	4	5	6	7	8	9	10	11
1	A	Б	В	!	?	"	1				
2	Γ	Д	Е	Ë	2						
3	Ж	3	И	Й	3						
4	K	Л	M	4							
5	Н	О	П	5							
6	P	С	Т	6							
7	У	Ф	X	7							
8	Ц	Ч	Ш	8							
9	Щ	Ъ	Ы	Ь	9						
0	Э	Ю	Я	(Space)	•	,	,	:	;	0	
*	/	+	_	=	<	>	L,	€	I	Ϊ	*
#	\$	olo	&	@	()	€	I	ў	#	

1.14.3 Accessing System Features (System Feature Access)

You can access a feature with the "Feature Access" menu.

To access "Feature Access" menu and select the feature



Features	Refer to
Automatic Callback Busy Cancel	1.2.4 When the Dialled Line is Busy or There is No Answer
Group Call Pickup	1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)
Directed Call Pickup	1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)


Features	Refer to
Paging	1.7.1 Paging
Doorphone Call	1.11.1 If a Doorphone/Door Opener is Connected
Door Open	1.11.1 If a Doorphone/Door Opener is Connected
External Relay	1.11.2 If an External Relay is Connected
External Background Music	2.1.4 Turning on the External Background Music (BGM)

1.14.4 Self Labelling (KX-NT366/KX-NT553/KX-NT556/KX-NT560 only)

The KX-NT366/KX-NT553/KX-NT556/KX-NT560 IP-PT have flexible buttons with an LCD screen next to the buttons.

For KX-NT366:

The KX-NT366 IP-PT has 12 flexible buttons, and the telephone's display shows which feature, telephone number, or extension number is assigned to each button. You can press the NEXT PAGE key to display 3 other sets (pages) of 12 flexible button assignments. A different feature, telephone number, or extension number can be assigned to each button in each set. This means that 48 flexible buttons are available.




For KX-NT553/KX-NT556:

The KX-NT553/KX-NT556 IP-PT has 12 flexible buttons, and the telephone's display shows which feature, telephone number, or extension number is assigned to each button. You can press the NEXT PAGE key to display other sets (pages) of 12 flexible button assignments as below.

	Pages	Total Flexible Buttons
KX-NT553	2	24
KX-NT556	3	36


Example: KX-NT556



For KX-NT560:

The KX-NT560 IP-PT has 8 flexible buttons, and the telephone's display shows which feature, telephone number, or extension number is assigned to each button. You can press the Page key to display 3 other sets

(pages) of 8 flexible button assignments. A different feature, telephone number, or extension number can be assigned to each button in each set. This means that 32 flexible buttons are available.



To switch display





For KX-NT366/KX-NT553/KX-NT556/KX-NT560 users:

- When you answer an incoming call or when you seize an outside line, the display automatically changes to the page that contains the green lit button.
- After customising each button, you can set the displayed text for the button. For details about customising buttons, refer to "3.1.3 Customising the Buttons".

1.15 Cellular Phone Features

1.15.1 Cellular Phone Features

When you are not at your desk or not in the office and receive a forwarded outside call on your cellular phone, you can use the following features if enabled through system programming.


- Transferring to an Extension in the PBX
- Transferring to a Private Network (TIE Line Access)
- Transferring to an Outside Phone Number
- Adding Other Parties during a Conversation (Conference)
- Talking to Two Parties Alternately (Call Splitting)
- Paging and then Transferring a Call



 Some features may not be available for cellular phones, depending on the type of outside line being used.

♦♦ Transferring to an Extension in the PBX

To transfer






- When transferring a call from an analogue trunk, you cannot talk to the destination party after dialling an extension number.
- You cannot transfer a call to a DISA floating extension number.
- This feature is only available from a cellular phone associated with the user container.

♦♦ Transferring to a Private Network (TIE Line Access)

During a conversation, you can make a call to an extension connected to another PBX in a private network and transfer a call to it.

To transfer






- * When transferring a call from an analogue trunk, you cannot talk to the destination party after dialling an extension number or 7 + private phone number.
- This feature is only available from a cellular phone associated with the user container.

Transferring to an Outside Phone Number

During a conversation, you can make a call to an outside phone number and transfer a call to it.

To transfer







- When transferring a call from an analogue trunk, you cannot talk to the destination party after dialling the outside phone number.
- This feature is only available from a cellular phone associated with the user container.

Adding Other Parties during a Conversation (Conference)


To establish a conference call



♦ Talking to Two Parties Alternately (Call Splitting)



♦ Paging and then Transferring a Call



Section 2 Manager Operation

This section shows the manager how to control the other extensions or the PBX.

2.1 Control Features

2.1.1 Extension Control


The manager extension can control the settings of other extensions.

Changing the Settings of Other Extensions

Changing the Settings of Other Extensions

To lock/unlock other extensions (Remote Extension Dial Lock)

This feature is also known as Remote Station Lock Control.





• The manager can use Remote Extension Dial Lock to unlock any extension, whether that extension was locked remotely (Remote Extension Dial Lock) or from the extension itself (Extension Dial Lock).

2.1.2 Time Service Mode Control


The manager extension or the preprogrammed extension can change the time mode (Day, Lunch, Break or Night).


There are two methods (Automatic or Manual) of changing the time modes.

Automatic: enables the time mode for each day of the week to change automatically. You may also change it manually.


Manual: enables to change a mode manually as follows.

To change the time mode (Day/Night/Lunch/Break)





To select the time service switching mode (Automatic/Manual)





- Besides the time mode, there is Holiday mode. It can change mode once on a specified date.
- The Time Service (Day/Night/Lunch/Break) button light shows the current status as follows:

Off: Day mode

Green on: Lunch mode **Flashing green:** Break mode

Red on: Night mode

Flashing red: Holiday mode

• The Time Service Switching Mode (Automatic/Manual) button light shows the current status

as follows:

Off: Automatic

Red on: Manual




Customising Your Phone

3.1.3 Customising the Buttons Create or edit a Time Service (Day/Night/Lunch/Break) button or a Time Service Switching Mode (Automatic/Manual) button.

2.1.3 Restriction Level Control (Dial Tone Transfer)

The manager extension can change the restriction level, permitting an extension to make a call.







- The restriction level is changed to the preprogrammed level of Toll Restriction/Call Barring button.
- The restriction level of SIP phones cannot be changed.




Customising Your Phone

3.1.3 Customising the Buttons
 Create or edit a Toll Restriction/Call Barring button.

2.1.4 Turning on the External Background Music (BGM)

The manager extension can select and broadcast background music in the office through external speakers.

To select and start/stop the background music



Multi-Connection Network

In a Multi-Connection network, pagers are numbered sequentially based on the site number and the pager's port.

External pager numbers are assigned by the system administrator. For details, consult your system administrator.

Note

The KX-NSX1000/KX-NSX2000 is not equipped with an external paging port. Therefore, this feature is available only when an expansion gateway with an external paging port is connected to the KX-NSX1000/KX-NSX2000.

2.1.5 Recording Outgoing Messages (OGM)

The manager extension can record three kinds of greeting messages (OGM) as follows:


1. DISA message: Used to greet and guide callers so that they access an extension user group or outside party without operator assistance.




- 2. Incoming Call Distribution Group message: Used to greet and guide callers to an incoming call distribution group.
- **3. Timed Reminder message**: Used for a wake-up call message when the extension answers the Timed Reminder.

All messages have their own extension numbers. You can select the desired message. If your PBX is connected to other PBX(s) in a network, please specify the site ID for recording. If no site ID is specified, the OGM of the site accommodated by the operated extension will be selected for operation.


To record




To play back



To record from an external BGM (MOH) port



To clear the message






 The default of OGM floating extension numbers depends on system programming. For more information, consult your System Administrator or System Manager.

2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)

When a problem is found on a certain outside line, the PBX automatically makes it unavailable for use temporarily. The manager can manually enable the outside line and allow users to use it again.

To re-enable an outside line





• In some countries/areas, the PBX may not be able to automatically make a faulty outside line unavailable for use.

2.2 Configuring Unified Messaging Features

2.2.1 System Manager Features

The System Manager can configure mailboxes, change class of service (COS) settings for subscribers, etc.

- Logging in to the System Manager's Mailbox
- Setting Up Mailboxes
- Setting Class of Service (COS) Parameters
- Remote Time Service Mode Setting
- Changing the Company Greeting and Incoming Call Service Setting
- Broadcasting Messages
- Changing the System Manager's Password

♦♦ Logging in to the System Manager's Mailbox

The procedures described in this section require the System Manager to use a telephone, however, many of these procedures can also be performed using a PC with Web Maintenance Console. For more information, consult your dealer.

In order to perform these procedures with a telephone, the System Manager must log in before performing any System Manager tasks. To log in as the System Manager, 3 items of information must be known: the UM group's floating extension number to access the Unified Messaging system, the System Manager's mailbox number, and the System Manager's mailbox password.

- The System Manager's mailbox number is 999 (default) depending on the mailbox number length specified in system programming.
- The System Manager's password can be assigned by the System Administrator using Web Maintenance Console or by the System Manager using his or her extension telephone (refer to " Changing the System Manager's Password").




- Before the System Manager can perform any System Manager tasks, "System Manager Access from Telephone" must be enabled and "Password for System Manager (Up to 16 numeric digits)" must be set by the System Administrator using Web Maintenance Console.
- After logging in, the system will announce the number of total messages, the number of new messages, or the length of new messages. These announcements depend on the mailbox settings and COS settings for the System Manager.
- If there are new messages in the mailbox, the messages will be played automatically. The System Manager can listen to them continuously without listening to the system prompts. This feature is only available when "Autoplay New Message" is activated for the System Manager's COS.
- If the Unified Messaging system is being programmed via Web Maintenance Console, the System Manager cannot create or edit mailboxes. The system will announce, "Sorry, this function is not available".




- · For more information on logging in, refer to "Logging in to Your Mailbox for the First Time".
- Manager Service switching
 You can switch mailboxes simply by pressing ## from the subscriber service menu, in the
 following order:

→ Subscriber service → Message Manager service → System Manager service —

Manual log-in



Remote automatic log-in





CAUTION

- It is strongly recommended that a password of 16 numbers be used for maximum protection against unauthorised access.
- To avoid unauthorised access to the PBX, keep the password secret. If it becomes known to others, the PBX may be misused.
- · Change the password periodically.

Notice

 When disabling the password requirement, ensure that an unauthorised third-party is not allowed access to your extension.

Setting Up Mailboxes

The System Manager's primary function is to create mailboxes for new subscribers and to maintain system organisation by deleting unneeded passwords and mailboxes.



 If the Unified Messaging system is being programmed via Web Maintenance Console, the System Manager cannot create or edit mailboxes. The system will announce, "Sorry, this function is not available".

Creating and Editing a Mailbox

The System Manager can create and edit subscriber mailboxes by following the steps below. When creating a new mailbox, or editing a mailbox's parameters, the following parameters can be set:

- Mailbox Number
- Subscriber's Name:

The system allows a maximum of 10 seconds for each name. The name should be spoken slowly and clearly. (We recommend using the subscriber's last name.)

- Extension Number
- First 4 Letters of the Subscriber's Last Name:

Enter only the first 4 letters of the owner's last name.

• First 4 Letters of the Subscriber's First Name:

Enter only the first 4 letters of the subscriber's first name.

· Class of Service Number:

Enter any COS number (1-62).

Interview Mailbox Number:

Interview Mailbox Numbers must not be the same number as an existing mailbox.

• All Calls Transfer To Mailbox (Change Logical Extension Status):

If this parameter is enabled, the extension is considered to be a Logical Extension and therefore calls directed to the extension via Automated Attendant service are automatically forwarded to the extension mailbox. The extension does not ring when a call is received.

· Message Waiting Lamp Notification:

If this parameter is enabled, the Message Waiting Lamp of the subscriber's telephone turns on when a new message is recorded.


· External Message Delivery:

Allows a subscriber to send a message to several subscribers and non-subscribers (including outside parties). If enabled, the prompt mode setting determines the language heard when the system calls the recipient.

Auto Forwarding:

Moves or copies unplayed messages from one mailbox to another, after a specified period of time.

To create/edit/delete any mailbox parameter



Parameters	Steps
Subscriber's Name	1. 1 to change the current setting.
	2. Record the subscriber's name.
	3. 2 to accept.
Extension Number	1. 1 to change the current setting.
	2. Enter the subscriber's extension number.
	3. 2 to accept.
First 4 Letters of the Subscriber's Last Name	1. 1 to change the current setting.
Subscriber 5 Last Name	2. Enter the first 4 letters of subscriber's last name.
	3. 2 to accept.
First 4 Letters of the Subscriber's First Name	1. 1 to change the current setting.
Subscriber's First Name	2. Enter the first 4 letters of subscriber's first name.
	3. 2 to accept.
Class of Service Number	1. 1 to change the current setting.
	2. Enter the Class of Service Number (1–62).
	3. 2 to accept.
Interview Mailbox Number	1. 1 to change the current setting.
	2. Enter the Interview Mailbox Number.
	3. 2 to accept.
All Calls Transfer To Mailbox (Change Logical Extension	1. 1 to change the current setting (enable or disable).
Status)	2. 2 to accept.

Parameters	Steps
Message Waiting Lamp Notification	1. 1 to change the current setting (enable or disable).
Notification	2. 2 to accept.
Device Notification for Unreceived Messages	1. 1 to change the current setting (enable or disable).
Omeceived messages	2. 2 to accept.
External Message Delivery	1. 1 to change the current setting (enable or disable).
	If set to "Enable", go to "Prompt Mode".
	2. 2 to accept.
Prompt Mode	1. 1 for Primary.
	2 for System.
	3 for Caller Select.
	 For System, enter the system prompt number (1–8).
	2. 4 to accept the current setting, then go to "External Message Delivery".
Auto Forwarding	1. 1 to change the current setting (enable or disable).
	If set to "Disable": The Auto Forwarding parameter is the last parameter to be entered. To continue assigning or editing other mailboxes, go back to STEP B. To finish, enter (M) (M)
	To finish, enter * .
	2. 2 to accept.
Forwarding Mailbox Number	1. 1 to change the current setting.
	2. Enter the forwarding mailbox number.
	3. 2 to accept.
Forwarding Delay Time	1. 1 to change the current setting.
	2. Enter the delay time, and # .
	3. 2 to accept.
Forwarding Mode	1. 1 to change the current setting (Copy or Move).
	2. 2 to accept, then go to "Auto Forwarding".

To delete a mailbox

The System Manager should delete mailboxes that are no longer needed. When another person accesses the Unified Messaging system, the action is automatically cancelled.

- Log in to the System Manager's mailbox.
 5 1 2
- 3. Enter the mailbox number.
- **4. 1** to delete the mailbox.



- The System Manager password cannot be reset here. The System Administrator can reset the System Manager password using Web Maintenance Console.
- After the password is reset, if the System Administrator has set "Default Password for New Mailboxes" to "Enable", the password will be set to the default password. If set to "Disable", the mailbox will have no password.

♦♦ Setting Class of Service (COS) Parameters


A Class of Service (COS) defines the set of system services available to the mailboxes assigned to it. There are 514 Classes of Service; the Class of Service number is automatically assigned to the mailbox when configured in the User Container. COS numbers 1 to 512 are assigned to general users. COS No. 513 and No. 514 are assigned by default to the Message Manager and the System Manager respectively.



 If the Unified Messaging system is being programmed via Web Maintenance Console, the System Manager cannot set COS parameters. The system will announce, "Sorry, this function is not available".

To set COS parameters

Follow the steps detailed below to set the following Class of Service parameters:



Parameters	Steps
Personal Greeting Length ^{*1}	1. 1 to change the greeting length.
	to accept the current setting, then go to the next parameter.
	2. Enter the greeting length (1–360 s).
	3. 2 to accept.
New Message Retention Time	1. 1 to change the retention time.
Time	2 to accept the current setting, then go to the next parameter.
	2. Enter the retention time (a maximum of 30 days or 0: Unlimited).
	3. 2 to accept.

Parameters	Steps
Saved Message Retention Time	1. 1 to change the retention time.
Time	2 to accept the current setting, then go to the next parameter.
	2. Enter the retention time (a maximum of 30 days or 0: Unlimited).
	3. 2 to accept.
Message Length	1. 1 to change the message length.
	2 to accept the current setting, then go to the next parameter.
	2. Enter the message length (1–60 min or 0: Unlimited).
	3. 2 to accept.
Total Message Time Available per Mailbox	1. 1 to change the total message time.
Available per mailbox	2 to accept the current setting, then go to the next parameter.
	2. Enter the total message time (1–600 min or 0: Unlimited).
	3. 2 to accept.
Message Retrieval Order	1. 1 to change the current setting (LIFO [Last In First Out] or
	FIFO [First In First Out]).
	2 to accept the current setting, then go to the next parameter.
	2. 2 to accept.
Prompt Mode	1. 1 for Primary.
	2 for System.
	 For System, enter system prompt number (1–8).
	2. 3 to accept.
Delete Message	1. 1 to change the current setting (enable or disable).
Confirmation	2. 2 to accept.
Message Envelope Playback	1. 1 for Before.
Mode	2 for After.
	3 for Require.
	4 to accept the current setting, then go to the next parameter.
	2. 4 to accept.
Caller ID Callback	1. 1 to change the current setting (enable or disable).
	2. 2 to accept.
4	

Play System Prompt after Personal Greeting 1. 1 to change the current setting (enable or disable). 2. 2 to accept. Use Call Waiting on Busy 1 1. 1 to change the current setting (enable or disable). 2. 2 to accept.	
2. 2 to accept. Use Call Waiting on Busy 1 1. 1 to change the current setting (enable or disable).	
to driange the danging (chasis of disasis).	
2 (3) to accent	
2. 2 to accept.	
Message Cancel for Live Call Screening ¹¹ 1. 1 to change the current setting (enable or disable).	
2. 2 to accept.	
Intercom Paging Group ¹¹ 1. 1 to change the paging group.	
2 to accept the current setting, then go to the next para	meter.
2. Enter the group number (1–33).	
3. 2 to accept.	
Maximum Number of Caller 1. 1 to change the current setting.	
IDs for Caller Name Announcement to accept the current setting, then go to the next para	meter.
2. Enter the number of announcements that can be programme subscribers (1–30/0: None).	d by
3. 2 to accept.	
Mailbox Capacity Warning 1. 1 to change the current setting.	
2 to accept the current setting, then go to the next para	meter.
2. Enter the warning threshold (1–60 min or 0: None).	
3. 2 to accept.	
Personal Greeting for Caller 1. 1 to change the current setting (enable or disable).	
2. 2 to accept.	
Caller ID Screen 1 1. 1 to change the current setting (enable or disable).	
2. 2 to accept.	
Call Transfer to Outside 1. 1 to change the current setting (enable or disable).	
2. 2 to accept.	
Subscriber Tutorial ⁻¹ 1. 1 for Normal Mode.	
2 for Simplified Mode.	
3 to disable.	

Parameters	Steps
Notify of Transfer	1. 1 to change the current setting (enable or disable).
	2. 2 to accept.
Directory Listing [™]	1. 1 to change the current setting (enable or disable).
	2. 2 to accept.
Auto Receipt	1. 1 to change the current setting (enable or disable).
	2. 2 to accept.
Autoplay New Message	1. 1 to change the current setting (enable or disable).
	2. 2 to accept.
First Playback Urgent Messages	1. 1 to change the current setting (enable or disable).
Messages	2. 2 to accept.
Announce Message Transferred Information	1. 1 to change the current setting (enable or disable).
	2. 2 to accept.
Caller ID Announcement	1. 1 to change the current setting (enable or disable).
	2. 2 to accept.
Announce Option Menu After Erasing Messages	1. 1 to change the current setting (enable or disable).
Tito. Liuonig moodagoo	2. 2 to accept.
New Message Length Announcement	1. 1 to change the current setting (enable or disable).
Amountoment	2. 2 to accept.

Remote Time Service Mode Setting

You can set the time service mode from an outside telephone even when you are away from the office.

To set the time service mode

- 1. Log in to the System Manager's mailbox.
- 2. 1 to change.
- 3. Select the desired Time Service mode entry.
 - 1 to set Day mode.
 - **2** to set Night mode.
 - **3** to set Lunch mode.
 - **4** to set Break mode.

♦ Changing the Company Greeting and Incoming Call Service Setting

When the Unified Messaging system answers calls, it greets the callers with a Company Greeting and then activates an Incoming Call Service. The System Manager or System Administrator can choose:

- The appropriate company greeting for each time mode (Day, Night, Lunch, and Break) of each call service. The default company greeting is Company Greeting 1. If the Company Greeting 1 is not recorded, nothing will not be played.
- The desired Incoming Call Service for each time mode of each call service. The default service is Custom Service 1 for Day/Lunch/Break mode, and Custom Service 2 for Night mode. If the Custom Service is not recorded, Automated Attendant service will be played.
- The assignment of the Service Group for each Unified Messaging extension number/Trunk.



 If the Unified Messaging system is being programmed via Web Maintenance Console, the System Manager cannot change the Company Greeting and Incoming Call Service Setting. The system will announce, "Sorry, this function is not available".

То	change the service group setting
1.	Log in to the System Manager's mailbox.
	a. 5 3
	b. 2 to change the Service Group setting.
2.	Enter the Service Group Number (1–64).
3.	Select the desired Time Service period entry. 1 for Day Time service.
	2 for Night Time service.
	3 for Lunch Time service.
	4 for Break Time service.
4.	1 to change the Company Greeting.
	2 to change the Incoming Call Service, then go to step 5.b.
	a. 1 to change the setting.
	2 to accept.
5.	Select the desired setting entry.
	1 to change a Company Greeting number.
	2 to set the System Greeting, then go to step 8.
	3 to disable, then go to step 8.
	a. Enter a Company Greeting number (1–32), then go to step 8.
	b. 1 to change the setting.
	2 to accept.
6.	Select the desired setting entry.
	1 to set Voice Mail Service, then go to step 8.
	2 to set Automated Attendant Service, then go to step 8.

2.2.1 System Manager Features

3 to set Custom Service.
4 to set Interview Service.
5 to set Fax Service.
6 to set Transfer to Mailbox.
7. Enter the Custom Service number (1–200), or the Mailbox number.
8. 2 to accept.
To change the service group assignment
1. Log in to the System Manager's mailbox.
2. 5 3
3. 1 to change the Service Group Assignment.
4. Enter the Unified Messaging extension number.
5. 1 to change the service group, then go to step 6.
2 to accept.
6. Enter the Service Group Number (1–64).
7. 2 to accept.
♣ Broadcasting Messages
The System Manager can deliver a message to multiple subscribers with one operation. Messages can be sent to all subscribers (Broadcasting Message feature) or to specified subscribers only. When delivering a message to specified subscribers, the System Manager can receive verification when the recipients listen to the message.
• The System Manager can set the date and time when a message is delivered. The date can be set up to one month in advance.
To deliver messages to all mailboxes (Broadcasting Messages)
The Broadcasting Messages feature allows the System Manager to deliver a message to multiple subscribers with one operation. Broadcast messages have priority over other regular or urgent messages, but otherwise are treated like regular messages. This feature is useful when informing subscribers about the current system status such as remaining capacity, requesting that unnecessary messages be erased, etc.
1. Log in to the System Manager's mailbox.
2. 2
3. 1 to record a broadcast message.
4. 1 to end recording.
5. 2 to accept.

To deliver messages to specified mailboxes

Use this feature to deliver the same message to one or more subscribers by specifying their mailbox numbers.

1.	Log in to the System Manager's mailbox.
	a. 2 2
2.	Enter the mailbox number of the intended recipient.
	• Enter by name by pressing # 1 first. Use a Mailbox Group by specifying its number.
	a. 2 to accept.
	b. 1 to record a message.
	 Enter 2 to add mailbox numbers. Enter 3 to review the mailing list. Enter ** to cancel message transfer.
	c. 1 to end recording.
	d. 2 to accept.
3.	1 to specify the delivery time.
	• Enter 1 2 to send the message immediately, then go to step 4.
	a. Enter the desired delivery time, then # .
	b. 1 for AM.
	2 for PM.
	 This option may not be available if the system is programmed to use 24-hour time.
	c. Enter the day of the month for delivery, then # . Example:
	 If today is February 16 and you enter 1 7 # , the message will be delivered tomorrow.
	• If today is February 16 and you enter 5 # , the message will be delivered on March 5.
	d. 2 to accept.
4.	1 to make the message urgent.
	2 to continue.
5.	1 to make the message private.
	2 to continue.

♦♦ Changing the System Manager's Password

The System Manager must enter the System Manager password in order to log in before performing any System Manager tasks. In order to ensure system security, we recommend selecting a long (max. 16 digits) password that cannot be easily guessed.



 If the Unified Messaging system is being programmed via Web Maintenance Console, the System Manager cannot change the System Manager password. The system will announce, "Sorry, this function is not available".

To change the System Manager's password

- 1. Log in to the System Manager's mailbox.
- 2. 3
- **3.** 1 to change the mailbox password.
 - **2** to accept the current setting.
- **4.** Enter the desired password, then # .
- 5. 2 to accept.

2.2.2 Message Manager Features

The Message Manager can maintain the general delivery mailbox, change notification settings, record/delete prompts, etc.

- Logging in to the Message Manager's Mailbox
- Managing the General Delivery Mailbox
- Setting Up Message Waiting Notification
- Customising the Message Manager's Mailbox
- Recording Messages
- Remote Call Forwarding Set
- Setting the Timed Reminder
- Day/Night Recording Menu
- Recording an Emergency Greeting
- List of Prompts for VM and AA Service

Logging in to the Message Manager's Mailbox

The procedures described in this section require the Message Manager to use a telephone, however, many of these procedures can also be performed using a PC with Web Maintenance Console. For more information, consult your dealer.

In order to perform these procedures with a telephone, the Message Manager must log in before performing any Message Manager tasks. To log in as the Message Manager, 3 items of information must be known: the UM group's floating extension number to access the Unified Messaging system, the Message Manager's mailbox number, and the Message Manager's mailbox password.

- The Message Manager's mailbox number is 998 (default) depending on the mailbox number length specified in system programming.
- The Message Manager's password can be assigned by the System Administrator using Web
 Maintenance Console or by the Message Manager using his or her extension telephone (refer to "

 Customising the Message Manager's Mailbox").




- Before the Message Manager can perform Message Management (recording Custom Service Menus, messages, etc.), "Message Manager Access from Telephone" must be enabled and "Password for Message Manager (Up to 16 numeric digits)" must be set by the System Administrator using Web Maintenance Console.
- After logging in, the system will announce the number of total messages, the number of new messages, or the length of new messages. These announcements depend on the mailbox settings and COS settings for the Message Manager.
- If there are new messages in the mailbox, the messages will be played automatically. The
 Message Manager can listen to them continuously without listening to the system prompts.
 This feature is only available when "Autoplay New Message" is activated for the Message
 Manager's COS.




- For more information on logging in, refer to " Logging in to Your Mailbox".
- Manager Service switching You can switch mailboxes simply by pressing ## from the subscriber service menu, in the following order:

→ Subscriber service → Message Manager service → System Manager service –

Manual log-in




Automatic log-in





• This feature may be disabled by the System Administrator for your mailbox.

Remote automatic log-in





CAUTION

- It is strongly recommended that a password of 16 numbers be used for maximum protection against unauthorised access.
- To avoid unauthorised access to the PBX, keep the password secret. If it becomes known to others, the PBX may be misused.
- · Change the password periodically.

Notice

• When disabling the password requirement, ensure that an unauthorised third-party is not allowed access to your extension.

♦ Managing the General Delivery Mailbox

One of the Message Manager's functions is to check the General Delivery Mailbox for messages and transfer them to the appropriate mailbox or mailboxes (Mailbox Groups may be used). This can be done at any time using the telephone.

To listen to messages

The Message Manager can monitor the status of the General Delivery Mailbox through his or her mailbox. He or she can listen to the messages stored in the General Delivery Mailbox and, if necessary, transfer them to their intended recipients.

1.	Log in to the Message Manager's mailbox.
2.	1 to receive the message.
3.	Enter the desired number.
	1 to listen to new messages.
	2 to listen to old messages.
	3 to listen to deleted messages.
4.	Enter the desired number.
	1 to listen to voice messages.
	2 to listen to fax message envelopes.
	# to listen to all messages.
5.	The system plays each message, identifying the sender and indicating when the message was recorded.
	1 to repeat this message.
	1 to replay the previous message.
	2 to play the next message.
	3 to delete this new/old message or recover this deleted message.
	4 to reply to this new/old message.
	5 to transfer this new/old message.
	6 to listen to the message envelope.
	• System programming determines if the message envelope is played before each message, after each message, or only when you press 6 .
	7 to rewind a voice message during playback, or print a new/old fax message after listening to a
	fax message envelope.
	8 to pause or restart the message during playback.
	8 4 to increase playback volume during playback.
	8 to set a Bookmark for the voice message during voice message playback.
	8 6 to start playback at the Bookmark for the voice message.
	to fast-forward during playback.
	# to save as new (when the new message is listened).
	1 to listen to the entire menu

To transfer messages

Messages left in the General Delivery Mailbox should be transferred to their intended recipients on a regular basis. The Message Manager can add his or her own voice comments when necessary. When a message is transferred, the original message is not deleted from the General Delivery Mailbox; it must be deleted manually.

 Start with step 1–5 in "To listen to messages" above. while listening to the message to transfer.
2. Enter the destination mailbox number.
3. 2 to accept.
4. 2 to record a comment.
 Enter 1 to transfer messages without comment. Enter 3 to add a mailbox number. Enter 4 to review the Mailing List.
5. 1 to end recording.
6. 2 to accept.
Setting Up Message Waiting Notification
The Unified Messaging system can notify the Message Manager when unplayed messages are waiting in his or her mailbox by turning on the message waiting lamp and/or calling an external device (i.e., telephone). The Unified Messaging system can also send notification via e-mail if the System Administrator has enabled
this feature.
To set notification by Message Waiting Lamp
The system lights the message waiting lamp on the Message Manager's extension when a new message is recorded in the Message Manager's mailbox.
 Extensions assigned as operators can be called by dialling "9/0 (default)". However, when setting this feature the extension number (not "9/0 [default]") must be specified. For more information, consult your System Administrator.
 When a 6-line display PT is used, the number of new (unplayed) messages will be displayed while the message waiting lamp is lit. If the telephone has a Message button, the Message light will also turn on when you receive a new message.
1. Log in to the Message Manager's mailbox.

Setting Notification by External Device

1 to change the Message Waiting Lamp Notification Status.

The system calls the preprogrammed telephone number when a new message is recorded in the Message Manager's mailbox. Set the following parameters as needed..

To assign notification numbers

A maximum of 3 telephone numbers can be set for message notification. It is also possible to have the caller select whether or not he or she wishes to enter a callback number.

- 1. Log in to the Message Manager's mailbox.
- 2. 2

2. 2

to change.
 to accept.

4.	
	Enter the desired number.
	1 to change the first telephone number.
	2 to change the second telephone number.
	3 to change the third telephone number.
5.	1 to change.
6.	Dial the telephone number.
7.	2 to accept.
8.	1 to change the telephone number.
	2 to accept.
	3 to review.
	4 to add more digits.
	5 to insert a pause.
	6 to insert a wait for dial tone.
TΛ	set device status
Fo Ma	r each device, the notification is enabled or disabled according to a preset schedule. The Message anager can enable a device according to a schedule. However, the System Administrator must first assign destination number to the desired device.
Fo Ma a d	r each device, the notification is enabled or disabled according to a preset schedule. The Message anager can <i>enable</i> a device according to a schedule. However, the System Administrator must first assign
Fo Ma a d	r each device, the notification is enabled or disabled according to a preset schedule. The Message anager can enable a device according to a schedule. However, the System Administrator must first assign destination number to the desired device.
For Ma a d d d d d d d d d d d d d d d d d	r each device, the notification is enabled or disabled according to a preset schedule. The Message anager can <i>enable</i> a device according to a schedule. However, the System Administrator must first assign destination number to the desired device. Log in to the Message Manager's mailbox.
For Ma a d d d d d d d d d d d d d d d d d	r each device, the notification is enabled or disabled according to a preset schedule. The Message anager can <i>enable</i> a device according to a schedule. However, the System Administrator must first assign destination number to the desired device. Log in to the Message Manager's mailbox.
For Ma a d d d d d d d d d d d d d d d d d	r each device, the notification is enabled or disabled according to a preset schedule. The Message anager can <i>enable</i> a device according to a schedule. However, the System Administrator must first assign destination number to the desired device. Log in to the Message Manager's mailbox. 2 2 Enter the device number (1–6). • Device number 4, 5, or 6 is used to specify a device number that is "Device No. 1, 2, or 3" for "E-mail/
For Ma a d d 1. 2. 3.	r each device, the notification is enabled or disabled according to a preset schedule. The Message anager can <i>enable</i> a device according to a schedule. However, the System Administrator must first assign destination number to the desired device. Log in to the Message Manager's mailbox. 2 2 Enter the device number (1–6). • Device number 4, 5, or 6 is used to specify a device number that is "Device No. 1, 2, or 3" for "E-mail/ Text Message Device" in Web Maintenance Console. • If a telephone number has not been assigned to the selected device number 1, 2, or 3, you cannot set

Customising the Message Manager's Mailbox

The Message Manager can customise the Message Manager's mailbox by changing the following parameters.

- The Message Manager's mailbox password

- The extension numbers of Operator 1, 2, and 3
- Telephone numbers 1 and 2 used for call forwarding destinations when Remote Call Forwarding is set to an outside line
- Automatic Delivery Status and Default Fax Number, used to immediately print faxes to a specified fax machine as soon as they are received in your mailbox.



 If the Unified Messaging system is being programmed via Web Maintenance Console, the Message Manager cannot customise his or her mailbox. The system will announce, "Sorry, this function is not available".

Message Manager's Password:

The Message Manager must enter the Message Manager password in order to log in before performing any Message Manager tasks. In order to ensure system security, we recommend selecting a long (max. 16 digits) password that cannot be easily guessed.

Operator's Extensions:

When callers require help, they can dial the operator call number to be transferred to an operator. A maximum of 3 operators can be programmed for each time mode; these operators are not necessarily the same as the operator extensions programmed for the PBX. The extension assigned as Operator 1 for the day mode is designated as the Message Manager.

• Telephone Numbers 1 and 2 for Remote Call Forward to Outside:

After programming/changing the telephone numbers used for Remote Call Forward to Outside, the Message Manager must reset the remote call forwarding setting (refer to " Remote Call Forwarding Set"), even if it was already enabled. Telephone numbers set here will not be effective until remote call forwarding is reset. If you do not reset remote call forwarding, calls will be forwarded to the old telephone numbers.

Default Fax Number:

To clear the default fax number, ask your System Administrator to clear it using Web Maintenance Console.

To customise the message manager's mailbox

1.	Log in to the Message Manager's mailbox.
	a. 3
	b. 1 to change the password.
	2 to accept.
	c. Enter the password, then #.
	d. 2 to accept.
2.	Enter the desired number.
	1 to change or assign the operator's extension.
	2 to accept.
	3 to delete, then go to step 3.
	Operator 1's extension number cannot be deleted.
	a. Dial the extension number.
	b. 2 to accept.

3.	Repeat steps 6–8 to assign or to delete the extension number for the Day, Night, Lunch and Break Modes for each operator.
	 a. Enter the desired number. 1 to change or assign the telephone number 1 setting. 2 to accept the current setting, then go to step 4.
	 b. Dial the telephone number (0 - 9 ,
	outside line). c. 2 to accept.
4.	 Enter the desired number. 1 to change or assign the telephone number 2 setting. 2 to accept the current setting.
	a. Dial the telephone number (0 – 9 , x [max. 32 digits]).
	b. 2 to accept.
5.	Enter the desired number. 1 to change automatic delivery status. 2 to accept the current setting.
6.	Enter the desired number.1 to change the default fax number.2 to accept the current setting.
	a. Dial the fax number ($\boxed{0}$ – $\boxed{9}$, $\boxed{\mathbf{*}}$, $\boxed{\mathbf{#}}$ [max. 32 digits]).
	b. 2 to accept.
F	Recording Messages

The Message Manager is responsible for recording various system messages (menus, voice labels, system prompts, and system caller names) and is also responsible for maintaining the following:

· Company Greetings:

A maximum of 32 company greetings for business/non-business and lunch/break hours as well as holidays can be selected, recorded, or deleted as necessary.

· Company Name

Custom Service Menus:

A maximum of 200 custom service menus can be recorded. These menus guide callers to the services they require without the need for a human operator.

A maximum of 20 Mailbox Groups can be created by the System Administrator. Each list can have a voice label.

System Prompts:

The Message Manager can change system prompts by recording new prompts and restoring them.

• Multilingual Selection Menu:

With this menu, callers can select the language they prefer for voice guidance. For example, the Message Manager can record a menu that announces:

"For English, press 7."

"For French, press 8."

• The System Caller Names:

A maximum of 200 Caller ID numbers can be registered by the System Administrator. The Message Manager is responsible for recording a name for each Caller ID number.

• On Hold Announcement Menu:

With this menu, callers in a queue can listen to the announcement or music while they are on hold.



• If the Unified Messaging system is being programmed via Web Maintenance Console, the Message Manager cannot record any messages. The system will announce, "Sorry, this function is not available".

То	record menus and voice labels
1.	Log in to the Message Manager's mailbox.
2.	4 to record messages.
3.	Enter the desired number to record. 1 for Company Greetings. 2 for Company Name. 3 for Custom Service Menus. 4 for Voice Labels for Mailbox Groups. 5 for System Prompts. 6 for Multilingual Selection Menu.
	7 for System Caller Names. 8 for On Hold Announcement Menu.
4.	For the item selected in step 3, follow these steps:
	a. For Company Greetings: Enter the Company Greeting Number (1–32).
	b. For the Company Name: Go to step 5.
	c. For Custom Service Menus: Enter a Custom Service Number (1–200).
	Enter
	d. For Voice Labels: Enter the number of the Mailbox Group to be labelled. (The System Administrator assigns list numbers.)
	e. For the Multilingual Selection Menu: Go to step 5.
	f. For the On Hold Announcement Menu: Go to step 5.
5.	1 to change the message.
	If a message has not yet been recorded, go to step 7.
6.	1 to record a message.2 to erase the current message, then go to step 3 or 4.
7.	1 to end recording.

9.	Re	peat steps 4–8 to record other Company Greetings, Custom Service Menus, and/or Voice Labels.
То	re	cord system prompts
1.	Log	g in to the Message Manager's mailbox.
2.		5 to record messages.
3.	En	ter the system prompt number you want to change.
4.		change specific prompts, go to step 5. change all prompts one after another without reviewing the current recording, go to step 6.
5.	То	change specific prompts:
	a.	1
	b.	Enter the prompt number you want to change (refer to " List of Prompts for VM and AA Service").
	C.	The system plays the prompt number and its prompt. If a prompt has not yet been recorded, the system plays the system prompt. If a prompt is turned off, "The prompt is now turned off" will play before the prompt.
	d.	1 to record.
	e.	1 to end recording.
	f.	2 to accept.
	g.	Repeat steps 5b to 5f to record other prompts.
6.	То	change all prompts one after another.
	a.	2
	b.	Enter the prompt number you want to change.
	C.	1 to change.
	d.	1 to end recording.
	e.	2 to accept.
	f.	The system plays the next prompt number.
	g.	Repeat steps 6c to 6f to record other prompts.
	ı	• It is possible to restore the original system prompts. Consult your System Administrator about this feature.
Tο	re	cord system caller names

Before recording System Caller Names, the associated telephone numbers must first be programmed using

Web Maintenance Console. For more information, consult your System Administrator.

1. Log in to the Message Manager's mailbox.

2. 4

2 to accept.

Operating Manual 243

3.	7 to modify system caller names.
4.	Enter the Caller ID List Number (1–200).
	Guidance is "Caller Name Announcement number".
	• Enter ** to go to step 3.
5.	1 to change the name.
	• If a name has not yet been recorded for this Caller ID number, go to step 6.
	• Enter 2 to accept or 3 to erase the current name, then go to step 4.
6.	1 to end recording.
7.	2 to accept.
8.	Repeat steps 4–7 to record names for other Caller ID List numbers.
₩ F	Remote Call Forwarding Set
cal	e Message Manager can program his or her extension from a remote location to forward various types of ls to the desired extension or an outside telephone. There are 6 forwarding settings available:
	FWD All: Forwards all incoming calls to a specified extension number.
	FWD Busy: Forwards all incoming calls to a specified extension number when the line is busy.
	FWD No Answer: Forwards all incoming calls to a specified extension number when there is no answer.
	FWD Busy or No Answer: Forwards all incoming calls to a specified extension number when the line is busy or there is no answer.
I	FWD to Outside: Forwards all incoming calls to telephone number 1 or 2 (preprogrammed in the Mailbox Setting), or to any other telephone number.
	FWD Cancel: Cancels the forwarding setting.
4	• This feature is not available when the Message Manager's extension (assigned for Operator 1 in the Day Mode) is "default". In this case, it should be changed to the operator's extension number. For more information, consult your System Administrator.
	 In order to use the FWD to Outside option, the ability to forward calls to trunks must be enabled through system programming.
	 Before setting Remote Call Forwarding to Outside, you should first store up to 2 destination telephone numbers (refer to " Customising the Message Manager's Mailbox").
То	assign Remote Call Forwarding set
1.	Log in to the Message Manager's mailbox.
2.	5
3.	Select the desired forwarding setting. 1 for FWD All.

	2 for FWD Busy.
	3 for FWD No Answer.
	for FWD Busy or No Answer.
	5 for FWD to Outside, then go to step 6.
	6 for FWD Cancel, then go to step 9.
4.	Enter the extension number.
5.	2 to accept the extension number, then go to step 10.
	• Enter 1 to change the extension number, then go to step 4.
6.	Enter the desired number.
	1 for telephone number 1, then go to step 8.
	2 for telephone number 2, then go to step 8.
	3 for another telephone number.
	• Before you can forward your calls to telephone number 1 or 2, you should first store the telephone numbers you plan on using with this feature.
7.	Enter the telephone number (0 - 9 , 🛪). (max. 32 digits)
	 Make sure you begin the telephone number with an outside line access number (to seize an outside line).
8.	2 to accept, then go to step 10.
	• Enter 1 to change the telephone number, then go to step 6.
9.	2 to accept.
10	. The new settings are transmitted to the system. If the setting has been completed properly, you will

• If the system announces, "Call forwarding not accepted. Please check the destination number.", the forwarding setting has not been completed properly, possibly because a



nonexistent extension number has been entered as the destination. For more information, consult your System Administrator.

Setting the Timed Reminder

The Message Manager can set or cancel the Timed Reminder. The telephone will ring at the set time according to the set mode (Once/Daily).

hear: "Call forwarding accepted" or "Call forwarding is cancelled" as appropriate.



- · This feature is not available for PSs.
- This feature is not available when the Message Manager's extension (assigned for Operator 1 in the Day Mode) is "default". In this case, it should be changed to the operator's extension number. For more information, consult your System Administrator.

To set/cancel

- 1. Log in to the Message Manager's mailbox.
- 6
- 3. Enter the desired number.

	1 to change the setting.
	2 to accept, then go on-hook to finish.
	3 to cancel (turn off), then go on-hook to finish.
4.	Enter the desired time, then # .
5.	Enter the desired number.*
	1 for AM.
	2 for PM.
6.	Enter the desired number.
	1 to set once.
	2 to set daily.
7.	2 to accept.
	* This option may not be available if the system is programmed to use 24-hour time. The time format (12 or 24 hour) is determined by the "Position of "AM/PM" in Time Stamp" setting. For more information, consult your System Administrator.
ф <u>Г</u>	Day/Night Recording Menu
ΑI	Day and Night Menu can be recorded as "Custom Service 1–2" directly from the top menu.
To	o record
1.	Log in to the Message Manager's mailbox.
2.	7 for Custom Service 1 Menu (Day).
	8 for Custom Service 2 Menu (Night).
3.	1 to change the message.
4.	1 to record a message.
5.	Record the message.
6.	1 to end recording.
7.	2 to accept.
	• This feature is not available when the "Quick Menu and Greeting Recording" setting is disabled for the Message Manager's mailbox. For more information, consult your System Administrator.



Direct Service Access

If Direct Service Access is set in Mailbox Settings, you can access this feature directly by dialling a specific Unified Messaging extension number from your extension. Automatic login must be enabled to use Direct Service Access (refer to "Automatic log-in"). For details about these Unified Messaging extension numbers, consult your System Administrator.

Recording an Emergency Greeting

An emergency greeting can be recorded as "Company Greeting 1" directly from the top menu. The emergency greeting can be used in times such as when the company must be closed due to bad weather.

To record

- **1.** Log in to the Message Manager's mailbox.
- 2. 9
- **3.** 1 to change the message.
- **4. 1** to record a message.
- **5.** Record the greeting.
- **6. 1** to end recording.
- **7. 2** to accept.



 This feature is not available when the "Quick Menu and Greeting Recording" setting is disabled for the Message Manager's mailbox. For more information, consult your System Administrator.



Direct Service Access

If Direct Service Access is set in Mailbox Settings, you can access this feature directly by dialling a specific Unified Messaging extension number from your extension. Automatic login must be enabled to use Direct Service Access (refer to "Automatic log-in"). For details about these Unified Messaging extension numbers, consult your System Administrator.

♦ List of Prompts for VM and AA Service

There are over 1000 system prompts in the Unified Messaging system. These prompts can be customised by re-recording them to change their content, or can be recorded in various languages. The maximum length of a prompt is fixed at 6 minutes.

When recording prompts in other languages, most often it is not necessary to record all prompts contained in the Unified Messaging system; recording over 1000 system prompts is a big undertaking. When a caller is connected to AA service or VM service, most likely he or she will only hear a small selection of the following prompts. Therefore, it is necessary only to record (or modify) the prompts that callers will hear. Please change prompts to suit the application. For example, prompt no. 1211 could be re-recorded to announce, "Thank you for calling ABCD Travel", instead of "Welcome to the Unified Messaging System". It is possible to record the prompts you wish to modify on your computer in .wav format and upload them to the Unified Messaging system. For more information, consult your System Administrator.

Prompts Common to VM and AA Services

Prompt No.	Modifiable Prompts
363	Good afternoon
364	Good evening
365	Good morning
1211	Welcome to the Unified Messaging System
973	To enter by name, press the hash sign and 1
974	To enter by name, press the pound sign and 1

Prompt No.	Modifiable Prompts
221	Enter the first 3 or 4 letters of the person's last name
326	For 'Q', press 7
327	For 'Z', press 9
693	Sorry, there are no more matching names
701	Sorry, this name cannot be found
392	Incorrect entry
842	To call the operator, press 0
90	Calling the operator
599	Please wait a moment
1201	Welcome to the general delivery mailbox
596	Please leave a message at the tone
966	To end recording, hang up or press 1 for more features
1026	To pause and restart recording, press 2
1060	To review, press 1
818	To accept, press 2
979	To erase and try again, press 3
829	To add, press 4
978	To erase and exit, press \times
1018	To make this message private, press 1
558	Otherwise, press 2
733	Thank you for calling

VM Prompts

Prompt No.	Modifiable Prompts
593	Please enter your party's mailbox number
219	Enter the first 3 or 4 letters of the person's first name
220	Enter the first 3 or 4 letters of the person's first or last name
1019	To make this message urgent, press 1

AA Prompts

Prompt No.	Modifiable Prompts
592	Please enter your party's extension
1224	You have a call
690	Sorry, no one is available to answer the call
1006	To leave a message, press 1
971	To enter another extension, press ×

Prompt No.	Modifiable Prompts
698	Sorry, this line is busy
388	If you would like to hold, press 1
847	To cancel holding, press 2 now. Otherwise, I'll try your party again.

Section 3 Customising Your Phone & System

This section shows you how to customise your individual telephone or PBX according to your needs. Find the desired setting and program as necessary.

3.1 Customising Your Phone (Personal Programming)

3.1.1 Customising Your Phone (Personal Programming)

You can customise your telephone features. For example, you can change the initial settings or button features according to your needs.


Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])

◆◆ Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])


You can assign a password to each extension. The following features require an extension PIN.

- 1. Screening calls (Live Call Screening [LCS])
- 2. Prohibiting other people from seeing your personal speed dialling directory, call log, and from playing back the voice messages in your message box (Display Lock)
- 3. Using the same settings as your extension at other extensions
- 4. Remote Control Operation (Walking COS)
- 5. Extension Dial Lock Clear

To set



To cancel





CAUTION

There is a risk that fraudulent telephone calls will be made if a third party discovers your password (extension PIN).

The cost of such calls will be billed to the owner/renter of the PBX.

To protect the PBX from this kind of fraudulent use, we strongly recommend:

- Keeping your PIN secret.
- **b.** Selecting a complex, random PIN that cannot be easily guessed.
- c. Changing your PIN regularly.
- Valid numbers for an extension PIN are "0" through "9".
- If the wrong extension PIN is entered a preprogrammed number of times, the PIN is locked.
- If you forget your extension PIN or your extension PIN is locked, your manager can clear the extension PIN and extension PIN lock.

3.1.2 Settings on the Programming Mode

You can programme features using the programming mode for a PT or PS.

- Setting Features
- Clearing Features




- · To exit at any time, lift the handset.
- To enter the programming mode when using a PS, refer to the documentation for your PS.

Setting Features

The default settings are shown in bold letters. For later reference, place a check mark in the boxes below to indicate your customised setting.

Notice

The default value may vary depending on country/area.



Item	Programming Input	Sele	ction & Parameter
Your extension information	0 0	The display shows number. <example> Ext 101</example>	your PT or PS's extension
Biomless Construct		1	Light
Display Contrast Selection ⁻¹ Preferred display contrast	0 1	2	Little Light
level from the 4 levels		3	Little Dark
available		4	☐ Dark
	02/	1	☐ English
Display Language		2	2nd Language
Selection Which display language do		3	3rd Language
you prefer?		4	4th Language
		5	5th Language
Display Switching Mode Would you like the call duration to be shown automatically on the display when answering an outside call?	0 3	0	No—Manual (The display keeps showing all of the outside caller's information unless you change it to the call duration manually.)
		1	Yes—Automatic (The first line of the display will change to the call duration automatically when you answer an outside call.)

Item	Programming Input	Sele	ection & Parameter
Display Backlight		0	☐ Yes—Automatic
Selection***2 Would you like to turn on the display backlight of the	0 4	1	Yes—always On
telephone?		2	☐ No—always Off
Self Labelling Display		1	Light
Contrast Preferred display contrast level from the 4 levels		2	Little Light
available for Self Labelling (KX-NT366/KX-NT553/	0 5	3	Little Dark
KX-NT556 only)		4	☐ Dark
Hot Line	1 1	desired no. (max. 32 digits) Available characters: 0–9, 💥, #, P (Pause)	
Would you like to dial a preset number simply by going off-hook?	1 2	0	☐ Do not use
		1	Use
Calling Line Identification Restriction (CLIR) Should you prevent your	1 3	0	☐ No—Allows your number to be displayed
number being displayed on the called party's telephone?		1	Yes—Prevent your number being displayed
Calling/Connected Line Identification Presentation	1 4	0	Caller ID assigned to your extension
(CLIP/COLP) Which number should be displayed on the called and calling party's telephone?		1	Caller ID assigned on the outside line being used

Item	Programming Input	Sele	ction & Parameter
		0	☐ No line
		1	An idle outside line
Preferred Line Assignment —Outgoing Which do you prefer to seize when you go off-hook to make calls?	1 9	The CO line no. assigned to the flexible button or	☐ A CO/ICD Group button
		Or INT' INTERCOM / (PDN)	Intercom (On a PDN extension, an idle PDN button is selected when going off-hook.)
		0	☐ No line
Preferred Line Assignment —Incoming Which line do you prefer to answer when you go off- hook?	2 0	1	☐ The longest ringing line (when multiple calls arrive)
		The CO line no. assigned to the flexible button or	☐ A CO/ICD Group button
		3 / (PDN)	A PDN button
		0	Ringing (Tone Call)
Alternate Receiving—Ring/ Voice*1 How do you prefer to receive an intercom call?	2 1	1	Directly—The party's voice is heard without ringing.
		2	Ring only—Prohibiting the caller switching to the voice mode.
Parallelled Telephone [™] Should the single line telephone in parallel ring?	2 2	0	No—The telephone will not ring.
		1	Yes—The telephone will ring.

Item	Programming Input	Sele	ction & Parameter	
Forced Answerback Selection ¹¹		0	☐ No—Disable	
Do you prefer to answer a call without going off-hook regardless of the AUTO ANS button status?	2 3	1	Yes—Enable	
Live Call Screening Mode Set*1 Which service do you prefer when a calling party is	2 5	0	You can monitor the message through the telephone speaker. (Handsfree mode)	
recording a message in your mailbox?		1	Only an alarm tone is heard. (Private mode)	
LCS Mode Set (After Answering)		0	☐ No—Stop recording	
Would you like to keep recording after answering the call in the LCS mode?	2 6	1	Yes—Keep recording	
Automatic Call Waiting ⁻³ Would you prefer to		0	□ No—Off	
automatically hear a call waiting tone when you receive a call while already on the phone?	3 0	1	☐ Yes—On	
	3 1	0	0	☐ No call (Off)
Manual Call Waiting How would you prefer to receive call waiting notifications for intercom calls?		1	☐ Tone (BSS)	
		2	☐ Voice announcement through the built-in speaker (OHCA) ⁻⁴	
		3	☐ Voice announcement through the handset (Whisper OHCA) ⁻⁵	
Call Waiting Tone Type Selection		0	☐ Tone 1	
Which type of call waiting tone do you prefer?	3 2	1	Tone 2	
		0	□ No—Off	
Absent Message Would you like to show a message on the caller's	4 0	message no. (1–	Yes—Shows the selected message.	
telephone display?		9	Yes—Shows your personal message.	

Item	Programming Input	Sele	ction & Parameter
Personal Absent Message Creating your personal message	4 1	messag	e (max. 16 characters)
		0	Off
		1	☐ Do Not Disturb (DND)
	5 0 / FWO/OND (for both calls)	2 + desired no. (max. 32 digits)	All—Forward all calls
Call Forwarding (FWD)/Do Not Disturb (DND) To forward or refuse some or all of your incoming calls	(for outside calls)	3 + desired no. (max. 32 digits)	Busy—Forwarded when your extension is busy.
	5 2 (for intercom	+ desired no. (max. 32 digits)	☐ No Answer—Forwarded when you do not answer.
	Suiley	no. (max. 32 digits)	Busy/No Answer— Forwarded when you do not answer or when your extension is busy.
FWD N/A Timer To set the timer for "No Answer" and "Busy/No Answer"	5 3	[] (De	(0–120) seconds fault: 15 seconds)
Call Pickup Deny Should you prohibit other		0	☐ No—Allow
people from picking up your calls?	6 0	1	Yes—Deny
Headset Operation [™]	6 1	0	☐ No—Headset off
Do you use the headset?		1	Yes—Headset on
Executive Busy Override Deny		0	☐ No—Allow
Do you prohibit other people from joining your conversation?	6 2	1	Yes—Deny
Paging Deny ⁻¹ Would you like to prohibit	6 3	0	☐ No—Allow
paging announcements?		1	Yes—Deny
Key Pad Tone Set" Do you prefer to hear the key	6 4	0	□ No—Off
pad tone?	((4)	1	Yes—On

Item	Programming Input	Sele	ction & Parameter
Background Music (BGM) ^{*1} Do you want background music through your telephone speaker while on- hook?	6 5	1 + BGM no. (1 digit)	☐ No—Off ☐ Yes—On
Bluetooth Registration ¹⁶ To register a Bluetooth wireless headset on your extension ¹⁷	6 6	Pass	key (max. 16 digits)
Bluetooth Removal ^{*6} To cancel the registration of a Bluetooth wireless headset on your extension ^{*7}	6 7		e ID of your Bluetooth wireless doset is displayed.
Extension PIN (Personal	9 0	extension PIN (max. 10 digits) + ENTER/STORE + same extension PIN	To set an extension PIN
Identification Number) To set your extension PIN or change the stored extension PIN		stored extension PIN + new extension PIN (max. 10 digits) + ENTER/STORE + same extension PIN	To change the stored extension PIN
Extension Dial Lock To prevent other people from	9 1	extension PIN (max. 10 digits) +	☐ To unlock
using your telephone		extension PIN (max. 10 digits) + 1	☐ To lock
Display Lock ⁻¹ To prevent other people from seeing your personal speed dialling directory, call log, and	ent other people from your personal speed directory, call log, and aying back the voice	extension PIN (max. 10 digits) +	☐ To unlock
from playing back the voice messages in your message box		extension PIN (max. 10 digits) +	☐ To lock

Item	Programming Input	Selec	ction & Parameter
One-touch Dialling		0	☐ No—Normal (Any Flexible buttons can be modified.)
Assignment Mode Selection Do you prefer to set the One- touch dialling only?	# *	1	Yes—Only One-touch dialling buttons can be modified. However, to modify them, there is no need to enter "2" before the number.

- ^{*1} Not available for a PS.
- Only available for IP-PTs (except KX-NT321)/KX-DT343/KX-DT346/KX-DT543/KX-DT546 telephones.
- This setting applies to both outside and intercom calls. For intercom calls, this feature must be enabled through system programming.
- Only available for certain digital proprietary telephones.
- Only available for IP-PTs and certain digital proprietary telephones.
- Only available for KX-NT300 series (except KX-NT321)/KX-NT560/KX-DT343/KX-DT346 telephones.
- Registering and cancelling a Bluetooth wireless headset may take time. Please avoid any interruption during that time by, for example, going off-hook.



CAUTION

There is a risk that fraudulent telephone calls will be made if a third party discovers your password (extension PIN).

The cost of such calls will be billed to the owner/renter of the PBX.


To protect the PBX from this kind of fraudulent use, we strongly recommend:

- a. Keeping your PIN secret.
- **b.** Selecting a complex, random PIN that cannot be easily guessed.
- c. Changing your PIN regularly.
- After the programme number is entered, the programme title is displayed.
 The programming screen can be changed with the Navigator Key (Up or Down).



You can select the parameter with the Navigator Key (Up or Down) instead of entering a number.


To store the names and numbers in personal speed dialling





• * To enter characters, refer to " Entering Characters".

To edit the names and numbers of personal speed dialling




Clearing Features

You can clear or change to features as follows:

Features	Default Setting
Display Switching Mode	Automatic
Hot Line	Off
Calling Line Identification Restriction (CLIR)	Allow
Calling/Connected Line Identification Presentation (CLIP/COLP)	Caller ID assigned on your extension
Preferred Line Assignment—Outgoing	Intercom
Preferred Line Assignment—Incoming	The longest ringing line
Alternate Receiving—Ring/Voice	Ringing (Tone Call)
Parallelled Telephone	Paired SLT will ring
Forced Answerback Selection	Disable
Live Call Screening Mode Set	Hands-free mode
LCS Mode Set (After Answering)	Stop recording
Automatic Call Waiting	Off

Features	Default Setting
Manual Call Waiting—Intercom Calls	Off (No call/No tone)
Call Waiting Tone Type Selection	Tone 1
Absent Message	Off
Personal Absent Message	Cleared
Call Forwarding (FWD)/Do Not Disturb (DND)—Intercom/Outside Calls	Off
FWD N/A Timer	15 seconds
Call Pickup Deny	Allow
Headset Operation	Headset off
Executive Busy Override Deny	Allow
Paging Deny	Allow
Key Pad Tone Set	On
Background Music (BGM)	Off
Data Line Security	Off
Connected Line Identification Restriction [COLR]	Allow
Log-in/Log-out	Log-in
Message Waiting	Off
Timed Reminder	Cleared

To change the above features back to their default settings






• If you do not desire that the Call Waiting, FWD/DND or Hot Line to be cleared by this feature, please ask your dealer.

3.1.3 Customising the Buttons

You can customise the flexible buttons and/or programmable feature (PF) buttons on PTs, Add-on Key Modules, and PSs. They can then be used to make or receive outside calls or as feature buttons.



- To enter programming mode when using a PS, refer to the documentation for your PS.
- The buttons in the table below can only be set on certain flexible buttons, as follows:
 - Flexible buttons on PTs/Add-on Key Modules/PSs: all buttons can be set.
 - Flexible buttons on DSS Consoles: all buttons except CTI and Primary Directory Number (PDN) buttons can be set.
 - Programmable feature (PF) buttons: only the One-touch Dialling button can be set.



Button	Programming Input
Loop-CO (L-CO)	*
Group-CO (G-CO)	# + Outside line group no. (2 digits)
Single-CO (S-CO)	• Outside line no. (3 digits)
Direct Station Selection (DSS)	1 + Extension no.*10
One-touch Dialling ¹	2 + Desired no. (max. 32 digits)
Incoming Call Distribution Group (ICD Group)	3 0 + Incoming call distribution group extension no. (+ # + delayed ringing time [0–7]) ⁻³
Message	4 0
Message for Another Extension	4 0 + Extension no./Incoming call distribution group extension no.
Call Forwarding (FWD)/Do Not Disturb (DND)—Both calls	4 1
FWD/DND—Outside calls	4 2
FWD/DND—Intercom calls	4 3
Group FWD—Both calls	4 + Incoming call distribution group extension no.
Group FWD—Outside calls	4 5 + Incoming call distribution group extension no.

Button	Programming Input
Group FWD—Intercom calls	4 6 + Incoming call distribution group extension no.
Account	4 8
Conference	4 9
Terminate	5 0
External Feature Access (EFA)	5 1
Call Charge Reference	5 2
Call Park	5 + Parking zone no. (2 digits)
Call Park (Automatic Park Zone)	5 3 *
Call Log⁺⁴	5 4
Call Log for ICD Group ⁻ ⁴	5 4 + Incoming call distribution group extension no.
Log-in/Log-out	5 5
Log-in/Log-out of a specified group	5 + Incoming call distribution group extension no.
Log-in/Log-out for all groups	5 5 X
Hurry-up	5 + Incoming call distribution group extension no.
Wrap-up	5 7
System Alarm ⁻ ⁴	5 8
Time Service (Day/Night/ Lunch/Break)	5 9 + 0/1/2/3 ⁻⁵ (+ # + Tenant no.)
Answer*4	6 0
Release*4	6 1
Toll Restriction/Call Barring	6 2 + Toll Restriction/Call Barring Level (1–7)
ISDN Service*6	6 3 + Desired no. (max. 32 digits)
Calling Line Identification Restriction (CLIR)	6 4
Connected Line Identification Restriction (COLR)	6 5
ISDN-Hold	6 6

3.1.3 Customising the Buttons

Button	Programming Input
Headset*4*7	6 7
Time Service Switching Mode (Automatic/Manual)	6 8 (+ Tenant no.)
СТІ	7 0
Primary Directory Number (PDN)	7 1
Secondary Directory Number (SDN)	7 2 + Extension no.*11 + # + delayed ringing time (0-7)*7
Check-in*4	8 0
Check-out ⁻ ⁴	8 1
Cleaned-up ⁻ ⁴	8 2
Two-way Record ^{*8}	9 • • • • • • • • • • • • • • • • • • •
Two-way Transfer ¹⁸	9 1 + UM group's floating extension no. '9/Voice mail floating extension no.
One-touch Two-way Transfer ^{*10}	9 1 + UM group's floating extension no." Voice mail floating extension no. + # + Extension no./Incoming call distribution group extension no.
Live Call Screening (LCS)*8	9 2
Voice Mail Transfer ^{*8}	9 4 + UM group's floating extension no. '9/Voice mail floating extension no.



*1 "**, "#", FLASH/RECALL, PAUSE, Secret (INTERCOM) and TRANSFER can also be stored.

If you do not want to display the stored number when making a call, press the Secret (INTERCOM) button before and after the numbers you wish to conceal.

If you store an outside party's number, you should first store a line access number. If you need to enter an account code, you can enter the specified account code before the line access number.

<Example>




- *2 For a PF button, "2" is not required to enter before the desired number.
- *3 Depending on the settings of your PBX, you may be required to enter delayed ringing time (0: Immediate, 1: 1 ring, 2: 2 rings, 3: 3 rings, 4: 4 rings, 5: 5 rings, 6: 6 rings, 7: No ring). In this case, you can automatically join a new ICD Group by creating a button for that group.
- *4 This button is not available for a PS.
- *5 0: Day/Night/Lunch/Break, 1: Day/Night/Break, 2: Day/Night/Lunch, 3: Day/Night
- *6 Availability of this button depends on the ISDN service of your telephone company. Refer to "1.2.5 Accessing the ISDN Service (ISDN Service Access)".
- *7 It is possible to set delayed ringing for each SDN button.
- *8 This button is used for the integrated voice mail features.
- *9 The UM group's default floating extension number is 500.
- To exit at any time, lift the handset.
- *10 You can set a Unified Messaging port extension number or the Unified Messaging FAX server extension number as an extension number for the DSS button.
- *11 When configuring the SDN key, only the extension number of the main device can be specified as the extension number.



 You can select the parameter with the Navigator Key (Up or Down) instead of entering a number.


To specify the ringing tones for each CO, ICD Group, PDN, SDN, or INTERCOM button (DPT/IP-PT only)





- * Available tone types vary depending on the telephone you are using:
 - KX-NT300 series (except KX-NT321)/KX-NT500 series/KX-DT300 series (except KX-DT321)/KX-DT500 series: Tone types "01" to "30" (01–20: tone, 21–30: melody) are available.
 - KX-NT321/KX-DT321: Only tone types "01" to "08" are available.
 It is possible to enter a tone type number from "09" to "30", but you will hear tone type "01".
 - Other telephones: Only tone types "01" to "08" are available.
 It is possible to enter a tone type number from "09" to "30", but you will hear tone type "02".
- Only one ringing tone can be selected for all PDN buttons on your extension.

To clear the button



3.2 System Programming Using Web Maintenance Console

3.2.1 User Programming

You can edit your personal information as well as limited extension and mailbox settings using My Portal in Web Maintenance Console. (You can view menus and setting items, but you can edit only a limited number of items.)

In addition, you can download the KX-NSX Series FAX Driver and the UM IMAP Session Controller for Microsoft Outlook. For details, refer to " Sending a Fax from your PC" and " IMAP" in "1.8.6 Other Features".

- Accessing My Portal for the First Time
- Logging in to My Portal
- My Portal Screen
- Editing Settings in My Portal
- Logout



• The contents and design of the software are subject to change without notice.

Accessing My Portal for the First Time

This step is required only when accessing My Portal for the first time.



- For the IP address of the NSX server, login name, and password, ask your System Administrator.
- If the configuration of the Web browser or PC changes, the certificate may need to be installed again. Once a certificate has been installed, My Portal will be displayed after step 2.
- 1. Launch your Web browser and input the IP address of the NSX server followed by "/WebMC/ users_potal/login" into the address bar, and then press **Enter**.
- **2.** If you connect to My Portal using TLS, a security alert window is displayed. Follow the prompts to install a security certificate. The procedure may vary according to your browser.

Logging in to My Portal

After establishing a connection to My Portal, the login window is displayed, and a login name and password must be entered.





• If you attempt to log in, but enter an incorrect password three times, you may not attempt to log in again for a 5 minute period.

CAUTION

- · For security, change the password the first time that you programme the NSX server.
- It is strongly recommended that a password of 16 numbers or characters be used for maximum protection against unauthorised access.
- To avoid unauthorised access to the NSX server, keep the password secret. If it becomes known to others, the NSX server may be misused.
- · Change the password periodically.

♦ My Portal Screen

The **My Portal** screen is displayed when you login to My Portal. On this screen, you can edit various user settings. To finish editing, click **OK**.

♦ Editing Settings in My Portal

Changing User Basic Information

You can change your User Basic Information in the Home tab of the My Portal screen.

- 1. In the **Home** tab, the following items are editable. Edit it as needed.
- 2. Click OK.

User Basic Information Parameters

Item	Description	
First Name Last Name	Enter your first name (up to 20 characters) and last name (up to 20 characters).	
Login ID	Specify a login ID for logging in to My Portal.	
Password Re-enter	Specify the password for logging in to My Portal. Enter the new password (up to 16 characters) in Password , and then enter it again in Re-enter to confirm it.	
User PIN / Voicemail Password ["0-9"] Confirm new PIN ["0-9"]	Specify a User PIN/Voicemail password. Enter the new password (up to 8 characters) in User PIN / Voicemail Password ["0-9"] , and then enter it again in Confirm new PIN ["0-9"] to confirm it.	
Language for My Portal	Specify the language to be used for the display of My Portal. Select the desired language from the drop-down list.	

Item	Description	
2nd Telephone-Delayed Ringing(s)	Specify the length of the delayed ringing time for sub devices. Select the desired delayed ringing time from the drop-down list (None , 5 sec , 10 sec , 15 sec).	
Portable Station-Delayed Ringing(s)	Specify the length of the delayed ringing time for wireless devices. Select the desired delayed ringing time from the drop-down list (None , 5 sec , 10 sec , 15 sec).	
Cancel ringing after forwarding	Select whether the telephone continues to receive a call when the call is forwarded to a public device. To prevent the telephone from ringing, select the check box.	
Mobile Phone #1-4 Number	Specify the extension number for your public devices.	
Mobile Phone #1-4 Delayed Ringing(s)	Specify the length of the delayed ringing time for public devices. Select the desired delayed ringing time from the drop-down list (None , 5 sec , 10 sec , 15 sec).	
Home Phone	Specify your home phone number.	
Personal Mobile Phone	Specify your personal cellular phone number.	
Email #1-3 Email Address	Specify the E-mail address to be used for Missed Call Notification and Voice Mail Notification.	
Email #1-3 Use for missed call notification	Select whether to use the Missed Call Notification feature. If you want to use the feature, select the check box.	
Email #1-3 Use for voice mail notification	Select whether to use the Voice Mail Notification feature. If you want to use the feature, select the check box.	
Memo-1	Specify the department to which the user belongs.	
Memo-2	Specify the area to which the user belongs.	

Registering a Prompt to the Mailbox

You can display, play, record or delete the following prompts:

- Personal Greetings (refer to " Changing or Deleting Your Personal Greeting Messages")
 - No Answer Greeting, Busy Signal Greeting, After Hours Greeting, Caller ID Greeting¹, Temporary Greeting and Absent Message
- Interview Mailbox Questions*2 (refer to " Interview Mailbox")
- Personal Caller ID Name¹ (refer to " Personal Caller Name Announcement")
- Personal Distribution List Voice Label² (refer to " Personal Group Distribution Lists")
- ^{*1} This feature may be disabled depending on your COS settings.
- This feature may be disabled depending on your system programming settings or mailbox settings.
- 1. In the Voicemail tab, click Registration for Personal Greetings.
- 2. In the **Prompt Registration** box, select a tab for the desired type of prompt.

To record a prompt

Select a Prompt No., and click Play/Record.

When "Record from extension" is selected:

- a. Specify the extension number of the telephone used for recording, then click Connect.
- **b.** When the specified extension rings, go off-hook.
- **c.** Click **Record**, **Stop**, or **Play** to record or play a system prompt.
- d. Click Disconnect.

When "Import from recorded file" is selected:

- a. Click **Browse**. The Open dialogue box appears.
- **b.** Navigate to the folder containing the WAV files you wish to import.
- **c.** Select the desired WAV file.
- d. Click Open to import the file.
- e. Click OK.

To start and stop prompt playback

- a. Select the desired prompt.
- b. Click Play/Record.
- c. Click Play or Stop.

To delete a specific prompt

- a. Select the desired prompt.
- b. Click Delete.
- c. Click OK.

Customising your mailbox setting

You can change your mailbox setting in the Voicemail tab of the My Portal screen.

- 1. In the Voicemail tab, click Edit for Advanced.
- 2. The Advanced Settings box appears. The following items are editable.

Mailbox Parameters

Item	Description		
Mailbox Password (Message Client)	Specifies the password needed to access the mailbox when using a client software program. If a default password is programmed by an administrator, that password will be assigned automatically when creating all mailboxes. To change a password for a mailbox:		
	1. Click Edit.		
	2. In the window that appears, enter the new password (4–16 characters in length) and then enter it again to confirm it.		
	3. Click OK.		
Advanced Call Transfer Setting	By combining the settings for Call Transfer and Incomplete Call Handling, you can create call handling "scenarios" for your extension. Up to 20 scenarios can be created, and a scenario can be assigned to each absent message in Scenario Setting .		

Item	Description		
	1. Click Edit for creating scenarios.		
	2. Select a Scenario number (1–20) from the drop-down list.		
	3. Type the scenario name in the Scenario Name box.		
	4. Assign the following options in each section. Click OK when finished.		
	Call Transfer Status Determines how the Unified Messaging system will handle a call in the selected scenario.		
	Selection Determines how the Unified Messaging system will handle a call in the selected scenario. Select the setting from the following items.		
	None: Rings your extension.		
	 Call blocking: Handles the call according to the Incomplete Call Handling for No Answer setting for your extension. Your extension will not ring. 		
	 Call screening: The caller is prompted to record his or her name. The Unified Messaging system then calls you and plays back the caller name. You can choose whether to answer the call. 		
	 Leave a Message: Transfers the caller to the mailbox. Intercom Paging: Pages you by intercom. Transfer to specified Custom Service Menu: Transfers the caller to the specified Custom Service. 		
	VIP Filter		
	If "Leave a Message" is selected for Selection and "Enable" is selected for this setting, calls from certain phone numbers will be transferred directly to your extension or specified telephone number.		
	 Telephone Number 1, 2, 3: Specifies the telephone numbers that the VIP Filter setting will be applied to. When a call is received from any of the numbers specified here, the call will be transferred immediately to the destination specified in Transfer to (Selection). 		
	 Transfer to (Selection): Specifies the transfer destination for calls transferred according to the VIP Filter setting. 		
	 Extension: The call is transferred to your extension. 		
	 Other: The call is transferred to the telephone number that is specified in Transfer to (Other). 		
	Transfer to specified Custom Service Menu Select a Custom Service from the drop-down menu if "Transfer to specified Custom Service Menu" is selected for Selection .		

Item	Description		
	Transfer to specified telephone number - 1 If "None" or "Call screening" is selected for Selection , specifying a telephone number here will transfer the caller to that telephone number. Enter a maximum of 32 characters consisting of 0–9, *, and #.		
	Note		
	If "Call screening" is selected, the transfer destination will hear the call screening prompt before the call is transferred.		
	Transfer to specified telephone number 2, 3, 4, 5 (Selection/Other) If "None" or "Call screening" is selected for Selection, and the call could not be transferred to the number specified in Transfer to specified telephone number- 1, the call will be transferred according to these settings for this scenario, in numerical order of priority.		
	Note		
	If "Call screening" is selected, the transfer destination will hear the call screening prompt before the call is transferred.		
	1. Select Other, Extension, or Covering Extension.		
	2. If "Other" is specified, enter a maximum of 32 characters consisting of 0–9, \pm , and \pm .		
	Incomplete Call Handling for No Answer Specifies how the scenario handles a call when there is no answer. More than one option can be selected.		
	Leave a Message: Allows the caller to record a message.		
	Transfer to a covering extension: Transfers the caller to a covering extension.		
	 Page the mailbox owner by intercom paging: Pages you by intercom. 		
	Transfer to operator: Transfers the caller to an operator.		
	Return to top menu: Lets the caller return to top menu and try another extension.		
	Transfer to specified Custom Service Menu: Transfers the caller to the specified Custom Service.		

Item	Description			
	Incomplete Call Handling for Busy Specifies how the scenario handles a call when the destination is busy. More than one option can be selected.			
	Leave a Message: Allows the caller to record a message.			
	• Transfer to a covering extension: Transfers the caller to a covering extension.			
	Page the mailbox owner by intercom paging: Pages you by intercom.			
	Transfer to operator: Transfers the caller to an operator.			
	 Return to top menu: Lets the caller return to top menu and try another extension. 			
	 Transfer to specified Custom Service Menu: Transfers the caller the specified Custom Service. 			
Scenario Setting	You can select scenarios set in Advanced Call Transfer Setting . A scenario can be set temporarily, or scenarios can be selected for use according to the Absent Message setting of your extension.			
	Current Scenario: The scenario that is assigned to the absent message currently set at your extension is displayed here.			
	Temporary Scenario: Setting a scenario here will use that scenario indefinitely. A scenario set here will be used regardless of your extension status. Selecting "None" will remove the setting.			
	Absent Message 1–9: The selected scenario will be used when the corresponding Absent Message is set at your extension.			

Changing Telephony Setting

You can change your extension's telephony settings in the **Telephony** tab of the **My Portal** screen.

- 1. In the **Telephony** tab, the following items are editable. Edit it as needed.
- 2. Click OK.

Telephony Parameters

Item	Description	
FWD/DND Settings - for external calls	To specify the forward type, select the desired type from the FWD/DND Settings - for external calls drop-down list, then enter the telephone number or select Phone (Home) or Phone (Mobile) to specify the forward destination.	
FWD/DND Settings - for internal calls	To specify the forward type, select the desired type from the FWD/DND Settings - for internal calls drop-down list, then enter the telephone number or select Phone (Home) or Phone (Mobile) to specify the forward destination.	
Use external calls setting for internal calls	To apply settings to both outside and intercom calls, click Use external calls setting for internal calls. When you select this, the FWD/DND setting of For external calls is applied to both outside and intercom calls.	

Item	Description	
FWD No Answer Time(s)	Specifies the length of time that the Unified Messaging system waits before handling unanswered calls to the extension. Select the desired time from the FWD No Answer Time(s) drop-down list.	
Call waiting Mode	Select the Call Waiting mode from the For external calls drop-down list and the For internal calls drop-down list respectively.	
Phone Display Language	To specify the language displayed on the LCD of the display PT, select the displayed language from the Phone Display Language drop-down list.	
Dial Lock	To activate Dial Lock, click Dial Lock .	
Display Lock	To activate Display Lock, click Display Lock .	
Device in use (for CTI)	To specify the device controlled with CTI, select the desired device from the Device in use (for CTI) drop-down list.	

These phone numbers are set in the **Home** tab of the **My Portal** screen.

Storing names and numbers in personal speed dialling

You can set frequently dialled numbers using two-digit speed dialling numbers (00–99). A maximum of 100 Personal Speed Dialling numbers can be programmed at your extension for your personal use.

- 1. In the Directry tab, enter the name of the Personal Speed Dialling number to call in **Speed Dialling - Personal Name** (max. 20 characters).
- 2. Enter the number to be dialled by the Personal Speed Dialling number in **Speed Dialling Personal Number** (max. 32 digits consisting of 0–9, \times , #, T [Transfer], [] [Secret], P [Pause], and F [Flash]).
- 3. Click OK.

\$ Logout

To logout of Web Maintenance Console, click the $\boxed{\text{(logout)}}$ button to end the programming session and return to the Login screen. When this option is chosen, system data is automatically backed up from the PBX to the Storage Memory Card.

- Click the (logout) button.
 A confirmation message will be displayed.
- 2. Click Yes.



If the computer running the Web browser that is connected to Web Maintenance Console is shut down, or the Web browser is closed, any changes that have not been saved will be lost. Always end your programming session by clicking the → (logout) button. For more information, consult your System Administrator.

Section 4

Customising Extensions and the System–for Managers

This section shows managers how to customise the PBX's extension and system settings according to their needs. Find the desired setting and program as necessary.

4.1 Manager Programming

4.1.1 Programming Information

The manager can programme the following items.

- Call Charges
- · Other Extensions Control

Available Extension

The extension assigned as a manager

Required Telephone

A Panasonic Proprietary Telephone with display (2 lines or more) (e.g., KX-NT343, KX-NT546, KX-DT346, KX-DT546)

Manager Password

To enter programming mode, the manager password (max. 10 digits) is required. (Default: 1234)

CAUTION


- The NSX server has a default password preset. For security, change the password the first time that you programme the NSX server.
- It is strongly recommended that a password of 10 numbers or characters be used for maximum protection against unauthorised access. For a list of numbers and characters that can be used in the password, refer to " Entering Characters".
- To avoid unauthorised access to the NSX server, keep the password secret. If it becomes known to others, the NSX server may be misused.
- · Change the password periodically.

Conditions

The programming extension must be idle, on-hook and holding no calls.

4.1.2 Manager Programming

♦ Changing Call Charges and Extension Control



Item	Programming Input
Changing the manager password.	0 + • + Password (max. 10 digits) + •

Item	Programming Input
Viewing extension call charges.	0 1 + 🔷 + Extension no.
Clearing extension call charges.	0 1 + 🔷 + Extension no. + 🔷 + 🔷
Setting the budget for extension call charges.	0 2 + + Extension no. + Charge* +
Viewing call charges for each verification code.	0 3 + + Verification code
Clearing call charges for each verification code.	0 3 + + Verification code + + +
Setting the budget for each verification code.	0 4 + + Verification code + Charge* +
Viewing call charges for each outside line.	0 5 + • Outside line no. (3 digits)
Assigning a charge rate for each outside line group.	0 6 + + Outside line group no. (2 digits) + Charge rate* +
Clearing all charges.	0 7 + 🔷 + 🔷
Printing the total call charge.	0 8 + 🔷 + 🔷
Locking/unlocking other extensions. (Remote Extension Dial Lock)	9 0 + + Extension no. + 1 (to lock)/ 0 (to unlock) + +
Clearing the PIN and PIN lock for extensions.	9 1 + 🔷 + Extension no. + 🔷
Clearing the PIN and PIN lock for verification codes.	9 2 + 🔷 + Verification code + 🔷
Setting the verification code PIN.	9 3 + + Verification code + PIN (max. 10 digits) +



CAUTION

There is a risk that fraudulent telephone calls will be made if a third party discovers your password (verification code PIN).

The cost of such calls will be billed to the owner/renter of the PBX.

To protect the PBX from this kind of fraudulent use, we strongly recommend:

- a. Keeping your PIN secret.
- **b.** Selecting a complex, random PIN that cannot be easily guessed.
- c. Changing your PIN regularly.
- * To enter a decimal point, press \times .

4.1.3 Supervisory Monitor (ACD) Control

- Monitor Control & Execute
- ACD Report Analysis




Note:

The Supervisory Monitor (ACD) Control feature cannot be used at the same time as Hospitality features. (Refer to "1.12.1 Using the Telephones in a Hotel-type Environment (Hospitality Features)".) For details, consult your system administrator.

By specifying an ACD Supervisor for extension users, the ACD Supervisor can check and analyse the operating conditions of an ICD group. This is done by monitoring the current condition of the ICD group, and by collecting and analysing statistical ACD report information.

ICD group monitoring enables recording of ACD report data and allows various analyses based on that data. To analyse the ACD report, there are three filters: "Group", "Agent", and "Call". The filtered ACD report data can be printed out and exported in CSV format. You can also create graphs (pie charts or bar charts) to easily analyse ACD reports. The flow from ACD report data collection to analysis is shown below:



Monitor Control & Execute

A user designated as an ACD Supervisor or Administrator can specify certain ICD groups to monitor and configure the monitoring settings. Finally, the user can start the monitor.

To configure the monitor settings and start monitoring

You can configure the monitor control settings in the **Group Monitor** of the **ICDG Management** in Web Maintenance Console.

- 1. On the left side of the screen, click Users → ICDG Management → Group Monitor.
- 2. Select an ACD Supervisor from the Supervisor selection drop-down list.
- **3.** On the **Layout** of the **Basic Settings**, select the layout for showing the monitor results.
- 4. Select the ICD Group that you want to monitor from the Select ICD Group drop-down list.
- **5.** On the **Options**, you can change the following settings for the monitor screen:

Item		Description	Value
Member Status View Mode		Select the display mode for members' status.	Standard, Simple
Highlighted Display Settings	Number of Current Waiting Calls (1-30)	Specify the number of waiting calls at which the Current Waiting Callsdisplay is highlighted.	1–30
	Waiting Time (0-10 min/10 sec)	Specify the waiting time at which the Longest Waiting Time display is highlighted.	0–10 minutes
	Colour Mode	Select the colour to use to highlight items on the screen.	Mode 1, Mode 2, Mode 3
	Blinking	Select whether items that are highlighted on the screen blink.	Enable, Disable

- 6. Click Apply.
- 7. When you finish configuring the settings, click **Start Monitor** to start monitoring the selected ICD group.
- 8. Click Close.
- 9. Click OK.

ACD Report Analysis

You can specify which items to include in the monitor result report, the style in which to display the report profile, and the output format.

- 1. On the left side of the screen, click Users → ICDG Management → ACD Report.
- 2. Select an ACD Supervisor from the Supervisor selection drop-down list.
 - To load an ACD report
 - a. Click Report Profiles.
 - b. Select the Profile Name.
 - c. Click Load.
 - · To save an ACD report
 - a. Click Report Profiles.
 - **b.** Name the **Profile Name** (max. 32 characters).
 - c. Click Save.
 - To select ACD report options
 - a. Click Option.
 - **b.** In **ACD Report Export CSV File Format**, select either **Comma(,)** or **Semicolon(;)** as the data separator.
 - c. Click OK.

You can make an ACD report through 3 types of filters: **Group**, **Agent**, and **Call**. On the ICD screen, select the target tab, configure the settings as necessary and then click **Apply**.

For Group

 On the Group tab under Filter Settings, select one of the following items in the View Mode drop-down list:

Group, Hour, Day, Date, Month, Trunk, Caller ID/CLIP

Note

If you select **Hour**, specify the time range (0:00–23:59) in **Range**.

- 2. On the **Group—Filter Settings—Select Group** screen, set the groups to analyse as follows:
 - a. Click Select.
 - **b.** Click the ICD group name you want to analyse from the ICD group names displayed on the **Available Group for ACD Report** window. (Maximum 64 groups displayed)
 - c. Click ==> to move the ICD group you selected in step b. to the Selected Group for ACD Report window. (Maximum 64 groups)
 To delete an ICD group from the Selected Group for ACD Report window, click the ICD group name, and then click <==.</p>
 - d. Click OK.
- 3. Select the target time period for the ACD report on **Group—Filter Settings—Select Period**.
- **4.** To show the report on a group basis, perform the following steps:
 - a. Click View Report.

The ACD Report - Group Report screen is displayed.

The filtered data is shown as follows:

Group	Incoming Calls	Total	The number of incoming calls received by the target ICD group.
		Answered	The number of incoming calls answered by the target ICD group.
			The number of incoming calls to the target ICD group cancelled by the caller.
		Overflow	The number of overflowed incoming calls from the target ICD group.
	Talk Time	Total	The total talking time of answered calls for the target ICD group. (HH:MM:SS)
		Average	The average talking time of answered calls for the target ICD group. (HH:MM:SS)
Wait Time (Answered)		Max.	The longest talking time of answered calls for the target ICD group. (HH:MM:SS)
		Total	The total waiting time of answered calls for the target ICD group. (HH:MM:SS)
		Average	The average waiting time of answered calls for the target ICD group. (HH:MM:SS)
		Max.	The longest waiting time of answered calls for the target ICD group. (HH:MM:SS)
	Wait Time (Lost)	Total	The total waiting time of cancelled calls for the target ICD group. (HH:MM:SS)
		Average	The average waiting time of cancelled calls for the target ICD group. (HH:MM:SS)
		Max.	The longest waiting time of cancelled calls for the target ICD group. (HH:MM:SS)
	Max. Waiting Calls		The maximum number of calls waiting in the queue of the target ICD group.

When View Mode is "Group", a pie graph will be created.

When View Mode is "Caller ID/CLIP", a graph report cannot be created.

In other modes, a bar graph will be created.

- **b.** The results report can be output in one of the following 3 ways:
 - **Graph**: Click **Graph**, open the **ACD Report Group Graph** screen, and display the graph of the report. Click **Print** to print the graph.
 - Export: Click Export, and save the report file.
 - Print: Click Print to print the report.
- c. Click Close.

For Agent

1. On the **Agent** tab under **Filter Settings**, select one of the following items in the **View Mode** drop-down list:

Agent, Hour, Day, Date, Month

Note

If you select **Hour**, specify the time range (0:00–23:59) in **Range**.

- 2. On the Agent—Filter Settings—Select Agent screen, set the groups to analyse as follows:
 - a. Click Select.
 - **b.** Click the agent name you want to analyse from the displayed agent names on **Available Agent for ACD Report** window.
 - c. Click ==> to move the agent you selected in step b. to the Selected Agent for ACD Report window. (Maximum 128 agents)

To delete an agent from the **Selected Agent for ACD Report** window, click the agent name, and then click <==.

- d. Click OK.
- 3. Select the target time period for the ACD report on Agent—Filter Settings—Select Period.
- **4.** To show the report on an agent basis, perform the following steps:
 - a. Click View Report.

The ACD Report - Agent Report screen is displayed.

The filtered data is shown as follows:

Agent	Total Answer		The number of calls that the target agent answers.
	Talk Time	Total	The total talking time for the target agent. (HH:MM:SS)
		Average	The average talking time for the target agent. (HH:MM:SS)
		Max.	The longest talking time for the target agent. (HH:MM:SS)
	Login Time		The total login time for the target agent. (HH:MM:SS)
	Not-ready Time		The total not-ready time for the target agent. (HH:MM:SS)
	Wrap-upTime		The total wrap-up time for the target agent. (HH:MM:SS)

- **b.** The results report can be output in one of the following 3 ways:
 - **Graph**: Click **Graph**, open the **ACD Report Agent Graph** screen, and display the graph of the report. Click **Print** to print the graph.
 - Export: Click Export, and save the report file.
 - Print: Click Print to print the report.
- c. Click Close.

For Call

- 1. On the Call—Filter Settings—Select Group screen, set the group to analyse as follows:
 - a. Click Select.
 - **b.** Click the ICD group name you want to analyse from the ICD group names displayed on the **Available Group for ACD Report** window. (Maximum 64 groups displayed)

- **c.** Click ==> to move the ICD group you selected in step b. to the **Selected Group for ACD Report** window. (Maximum 64 groups)
 - To delete an ICD group from the **Selected Group for ACD Report** window, click the ICD group name, and then click <==.
- d. Click OK.
- 2. Select the target time period for the ACD report on Call—Filter Settings—Select Period.
- Select the target for an ACD report from the following, and then configure the filter settings on the Call— Call Filter Mode screen.
 - Caller ID/CLIP Filter: You can filter by Caller ID or CLIP.
 - a. Click Caller ID/CLIP Filter.
 - **b.** Enter the caller ID or CLIP as the target to analyse (maximum 10).
 - Talk/Wait Duration Filter: You can filter by continuous talk time or wait time.
 - a. Click Talk/Wait Duration Filter.
 - **b.** Select **Talk Time** or **Wait Time** from the **Mode** drop-down list.
 - c. Set the target time range to filter.
 To set the minimum time duration, click Min., and set the time (0:00–23:59).
 To set the maximum time duration, click Max., and set the time (0:00–23:59).
 - · Lost Call Filter: You can filter by lost calls.
 - a. Click Lost Call Filter.
- **4.** To show the report on a group basis, perform the following steps:
 - a. Click View Report.

The ACD Report - Call Report screen is displayed.

The filtered data is shown as follows:

Call	ACD Report - Call Report	Start Date	The start date of the call.
		Start Time	The start time of the call. (HH:MM:SS)
		End Date	The end date of the call.
		End Time	The end time of the call. (HH:MM:SS)
		Result	The processing result. (Answered/ Abandoned/Overflowed/ Unanswered) ¹¹
		ICDG	The incoming ICD Group number.
		Incoming Agent	The extension number of the agent that received the call. 2
		Answering Agent	The answering member. (Extension Name/Extension Number)
		Talk Time	The talking time. (HH:MM:SS)
		Wait Time	The waiting time.(HH:MM:SS) ⁻³
		Trunk	The incoming trunk group number.
		Caller ID/ CLIP	The caller's number.

- •1 Unanswered is displayed when the agent did not answer the call if the ICD group distribution method is set to Uniform Call Distribution or Priority Hunting.
- Displayed only when the ICD group distribution method is set to Uniform Call Distribution or Priority Hunting.
- The unanswered wait time is displayed when the call was **Unanswered** and the ICD group distribution method is set to Uniform Call Distribution or Priority Hunting.

Note

The displays described in *1–*3 can be changed through system programming. For details, consult your system administrator.

No graphical data is supported for Call Report.

- **b.** The results report can be output in one of the following 2 ways:
 - Export: Click Export, and save the report file.
 - Print: Click Print to print the report.
- c. Click Close.

Section 5 Appendix

This section provides the List of Operations by Telephone Type, the Troubleshooting, the Feature Number Table and Tone List. Check the Troubleshooting section before consulting your dealer.

5.1 List of Operations by Telephone Type

5.1.1 List of Operations by Telephone Type

The features that each type of telephone supports are marked with a \checkmark . Features without a \checkmark for a certain telephone type are not supported for that telephone type.



• Some operations of these features may not be supported by a certain telephone type. For details, refer to the each section's operations.

		Telephone Type			
Features	PT	PS	SLT	SIP phone	
1.2.1 Basic Calling		1	1	1	
◆◆ Calling Another Extension	✓	✓	✓	✓	
Calling an Outside Party	✓	✓	✓	✓	
◆ Making a Call to a Private Network (TIE Line Access)	✓	✓	✓	✓	
◆ Using an Account Code (Account Code Entry)	✓	✓	✓	✓	
1.2.2 Easy Dialling					
♦♦ With a One-touch Button (One-touch Dialling)	✓	✓			
◆ Using Numbers Stored at Your Extension (Personal Speed Dialling)	✓		√	√	
Using Numbers Stored in the PBX (System Speed Dialling)	✓	✓	✓	√	
◆ To a Preset Number by Going Off-hook (Hot Line)	✓	✓	√		
◆ Using a Preprogrammed Number (Quick Dialling)	Number (Quick Dialling) ✓		✓	✓	
1.2.3 Redial	✓	√	✓	✓	
1.2.4 When the Dialled Line is Busy or There is No Answer					
Reserving a Busy Line (Automatic Callback Busy)	✓	✓	✓		
◆◆ Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])	✓	√	√		
Sending a Call Waiting Notification (Call Waiting)	✓	✓	✓		
Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)	✓	✓	√	✓	
Joining an Existing Call (Executive Busy Override)	✓	✓	✓		
Monitoring Another Extension (Call Monitor)		✓	√		

		Telephone Type			
Features	PT	PS	SLT	SIP phone	
♦♦ To an Extension Refusing the Call (DND Override)	✓	✓	✓		
1.2.5 Accessing the ISDN Service (ISDN Service Access)	✓	✓			
1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice)	✓	✓	✓		
1.2.7 Calling without Restrictions					
Using Your Calling Privileges at Another Extension (Remote COS Access)	✓	✓	✓	✓	
1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)	✓	✓	✓		
1.3.1 Answering Calls	✓	✓	✓	✓	
1.3.2 Answering Hands-free (Hands-free Answerback)	✓	✓			
1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)					
Answering a Call from Another Telephone (Call Pickup)	✓	✓	✓	✓	
Answering a Call from Another Telephone (Call Pickup Group Monitor)					
◆ Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)	✓	✓	√	√	
1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])	✓	✓	√		
1.3.5 Using the ANSWER/RELEASE Button	✓				
1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID])	✓	✓	✓		
1.4.1 Transferring a Call (Call Transfer)					
Transferring to an Extension in the PBX	✓	✓	✓	✓	
Transferring to an Outside Party Using the PBX Service	✓	✓	√	✓	
Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)	✓	✓	✓		
Transferring to an Outside Party Using the SIP Service	✓	✓	✓		
1.4.2 Holding a Call	✓	✓	✓	✓	
1.4.3 Talking to Two Parties Alternately (Call Splitting)	✓	✓	✓		
1.4.4 Answering Call Waiting	✓	✓	✓		

Features		Telephone Type			
		PS	SLT	SIP phone	
1.4.5 Multiple Party Conversation					
Adding Other Parties during a Conversation (Conference)	✓	✓	✓		
Leaving a Conference (Unattended Conference)	✓	✓			
Leaving a Conference (Leaving Three-party Conference)	✓	√	✓		
Letting a Third Party Join Your Call (Privacy Release)	✓	√			
Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)	√	✓	√		
1.4.6 Mute	✓	✓			
1.4.7 Letting Other People Listen to the Conversation (Off-hook Monitor)	√				
1.4.8 Using the Headset (Headset Operation)					
1.5.1 Primary Directory Number (PDN)/Secondary Directory Number (SDN) Extension		✓			
1.6.1 Forwarding Calls					
Forwarding Your Calls (Call Forwarding [FWD])	✓	✓	✓	✓	
Remote FWD Settings Using Group FWD Button	✓				
FWD/DND Settings Using Fixed FWD/DND Button	✓				
Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)	✓	√	√		
1.6.2 Showing a Message on the Caller's Telephone Display (Absent Message)	✓	✓	√	✓	
1.6.3 Preventing Other People from Using Your Telephone (Extension Dial Lock)					
To lock	✓	✓	✓	✓	
To unlock	✓	✓	✓	✓	
To make an outside call while your extension is locked	✓	✓	✓		
1.7.1 Paging					
♦♦ Group Paging	✓	✓	✓	✓	
Paging and then Transferring a Call	✓	✓	✓	✓	
1.7.2 Answering/Denying a Paging Announcement	<u> </u>				

		Telephone Type			
Features	PT	PS	SLT	SIP phone	
To answer	✓	✓	✓	✓	
To allow/deny a paging announcement (Paging Deny)	✓				
1.7.3 Making a Conference Group Call					
Conference Mode	✓	✓	✓	✓	
Broadcast Mode	✓	✓	✓	✓	
Join After Time Out	✓	✓	✓	√	
1.8 Using the Unified Messaging Features *2 *3	✓	✓	✓	✓	
1.9.1 Setting the Alarm (Timed Reminder)	✓		✓	✓	
1.9.2 Refusing Incoming Calls (Do Not Disturb [DND])					
♦ Do Not Disturb (DND)	✓	✓	✓	✓	
Switching FWD/DND Status Using Fixed FWD/DND Button					
1.9.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA) 14 15		✓	✓	✓	
1.9.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/COLP])	✓	√	√	✓	
1.9.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR])	✓	✓	✓	√	
1.9.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])	✓	✓	√	✓	
1.9.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)	✓	✓	✓	✓	
1.9.8 Turning on the Background Music (BGM)	✓				
1.9.9 Protecting Your Line against Notification Tones (Data Line Security)	√	✓	✓	✓	
1.9.10 Checking the Time Service Status	✓				
1.9.11 Setting the Parallelled Telephone to Ring (Parallelled Telephone)	√ *6				
1.9.12 Clearing Features Set at Your Extension (Extension Feature Clear)	√	✓	✓	✓	
1.10.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up)	√	✓	✓	✓	

	Telephone Type			
Features		PS	SLT	SIP phone
1.10.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)				
Monitoring the Status of Waiting Calls	√ *7			
♦♦ Monitoring and Changing the Log-in/Log-out Status of Extensions	✓ *7			
1.10.3 Forwarding a Waiting Call (Manual Queue Redirection)	✓	✓		
1.11.1 If a Doorphone/Door Opener is Connected		I	1	1
♦♦ Doorphone Call	✓	✓	✓	✓
Opening a Door (Door Open)	✓	✓	√	✓
1.11.2 If an External Relay is Connected				
To switch on the relay	✓	✓	✓	
1.11.3 If an External Sensor is Connected		l		
To answer a sensor call	✓	✓	✓	✓
1.11.4 If a Host PBX is Connected				
Accessing External Services (External Feature Access [EFA])	✓	✓	✓	
1.12.1 Using the Telephones in a Hotel-type Environment (Hospitality Features)				1
◆ Check-in	✓ *7			
♦♦ Check-out	✓ *7			
Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)	✓			
♦ ♦ Cleaned-up	√ *7			
1.12.2 Recording Information Using Preprogrammed Messages (Printing Message)	✓		✓	
1.13.1 Introduction to the User Container Feature	✓		✓	✓
1.13.2 Service-in/Service-out (Smart Desk)				•
Service-in	✓	✓	✓	✓
♦♦ Service-out	✓	✓	✓	
1.13.3 Switching between CTI Control Devices	✓	✓	✓	✓
1.14.1 Using the Call Log	✓	✓		
1.14.2 Using the Directories	✓	✓		

		Telephone Type			
Features	PT	PS	SLT	SIP phone	
1.14.3 Accessing System Features (System Feature Access)	✓ *8				
1.14.4 Self Labelling (KX-NT366/KX-NT553/KX-NT556/ KX-NT560 only)	√ *9				
2.1.1 Extension Control	✓	✓	✓	✓	
2.1.2 Time Service Mode Control	✓	✓	✓	✓	
2.1.3 Restriction Level Control (Dial Tone Transfer)		✓			
2.1.4 Turning on the External Background Music (BGM)		✓	✓	✓	
2.1.5 Recording Outgoing Messages (OGM)	✓				
2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)	√	✓	✓		
2.2 Configuring Unified Messaging Features *10	✓	✓	✓	✓	
3.1 Customising Your Phone (Personal Programming)		I		1	
Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])		✓	✓	√	
3.1.2 Settings on the Programming Mode	✓	✓			
3.1.3 Customising the Buttons	✓	✓			
4.1 Manager Programming		1	1	1	
Changing Call Charges and Extension Control	✓				

- ^{*1} Available telephones are as follows:
 - IP-PTs (except models with a single line display)
 - DPTs (except models with a single line display)
- ^{*2} " Live Call Screening (LCS)" and " Recording Your Conversation" are only available for PTs and PSs.
- ^{*3} Setting the Alarm (Timed Reminder)" is only available for PTs, SLTs and SIP phones.
- *4 OHCA is only available for certain DPTs.
- *5 Whisper OHCA is only available for IP-PTs and certain DPTs.
- *6 Only available for DPTs.
- ⁴⁷ Only available for Display PTs.
- Only available for the KX-NT300 series, KX-NT500 series, KX-DT300 series, and KX-DT500 series.
- Only available for the KX-NT366 and KX-NT553/KX-NT556/KX-NT560.
- *10 " Setting the Timed Reminder" is only available for PTs, SLTs and SIP phones.

5.2 Troubleshooting

5.2.1 Troubleshooting

Troubleshooting

Problem	Remedy
The telephone does not work properly.	Confirm with your manager that your settings are correct.
	 If the problem persists, consult your dealer.
The telephone does not respond when buttons are pressed.	The telephone is locked.
Some features do not work.	 System management may restrict certain features. Consult your manager.
	 The feature numbers have changed. Confirm the revised number and try again.
Even though following the manual instructions, none of the operations work when using a proprietary telephone.	The Intercom line was not seized. The seized line, when going off-hook, was changed by personal setting. (
The parallelled single line telephones do not ring.	"No ring" may be selected. Change the setting to ring. (
My proprietary telephone does not have a feature button.	Some models do not have the feature button. Change a flexible button to the desired button. (♠ 3.1.3 Customising the Buttons) Enter the specified feature number instead of the feature button. (♠ 1.1.5 Before Operating the Telephones)

Problem	Remedy
A reorder tone is audible or "Restricted" is displayed.	 The telephone is locked. □ Unlock your telephone. (□ 1.6.3 Preventing Other People from Using Your Telephone (Extension Dial Lock), 2.1.1 Extension Control)
	 Toll restriction is activated. Consult your manager or dealer.
	 An account code is required. (12.7 Calling without Restrictions, Using an Account Code (Account Code Entry) in 1.2.1 Basic Calling)
I cannot make an outside call using the Onetouch Dialling button or speed dialling.	• A line access number was not stored. → A line access number is required for outside calls. (→ 1.2.1 Basic Calling, 3.1.3 Customising the Buttons)
I cannot remember the feature numbers.	• If the feature numbers have been changed from the default values, write the new feature numbers in the table in "5.3.1 Feature Number Table".
	 Ask your dealer to change the feature numbers for easier use.
While talking to an outside party, the line is disconnected.	The time limit has run out. (
Redialling does not function.	• The dialled number was more than 32 digits. (📭 1.2.3 Redial)
I cannot have a conversation using the Bluetooth headset.	 Make sure that the headset is properly registered to the module.
	 Make sure that the headset is properly charged according to the manual of the headset.
	 Remove the wired headset from the headset jack. Priority is given to the wired headset when both are connected.
I cannot register, de-register, or confirm the ID of the Bluetooth headset.	Make sure that the module is properly installed in the IP-PT/DPT.
The PC and fax machine communication failed.	• An indication tone may have interrupted communication. () 1.9.9 Protecting Your Line against Notification Tones (Data Line Security))

Problem	Remedy
I do not want to show my telephone number to the calling or called party's telephone.	(
I want to show my telephone number to the calling or called party's telephone.	(
I cannot send a call waiting tone to the dialled extension.	 The other party has not set the Call Waiting feature. (
I forgot the password.	 Notification Tones (Data Line Security)) Ask the manager to assist you. (\(\mathbb{P} \) 2.1.1 Extension Control)
The background music started suddenly.	• ■ Turn off the music. (IP 1.9.8 Turning on the Background Music (BGM), 2.1.4 Turning on the External Background Music (BGM))
I do not want to display a number which is stored in memory.	 Conceal the number. (
I want to confirm my extension number.	(
The date and time are not correct.	 Set the date and time by system programming. Consult your dealer.
The visibility of the display is poor.	• ► Change the Display contrast level. (🔊 3.1.2 Settings on the Programming Mode)
I want to specify the ringing tones.	(
The MESSAGE button light has lit up.	Another extension left you a message waiting indication or someone left a message in your mailbox while you were on the phone or away from your desk.

Problem	Remedy
An SDN button on my extension does not work.	A PDN button is not assigned on the extension corresponding to your SDN button.
I cannot use the secondary Ethernet port.	• If you are using a KX-NT500 series telephone, check whether ECO mode is enabled (□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

5.3 Feature Number Table

5.3.1 Feature Number Table

Numbers listed below are the default settings. There are flexible feature numbers and fixed feature numbers. If you change the flexible feature numbers, fill in your assigned numbers (new) in the list for future reference.

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.2.1 Basic Calling		
◆ Calling Another Extension		
To call an extension (Intercom Call)	9/0	
To select an idle outside line automatically (Automatic Line Access)	0/9 ()	outside phone no.
To select an idle outside line in the specified outside line group automatically (Outside Line Group Access)	8 ()	outside line group no. (3 digits) + outside phone no.
Making a Call to a Private Network (TIE Line Access)	7 ()	private phone no.
Using an Account Code (Account Code Entry)	*49 ()	account code + # + outside phone no.
1.2.2 Easy Dialling		
Using Numbers Stored at Your Extension (Personal Speed Dialling)		
- To store	*30 ()	personal speed dialling no. (2 digits) + phone no. + #
- To dial	(* *	* + personal speed dialling no. (2 digits)
Using Numbers Stored in the PBX (System Speed Dialling)		
- To dial	* * ()	system speed dialling no. (3 digits)
To a Preset Number by Going Off-hook (Hot Line)	*740 ()	
- To store		2 + phone no. + #
- To set		1
- To cancel		0
1.2.3 Redial		

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
Redialling the Last Number You Dialled (Last Number Redial)	# ()	
1.2.4 When the Dialled Line is Busy or There is No Answer		
To cancel callback ringing (Automatic Callback Busy Cancel)/To cancel (CCBS Cancel)	*46 ()	
Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)	*70 ()	
For an extension leaving a message waiting indication		
- To leave/cancel		1/0 + extension no.
For an extension receiving a message waiting indication		
- To call back		2
- To clear		0 + your extension no.
1.2.7 Calling without Restrictions		
Using Your Calling Privileges at Another Extension (Remote COS Access)	*47 ()	extension no. + extension PIN + phone no.
To call with a verification code (Verification Code Entry)		* + verification code + verification code PIN + phone no.
1.2.8 To Access Another Party Directly from Outside (Direct Inward System Access [DISA])		
◆ Calling through DISA		
To an extension (In All Security Mode only)		your extension no./(* + verification code) + extension PIN/verification code PIN + extension no.
To an outside party (In Trunk Security Mode/All Security Mode only)		your extension no./(* + verification code) + extension PIN/verification code PIN + outside phone no.
1.2.9 Setting Your Telephone from Another Extension or through DISA (Remote Setting)		your extension no. + extension PIN + feature no.
From another extension		
- Through DISA		
1.3.3 Answering a Call Ringing at Another Telephone (Call Pickup)		

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
Answering a Call from Another Telephone (Call Pickup)		
- Group	×40 ()	group no. (2 digits)
- Directed	*41 ()	extension no.
Denying Other People the Possibility of Picking Up Your Calls (Call Pickup Deny)	*720 ()	
- To deny		1
- To allow		0
1.3.4 Answering a Call via an External Speaker (Trunk Answer From Any Station [TAFAS])		
 Calls through an external speaker 	*42 ()	Site ID (2 digits)
1.3.6 Identifying Malicious Calling Parties (Malicious Call Identification [MCID])	*7*3 ()	
1.4.1 Transferring a Call (Call Transfer)		
Transferring a Call Using the ISDN Service (Call Transfer [CT]—by ISDN)	*62 ()	phone no.
Transferring to an Outside Party Using the SIP Service		
 Blind Transfer 	* 61	phone no. + #
1.4.2 Holding a Call		
To hold (Call Hold)/To retrieve a call (Call Hold Retrieve)	*50 ()	
To retrieve a call (Call Hold Retrieve)		
 Specified with a held line number 	*53 ()	outside line no. which is held (3 digits)
 Specified with a holding extension number 	*51 ()	extension no. which has a held call
♦♦ Holding in a System Parking Zone (Call Park)	*52 ()	
- To set		parking zone no. (2 digits)/*
- To retrieve		stored parking zone no. (2 digits)

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.4.4 Answering Call Waiting		
Answering Call Waiting in the PBX	*50 ()	
Answering Call Waiting from the Telephone Company	*60 ()	
1.4.5 Multiple Party Conversation		
Adding a Third Party during a Conversation Using the ISDN Service (Three-party Conference [3PTY]—by ISDN)	*62 ()	phone no. + TRANSFER button + 3
1.6.1 Forwarding Calls		
Forwarding Your Calls (Call Forwarding [FWD])/ 1.9.2 Refusing Incoming Calls (Do Not Disturb [DND])		
- Both Calls	× 710	0 (Cancel)/ 1 (Do Not Disturb [DND])/ 2 (All calls) + phone no. + #/
- Outside Calls	×711	3 (Busy) + phone no. + #/ 4 (No Answer) + phone no. + #/
- Intercom Calls	*712 ()	5 (Busy/No Answer) + phone no. + #/ 7 (Follow Me) + your extension no./ 8 (Follow Me Cancel) + your extension no.
To set the timer for "No Answer" and "Busy/No Answer"	*713 ()	00-99 (second)
To set/cancel (Call Forwarding [FWD] for your Incoming Call Distribution Group)		
- Both Calls	× 714	
- Outside Calls	() *715 ()	1 (Set) + ICD Group extension no. + phone no. + #/
- Intercom Calls	*716 ()	0 (Cancel) + ICD Group extension no.

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
Forwarding Your Calls Using ISDN Service (Call Forwarding [CF]—by ISDN)	*7*5 ()	
- To set		outside line no. + # + multiple subscriber no. + # + 2 (Unconditional)/3 (Busy)/4 (No Reply) + phone no. + #
- To cancel		outside line no. + # + multiple subscriber no. + # + 0
- To confirm		outside line no. + # + multiple subscriber no. + # + 1
1.6.2 Showing a Message on the Caller's Telephone Display (Absent Message)	*750 ()	
- To set		1-9 (+ parameter) + #
- To cancel		0
1.6.3 Preventing Other People from Using Your Telephone (Extension Dial Lock)	*77 ()	
- To lock		1
- To unlock		0 + extension PIN
 To make an outside call while your extension is locked 	×47 ()	your extension no. + extension PIN + phone no.
1.7.1 Paging		
♦ ♦ Group Paging	*33 ()	paging group no. (3 digits)
1.7.2 Answering/Denying a Paging Announcement		
- To answer	*43 ()	
To deny	× 721	1
- To allow		0
1.7.3 Making a Conference Group Call	*32 ()	
 To call and start a conversation 		conference group no. (2 digits) + entry code + #
 To call and make an announcement 		conference group no. (2 digits) + entry code + #
Join After Time Out		

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
To make a conference group call with an entry code		conference group no. (2 digits) + entry code + #
To join a conversation with an entry code		# + conference group no. (2 digits) + entry code + #
1.8.5 Transferring Calls		
◆◆ Voice Mail Transfer		
- Both Calls	*710 ()	0 (Cancel)/ 2 (All calls)/
Outside Calls	× 711	3 (Busy)/ 4 (No Answer)/
- Intercom Calls	*712 ()	5 (Busy/No Answer) + UM group's floating extension no. 1 + #
1.9.1 Setting the Alarm (Timed Reminder)	*760 ()	
- To set		12H: 1 + hour/minute + 0 (AM)/1 (PM) + 0 (once)/1 (daily) 24H: 1 + hour/minute + 0 (once)/1 (daily)
- To cancel		0
1.9.3 Receiving Call Waiting (Call Waiting/Off-hook Call Announcement [OHCA]/Whisper OHCA)		
For intercom calls (No call/Tone/OHCA/Whisper OHCA)	*731 ()	0 (No call)/1 (Tone)/2 (OHCA)/3 (Whisper OHCA)
For outside calls (No tone/Tone)	*732 ()	0 (No tone)/1 (Tone)
1.9.4 Displaying Your Telephone Number on the Called Party and Caller's Telephone (Calling/Connected Line Identification Presentation [CLIP/ COLP])	*7*2 ()	
- Public		1
- Your extension		2
1.9.5 Preventing Your Telephone Number Being Displayed on the Caller's Telephone (Connected Line Identification Restriction [COLR])	*7*0 ()	
- To show		0
- To prevent		1

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
1.9.6 Preventing Your Number Being Displayed on the Called Party's Telephone (Calling Line Identification Restriction [CLIR])	*7*1 ()	
- To show		0
To prevent		1
1.9.7 Preventing Other People from Joining Your Conversation (Executive Busy Override Deny)	*733 ()	
To prevent		1
- To allow		0
1.9.8 Turning on the Background Music (BGM)	*751 ()	
- To set		BGM no. (1 digit)
- To cancel		0
1.9.9 Protecting Your Line against Notification Tones (Data Line Security)	*730 ()	
- To set		1
- To cancel		0
1.9.11 Setting the Parallelled Telephone to Ring (Parallelled Telephone)	*39 ()	
- Ring		1
- No Ring		0
1.9.12 Clearing Features Set at Your Extension (Extension Feature Clear)	*790 ()	
1.10.1 Leaving an Incoming Call Distribution Group (Log-in/Log-out, Wrap-up)		
Log-in	*736 ()	1 + ICD Group extension no./*
Log-out		0 + ICD Group extension no./★
To enter/leave Not Ready mode	*735 ()	1 (Not Ready)/0 (Ready)
¹² 1.10.2 Monitoring and Controlling the Call Status of an Incoming Call Distribution Group (Incoming Call Distribution Group Monitor)	*739 ()	ICD Group extension no.
1.11.1 If a Doorphone/Door Opener is Connected		

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
◆◆ Doorphone Call	*31 ()	doorphone no. (3 digits)
Opening a Door (Door Open)	*55 ()	doorphone no. (3 digits)
1.11.2 If an External Relay is Connected	*56 ()	relay no. (3 digits)
1.11.4 If a Host PBX is Connected		
Accessing External Services (External Feature Access [EFA])	*60 ()	service code
1.12.1 Using the Telephones in a Hotel-type Environment (Hospitality Features)		
Setting a Timed Reminder to a Room Extension (Remote Wake-up Call)	*76* ()	
- To set		12H: 1 + extension no. + hour/minute + 0 (AM)/1 (PM) + 0 (once)/1 (daily) 24H: 1 + extension no. + hour/minute + 0 (once)/1 (daily)
- To cancel		0 + extension no.
- To confirm		2 + extension no.
1.12.2 Recording Information Using Preprogrammed Messages (Printing Message)	*761 ()	message no. (+ parameter) + #
1.13.2 Service-in/Service-out (Smart Desk)		
◆◆ Service-in		
Main Device Service-in Operation	*722 ()	your extension no. + extension PIN
Sub Device Service-in Operation	*723 ()	your extension no. + extension PIN
Wireless Device Service-in Operation	*724 ()	your extension no. + extension PIN
◆◆ Service-out		
Service-out Operation	*725 ()	extension PIN
1.13.2 Service-in/Service-out (Smart Desk)		
1.13.3 Switching between CTI Control Devices	*726 ()	0 (Main Device)/2 (Sub Device)/3 (Wireless Device)

Feature (While dial tone is heard)	Default (New)	Additional digits/buttons
2.1.1 Extension Control		
⁻⁴ To lock/unlock other extensions (Remote Extension Dial Lock)		
- To unlock	× 782	extension no.
	()	
- To lock	×783 ()	extension no.
¹⁵ 2.1.2 Time Service Mode Control	× 780	
Day/Night/Lunch/Break	,	0/1/2/3
¹⁴ 2.1.4 Turning on the External Background Music (BGM)	*35 ()	
- To start		Site ID (2 digits)/★ + BGM no. (1 digit)
- To stop		Site ID (2 digits)/+ + 0
¹⁴ 2.1.5 Recording Outgoing Messages (OGM)	*36 ()	
- To record		1 + OGM floating extension no. 6 [To specify a site ID] 9 + Site ID (2 digits) + 1 + OGM floating extension no. 6
- To play back		2 + OGM floating extension no. 6 [To specify a site ID] 9 + Site ID (2 digits) + 2 + OGM floating extension no. 6
- To clear		0 + OGM floating extension no. 6 [To specify a site ID] 9 + Site ID (2 digits) + 0 + OGM floating extension no. 6
¹ 2.1.6 Allowing Users to Seize an Unavailable Outside Line (Trunk Busy Out)	*785 ()	outside line no. (3 digits)
3.1.1 Customising Your Phone (Personal Programming)		
Assigning an Extension PIN to Your Extension (Extension PIN [Personal Identification Number])	*799 ()	
- To set		1 + extension PIN + # + same extension PIN + #
- To cancel		0 + stored extension PIN

The UM group's default floating extension number depends on system programming. For more information, consult your System Administrator or System Manager.

^{*2} Supervisor only

^{*3} Hotel operator only

- Manager only
 Manager and preprogrammed extension user only
 The default of OGM floating extension numbers depends on system programming. For more information, consult your System Administrator or System Manager.

Feature (While busy, DND or call tone is heard/after dialling)	Default
1.2.4 When the Dialled Line is Busy or There is No Answer	
Sending a Call Waiting Notification (Call Waiting)	1
To an Extension Refusing the Call (DND Override)	
Joining an Existing Call (Executive Busy Override)	3
Leaving a Message Waiting Indication/Calling Back the Caller Who Left an Indication (Message Waiting)	4
Monitoring Another Extension (Call Monitor)	5
Reserving a Busy Line (Automatic Callback Busy)/ Setting Callback on an ISDN Line (Completion of Calls to Busy Subscriber [CCBS])	6
1.2.6 Alternating the Calling Method (Alternate Calling—Ring/Voice)	*

Feature (While dialling or talking)	Fixed Number
1.4.5 Multiple Party Conversation	
◆ Adding Other Parties during a Conversation (Conference)	3
1.11.1 If a Doorphone/Door Opener is Connected	
From any extension while talking to the doorphone	5

5.4 What is This Tone?


5.4.1 What is This Tone?

While on-hook


Ring Tones

The following tones are programmable allowing recognition of call type (Outside, Intercom or Doorphone).






Tone 2



Tone 3




Tone 4



When going off-hook

Dial Tones

Tone 1 Normal



Tone 2

- When any of the following features are set:
 - Absent Message
 - Background Music
 - Call Forwarding
 - Call Pickup Deny
 - Call Waiting
 - Do Not Disturb
 - Extension Dial Lock
 - Executive Busy Override Deny
 - Hot Line
 - Timed Reminder

Tone 3


- When answering an external sensor call
- After pressing TRANSFER or Recall/hookswitch to hold a call temporarily (e.g., Call Splitting)
- While a called PS is being searched
- When Account Code Entry is performed
- When answering a Timed Reminder call with no message

Tone 4

Message waiting indication was received.








When you make calls

Busy Tone




Reorder Tone


The outside line you tried to seize is not assigned or denied.

Ringback Tones

Tone 1



Tone 2



Do Not Disturb (DND) Tone

The dialled extension is refusing incoming calls.




While off-hook

Indication Tones

Tone 1

Call waiting tone




Tone 2

A call is on hold longer than the specified time

When talking to an outside party

Warning Tone

This tone is sent 15, 10 and 5 seconds before the specified time for disconnection.




When setting the features or programming

Confirmation Tones

Tone 1

- The feature setting was set successfully.
- A call is received in Voice-calling mode.



Tone 2

- Before receiving a page through an external speaker
- You receive a call in Hands-free mode.



Tone 3


- Before the following features activate:
 - Retrieving a held call
 - Picking up another call
 - Paging/Answering a paging announcement
 - Answering the call through a speaker
- You establish a call with an extension in the following cases:
 - The called extension has hands-free Answerback enabled.
 - Voice-calling mode
- When making a call to or from a doorphone.


Tone 4

Establishing or leaving a conference

Tone 5

A call has been put on hold.





For Future Reference

Please print, record, and retain the following information for future reference.

Note

The serial number of this product can be found on the label affixed to the unit. You should record the model number and the serial number of this unit as a permanent record of your purchase to aid in identification in the event of theft.

MODEL NO.	
SERIAL NO.	
DATE OF PURCHASE	
NAME OF DEALER	
DEALER'S ADDRESS	
DEALER'S TEL. NO.	



